

SafeNet Luna Network HSM 7.3

LUNASH COMMAND REFERENCE GUIDE



Document Information

Product Version	7.3
Document Part Number	007-013576-005
Release Date	13 December 2019

Revision History

Revision	Date	Reason
Rev. A	13 December 2019	Initial release.

Trademarks, Copyrights, and Third-Party Software

Copyright 2001-2019 Thales. All rights reserved. Thales and the Thales logo are trademarks and service marks of Thales and/or its subsidiaries and are registered in certain countries. All other trademarks and service marks, whether registered or not in specific countries, are the property of their respective owners.

Disclaimer

All information herein is either public information or is the property of and owned solely by Thales and/or its subsidiaries who shall have and keep the sole right to file patent applications or any other kind of intellectual property protection in connection with such information.

Nothing herein shall be construed as implying or granting to you any rights, by license, grant or otherwise, under any intellectual and/or industrial property rights of or concerning any of Thales's information.

This document can be used for informational, non-commercial, internal, and personal use only provided that:

- > The copyright notice, the confidentiality and proprietary legend and this full warning notice appear in all copies.
- > This document shall not be posted on any publicly accessible network computer or broadcast in any media, and no modification of any part of this document shall be made.

Use for any other purpose is expressly prohibited and may result in severe civil and criminal liabilities.

The information contained in this document is provided "AS IS" without any warranty of any kind. Unless otherwise expressly agreed in writing, Thales makes no warranty as to the value or accuracy of information contained herein.

The document could include technical inaccuracies or typographical errors. Changes are periodically added to the information herein. Furthermore, Thales reserves the right to make any change or improvement in the specifications data, information, and the like described herein, at any time.

Thales hereby disclaims all warranties and conditions with regard to the information contained herein, including all implied warranties of merchantability, fitness for a particular purpose, title and non-infringement. In no event shall Thales be liable, whether in contract, tort or otherwise, for any indirect, special or consequential

damages or any damages whatsoever including but not limited to damages resulting from loss of use, data, profits, revenues, or customers, arising out of or in connection with the use or performance of information contained in this document.

Thales does not and shall not warrant that this product will be resistant to all possible attacks and shall not incur, and disclaims, any liability in this respect. Even if each product is compliant with current security standards in force on the date of their design, security mechanisms' resistance necessarily evolves according to the state of the art in security and notably under the emergence of new attacks. Under no circumstances, shall Thales be held liable for any third party actions and in particular in case of any successful attack against systems or equipment incorporating Thales products. Thales disclaims any liability with respect to security for direct, indirect, incidental or consequential damages that result from any use of its products. It is further stressed that independent testing and verification by the person using the product is particularly encouraged, especially in any application in which defective, incorrect or insecure functioning could result in damage to persons or property, denial of service, or loss of privacy.

All intellectual property is protected by copyright. All trademarks and product names used or referred to are the copyright of their respective owners. No part of this document may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, chemical, photocopy, recording or otherwise without the prior written permission of Thales Group.

Regulatory Compliance

This product complies with the following regulatory regulations. To ensure compliancy, ensure that you install the products as specified in the installation instructions and use only Thales-supplied or approved accessories.

USA, FCC

This equipment has been tested and found to comply with the limits for a “Class B” digital device, pursuant to part 15 of the FCC rules.

Canada

This class B digital apparatus meets all requirements of the Canadian interference-causing equipment regulations.

Europe

This product is in conformity with the protection requirements of EC Council Directive 2014/30/EU. This product satisfies the CLASS B limits of EN55032.

CONTENTS

Preface: About the LunaSH Command Reference Guide	14
Customer Release Notes	14
Audience	14
Document Conventions	14
Support Contacts	16
Chapter 1: Using LunaSH	17
LunaSH Features	17
Accessing LunaSH	17
Seeing More Commands	18
Exiting LunaSH	18
Chapter 2: LunaSH Commands	19
LunaSH Command Summary	20
audit	36
audit changepwd	38
audit config	39
audit init	42
audit log	44
audit log clear	45
audit log list	46
audit log tail	47
audit log tarlogs	49
audit log untarlogs	50
audit log verify	51
audit login	54
audit logout	56
audit remotehost	57
audit remotehost add	58
audit remotehost clear	59
audit remotehost delete	60
audit remotehost list	61
audit secret	62
audit secret export	63
audit secret import	64
audit show	65
audit sync	66
client	67
client assignpartition	68
client delete	69
client fingerprint	70

client hostip	71
client hostip map	72
client hostip show	73
client hostip unmap	74
client list	75
client register	76
client revokepartition	77
client show	78
hsm	79
hsm backup	82
hsm changepolicy	84
hsm changepw	86
hsm checkcertificates	87
hsm displaylicenses	88
hsm factoryreset	89
hsm firmware	91
hsm firmware rollback	92
hsm firmware show	94
hsm firmware upgrade	95
hsm generatedak	96
hsm information	97
hsm information monitor	98
hsm information reset	101
hsm information show	102
hsm init	103
hsm loadcustomercert	106
hsm login	107
hsm logout	108
hsm ped	109
hsm ped connect	110
hsm ped deselect	113
hsm ped disconnect	114
hsm ped show	115
hsm ped select	117
hsm ped server	118
hsm ped server delete	119
hsm ped server list	120
hsm ped server register	121
hsm ped set	122
hsm ped timeout	123
hsm ped timeout set	124
hsm ped timeout show	125
hsm ped vector	126
hsm ped vector erase	127
hsm ped vector init	128
hsm qos metrics	129
hsm qos metrics reset	129

hsm qos metrics show	132
hsm restore	136
hsm selftest	138
hsm setlegacydomain	139
hsm show	140
hsm showpolicies	145
hsm stc	147
hsm stc activationtimeout	149
hsm stc activationtimeout set	150
hsm stc activationtimeout show	151
hsm stc cipher	152
hsm stc cipher disable	153
hsm stc cipher enable	154
hsm stc cipher show	155
hsm stc disable	156
hsm stc enable	157
hsm stc hmac	158
hsm stc hmac disable	159
hsm stc hmac enable	160
hsm stc hmac show	161
hsm stc identity	162
hsm stc identity create	163
hsm stc identity delete	164
hsm stc identity initialize	165
hsm stc identity partition	166
hsm stc identity partition deregister	167
hsm stc identity partition register	168
hsm stc identity show	169
hsm stc partition	170
hsm stc partition export	171
hsm stc partition show	172
hsm stc rekeythreshold	173
hsm stc rekeythreshold set	174
hsm stc rekeythreshold show	175
hsm stc status	176
hsm stm	177
hsm stm recover	178
hsm stm show	180
hsm stm transport	181
hsm supportinfo	182
hsm tamper	183
hsm tamper clear	184
hsm tamper show	185
hsm update	186
hsm update capability	187
hsm update show	189
hsm zeroize	190

my	192
my file	193
my file clear	194
my file delete	195
my file list	196
my password	197
my password expiry show	198
my password set	199
my public-key	200
my public-key add	201
my public-key clear	202
my public-key delete	203
my public-key list	204
network	205
network dns	206
network dns add	207
network dns add nameserver	208
network dns add searchdomain	209
network dns delete	210
network dns delete nameserver	211
network dns delete searchdomain	212
network hostname	213
network interface	214
network interface bonding	216
network interface bonding config	217
network interface bonding disable	218
network interface bonding enable	219
network interface bonding show	221
network interface delete	222
network interface dhcp	223
network interface slaac	226
network interface static	228
network ping	231
network route	232
network route add	233
network route clear	235
network route delete	236
network route show	238
network show	239
ntls	242
ntls bind	243
ntls certificate	245
ntls certificate monitor	246
ntls certificate monitor disable	247
ntls certificate monitor enable	248
ntls certificate monitor show	249
ntls certificate monitor trap trigger	250

ntls certificate show	251
ntls information	253
ntls information reset	254
ntls information show	255
ntls ipcheck	256
ntls ipcheck disable	257
ntls ipcheck enable	258
ntls ipcheck show	259
ntls show	260
ntls tcp_keepalive	261
ntls tcp_keepalive set	262
ntls tcp_keepalive show	264
ntls threads	265
ntls threads set	266
ntls threads show	268
ntls timer	269
ntls timer set	270
ntls timer show	271
package	272
package deletefile	273
package erase	274
package list	275
package listfile	276
package update	277
package verify	279
partition	280
partition backup	281
partition create	285
partition delete	287
partition list	288
partition rename	289
partition resize	290
partition restore	292
partition show	294
service	296
service list	297
service restart	298
service start	300
service status	301
service stop	302
status	303
status cpu	305
status date	306
status disk	307
status handles	309
status interface	311
status mac	312

status mem	313
status memmap	314
status netstat	315
status ps	317
status sensors	318
status sysstat	321
status sysstat code	322
status sysstat show	324
status time	325
status zone	326
stc	327
stc activationtimeout	328
stc activationtimeout set	329
stc activationtimeout show	330
stc cipher	331
stc cipher disable	332
stc cipher enable	333
stc cipher show	334
stc hmac	335
stc hmac disable	336
stc hmac enable	337
stc hmac show	338
stc partition	339
stc partition export	340
stc partition show	341
stc rekeythreshold	342
stc rekeythreshold set	343
stc rekeythreshold show	344
sysconf	345
sysconf appliance	347
sysconf appliance hardreboot	348
sysconf appliance poweroff	349
sysconf appliance reboot	350
sysconf appliance rebootonpanic	351
sysconf appliance rebootonpanic disable	352
sysconf appliance rebootonpanic enable	353
sysconf appliance rebootonpanic show	354
sysconf banner	355
sysconf banner add	356
sysconf banner clear	358
sysconf config	359
sysconf config backup	360
sysconf config clear	362
sysconf config delete	363
sysconf config export	364
sysconf config factoryreset	365
sysconf config import	369

sysconf config list	370
sysconf config restore	371
sysconf config show	373
sysconf drift	374
sysconf drift init	375
sysconf drift reset	376
sysconf drift set	377
sysconf drift startmeasure	378
sysconf drift status	379
sysconf drift stopmeasure	380
sysconf fingerprint	381
sysconf fingerprint license	382
sysconf fingerprint ntlm	383
sysconf fingerprint ssh	384
sysconf forcesologin	385
sysconf forcesologin disable	387
sysconf forcesologin enable	388
sysconf forcesologin show	390
sysconf license	391
sysconf license apply	392
sysconf license list	393
sysconf license revoke	394
sysconf ntp	395
sysconf ntp addserver	396
sysconf ntp autokeyauth	398
sysconf ntp autokeyauth clear	399
sysconf ntp autokeyauth generate	400
sysconf ntp autokeyauth install	402
sysconf ntp autokeyauth list	403
sysconf ntp autokeyauth update	404
sysconf ntp deleteserver	405
sysconf ntp disable	406
sysconf ntp enable	407
sysconf ntp listservers	408
sysconf ntp log tail	409
sysconf ntp ntpdate	410
sysconf ntp show	411
sysconf ntp status	412
sysconf ntp symmetricauth	414
sysconf ntp symmetricauth key	415
sysconf ntp symmetricauth key add	416
sysconf ntp symmetricauth key clear	417
sysconf ntp symmetricauth key delete	418
sysconf ntp symmetricauth key list	419
sysconf ntp symmetricauth trustedkeys	420
sysconf ntp symmetricauth trustedkeys add	421
sysconf ntp symmetricauth trustedkeys clear	422

sysconf ntp symmetricauth trustedkeys delete	423
sysconf ntp symmetricauth trustedkeys list	424
sysconf radius	425
sysconf radius addserver	426
sysconf radius deleteserver	427
sysconf radius disable	428
sysconf radius enable	429
sysconf radius show	430
sysconf regencert	431
sysconf reimage	433
sysconf reimage start	434
sysconf reimage tarlog	436
sysconf snmp	437
sysconf snmp disable	438
sysconf snmp enable	439
sysconf snmp notification	440
sysconf snmp notification add	441
sysconf snmp notification clear	443
sysconf snmp notification delete	444
sysconf snmp notification list	445
sysconf snmp show	446
sysconf snmp trap	447
sysconf snmp trap clear	448
sysconf snmp trap disable	449
sysconf snmp trap enable	450
sysconf snmp trap set	451
sysconf snmp trap show	452
sysconf snmp trap test	453
sysconf snmp user	455
sysconf snmp user add	456
sysconf snmp user clear	458
sysconf snmp user delete	459
sysconf snmp user list	460
sysconf ssh	461
sysconf ssh device	462
sysconf ssh ip	463
sysconf ssh password	464
sysconf ssh password disable	465
sysconf ssh password enable	466
sysconf ssh port	467
sysconf ssh publickey	468
sysconf ssh publickey disable	469
sysconf ssh publickey enable	470
sysconf ssh regenkeypair	471
sysconf ssh show	472
sysconf time	473
sysconf timezone	474

sysconf timezone list	475
sysconf timezone set	476
sysconf timezone show	477
sysconf tls ciphers	478
sysconf tls ciphers reset	479
sysconf tls ciphers set	482
sysconf tls ciphers show	485
syslog	487
syslog cleanup	488
syslog export	489
syslog period	490
syslog rotate	491
syslog remotehost	492
syslog remotehost add	493
syslog remotehost clear	494
syslog remotehost delete	495
syslog remotehost list	496
syslog rotations	497
syslog severity set	498
syslog show	499
syslog tail	501
syslog tarlogs	503
token backup	504
token backup factoryreset	506
token backup init	508
token backup list	511
token backup login	513
token backup logout	515
token backup partition	517
token backup partition delete	519
token backup partition list	521
token backup partition show	523
token backup show	525
token backup update	527
token backup update capability	529
token backup update firmware	531
token backup update show	533
user	534
user add	535
user delete	536
user disable	537
user enable	538
user list	539
user password	540
user radiusadd	541
user role	542
user role add	543

user role clear	545
user role delete	546
user role import	547
user role list	548
webserver	549
webserver bind	550
webserver certificate	552
webserver certificate generate	553
webserver certificate show	555
webserver ciphers	557
webserver ciphers set	558
webserver ciphers show	559
webserver disable	560
webserver enable	561
webserver show	562

PREFACE: About the LunaSH Command Reference Guide

This document describes how to access and use the LunaSH command line interface. It contains the following chapters:

- > "Using LunaSH" on page 17
- > "LunaSH Commands" on page 19

This preface also includes the following information about this document:

- > "Customer Release Notes" below
- > "Audience" below
- > "Document Conventions" below
- > "Support Contacts" on page 16

For information regarding the document status and revision history, see "Document Information" on page 2.

Customer Release Notes

The customer release notes (CRN) provide important information about this release that is not included in the customer documentation. Read the CRN to fully understand the capabilities, limitations, and known issues for this release. You can view or download the latest version of the CRN from the Technical Support Customer Portal at <https://supportportal.gemalto.com>.

Audience

This document is intended for personnel responsible for maintaining your organization's security infrastructure. This includes SafeNet Luna Network HSM users and security officers, key manager administrators, and network administrators.

All products manufactured and distributed by Thales Group are designed to be installed, operated, and maintained by personnel who have the knowledge, training, and qualifications required to safely perform the tasks assigned to them. The information, processes, and procedures contained in this document are intended for use by trained and qualified personnel only.

It is assumed that the users of this document are proficient with security concepts.

Document Conventions

This document uses standard conventions for describing the user interface and for alerting you to important information.

Notes

Notes are used to alert you to important or helpful information. They use the following format:

NOTE Take note. Contains important or helpful information.

Cautions

Cautions are used to alert you to important information that may help prevent unexpected results or data loss. They use the following format:

CAUTION! Exercise caution. Contains important information that may help prevent unexpected results or data loss.

Warnings

Warnings are used to alert you to the potential for catastrophic data loss or personal injury. They use the following format:

****WARNING**** Be extremely careful and obey all safety and security measures. In this situation you might do something that could result in catastrophic data loss or personal injury.

Command Syntax and Typeface Conventions

Format	Convention
bold	The bold attribute is used to indicate the following: <ul style="list-style-type: none"> > Command-line commands and options (Type dir /p.) > Button names (Click Save As.) > Check box and radio button names (Select the Print Duplex check box.) > Dialog box titles (On the Protect Document dialog box, click Yes.) > Field names (User Name: Enter the name of the user.) > Menu names (On the File menu, click Save.) (Click Menu > Go To > Folders.) > User input (In the Date box, type April 1.)
<i>italics</i>	In type, the italic attribute is used for emphasis or to indicate a related document. (See the <i>Installation Guide</i> for more information.)
<variable>	In command descriptions, angle brackets represent variables. You must substitute a value for command line arguments that are enclosed in angle brackets.
[optional] [<optional>]	Represent optional keywords or <variables> in a command line description. Optionally enter the keyword or <variable> that is enclosed in square brackets, if it is necessary or desirable to complete the task.

Format	Convention
{a b c} {<a> <c>}	Represent required alternate keywords or <variables> in a command line description. You must choose one command line argument enclosed within the braces. Choices are separated by vertical (OR) bars.
[a b c] [<a> <c>]	Represent optional alternate keywords or variables in a command line description. Choose one command line argument enclosed within the braces, if desired. Choices are separated by vertical (OR) bars.

Support Contacts

If you encounter a problem while installing, registering, or operating this product, please refer to the documentation before contacting support. If you cannot resolve the issue, contact your supplier or [Thales Customer Support](#).

Thales Customer Support operates 24 hours a day, 7 days a week. Your level of access to this service is governed by the support plan arrangements made between Thales and your organization. Please consult this support plan for further information about your entitlements, including the hours when telephone support is available to you.

Customer Support Portal

The Customer Support Portal, at <https://supportportal.thalesgroup.com>, is where you can find solutions for most common problems. The Customer Support Portal is a comprehensive, fully searchable database of support resources, including software and firmware downloads, release notes listing known problems and workarounds, a knowledge base, FAQs, product documentation, technical notes, and more. You can also use the portal to create and manage support cases.

NOTE You require an account to access the Customer Support Portal. To create a new account, go to the portal and click on the **REGISTER** link.

Telephone

The support portal also lists telephone numbers for voice contact ([Contact Us](#)).

CHAPTER 1: Using LunaSH

This chapter describes how to access and use the LunaSH utility. It contains the following topics:

- > ["LunaSH Features" below](#)
- > ["Accessing LunaSH" below](#)
- > ["Seeing More Commands" on the next page](#)
- > ["Exiting LunaSH" on the next page](#)

LunaSH Features

LunaSH provides the following features:

- > Command history is supported, using up/down arrows, **Home**, **End**, **Page Up**, **Page Down**.
- > Command shortnames are supported. You must type sufficient letters of a command or sub-command to make the input unique in the current syntax. For example, you could invoke system syntax help with "help", "hel", "he", but not just "h" (because there is also an "hsm" command and typing just "h" is not sufficient to indicate whether you want "help" or "hsm"). Additionally, for syntax help, the alias "?" is available.
- > When the logging function is active, the full name of a command is recorded in the log, not the short version.
- > If you supply a short form that is ambiguous, an error message is presented, followed by the list of available commands, sub-commands, or options at the current level.
- > Context-sensitive command completion is supported, using **Tab**.
- > Commands and options are case-insensitive.

NOTE Sub-commands do not take a leading dash; options must be typed with a leading single dash. If a command is refused, retry, being careful to type correct syntax. If you are unsure, type the command name followed by a question mark, to force a syntax error and a summary of the proper syntax for that command.

Accessing LunaSH

LunaSH is the command interface for SafeNet Luna Network HSM.

Connect to the SafeNet appliance using any SSH-capable communication utility (Windows users can use the provided putty.exe).

When a successful connection is made, a terminal window opens and the prompt "login as:" appears.

For maximum access, type "admin" and press **Enter**.

You are prompted for the admin password. If this is the first time you have connected, the default password is "PASSWORD", and you are required to change it to something more secure.

Once you have logged in, the system presents the LunaSH prompt, which includes the hostname that you have assigned to your SafeNet appliance:

```
[myLuna] lunash:>
```

You can now issue any LunaSH command. For a summary, type "?" or "help" and press **Enter**.

If the admin user has previously created other users, and you know the relevant password, you can log in as a named user instead of "admin".

Seeing More Commands

All of the top-level LunaSH commands (except "exit") have sub-commands and options.

To view a syntax summary of a command, type "help" or "?" followed by the command name. You can also type a command name followed by a space, followed by a character that is unlikely to appear in the sub-commands or options, like "?" or "h".

Exiting LunaSH

Any time you wish to leave your lunash:> session, type "e", "ex", "exi", or "exit" at the prompt and press **Enter**. Your session terminates and the terminal window closes.

To return to lunash:>, you will need to open a new terminal session (with PuTTY.exe or SSH, as appropriate) and login as admin when the "login as:" prompt appears.

CHAPTER 2: LunaSH Commands

This chapter describes the commands available in the SafeNet Luna Network HSM command shell (LunaSH). The commands are described in alphabetical order and provide:

- > A brief description of the command function
- > The users who are able to access the command
- > The command syntax and parameter descriptions
- > Usage examples

See "[LunaSH Command Summary](#)" on the next page for a list of all of the LunaSH commands and the user privileges required to access them.

The following table provides links to the top-level commands in the hierarchy. Select a link to display the command syntax or to navigate to the sub-command you need:

Argument(s)	Shortcut	Description
audit	a	Perform HSM auditing tasks. These commands are available only to the Audit user. See " audit " on page 36.
client	c	Manage HSM clients and their access to HSM partitions. See " client " on page 67.
hsm	hs	Manage the HSM on the appliance. See " hsm " on page 79.
my	m	Manage the current user's files, passwords, and public keys. See " my " on page 192.
network	ne	View and configure network settings. See " network " on page 205.
ntls	nt	Manage the network trust link service (NTLS). See " ntls " on page 242.
package	pac	Manage secure package updates. See " package " on page 272.
partition	par	Manage partitions on the HSM. See " partition " on page 280.
service	se	View or manage services. See " service " on page 296.
status	sta	View the current system status. See " status " on page 303.
stc	stc	Configure and manage secure trusted channel (STC) network links between partitions and clients. See " stc " on page 327.

Argument(s)	Shortcut	Description
sysconf	sysc	Configure the appliance. See "sysconf" on page 345 .
syslog	sysl	Manage the system logs. See "syslog" on page 487 .
token backup	t	Access backup commands. See "token backup" on page 504 .
user	u	Manage users and their roles. See "user" on page 534 .
webserver	w	Configure REST API services (if you have the upgrade installed). See "webserver" on page 549 .

LunaSH Command Summary

This section provides a summary of all of the LunaSH commands, and which users are able to access the commands.

The standard administrative LunaSH user accounts on the SafeNet Luna Network HSM appliance are:

admin	All commands, except some specialized audit commands. This is the highest-level, full-access administrative role.
operator	Most commands, except some configuration commands for the system and the HSM.
monitor	Only commands that present information about the appliance or the HSM.
audit	Only commands governing HSM audit logging functions.

When you log into the appliance as one of the standard users (or a custom user assigned one of the standard roles), you are able to access the subset of commands listed in the relevant column below. You can also create custom user roles and specify the list of commands that user role is able to access (see ["Appliance Roles and Procedures" on page 1](#)).

Some commands are restricted to the HSM SO or Auditor; these will not work until you log in to the HSM using **hsm login** or **audit login**.

NOTE The commands marked "configurable" do not require **hsm login** by default. You can use **sysconf forcesologin enable** to require **hsm login** for these commands (see ["sysconf forcesologin" on page 385](#)).

Command	admin	operator	monitor	audit	hsm or audit login required
exit	✓	✓	✓	✓	

Command	admin	operator	monitor	audit	hsm or audit login required
help	✓	✓	✓	✓	
audit					
"audit changepwd" on page 38				✓	
"audit config" on page 39				✓	✓
"audit init" on page 42				✓	
"audit log clear" on page 45				✓	
"audit log list" on page 46				✓	
"audit log tail" on page 47				✓	
"audit log tarlogs" on page 49				✓	
"audit log untarlogs" on page 50				✓	
"audit log verify" on page 51				✓	
"audit login" on page 54				✓	
"audit logout" on page 56				✓	✓
"audit remotehost add" on page 58				✓	
"audit remotehost clear" on page 59				✓	
"audit remotehost delete" on page 60				✓	
"audit remotehost list" on page 61				✓	
"audit secret export" on page 63				✓	✓
"audit secret import" on page 64				✓	✓
"audit show" on page 65				✓	
"audit sync" on page 66				✓	✓
client					
"client assignpartition" on page 68	✓	✓			configurable
"client delete" on page 69	✓	✓			configurable

Command	admin	operator	monitor	audit	hsm or audit login required
"client fingerprint" on page 70	✓	✓			
"client hostip map" on page 72	✓	✓			configurable
"client hostip show" on page 73	✓	✓	✓		
"client hostip unmap" on page 74	✓	✓			configurable
"client list" on page 75	✓	✓	✓		
"client register" on page 76	✓	✓			configurable
"client revokepartition" on page 77	✓	✓			configurable
"client show" on page 78	✓	✓	✓		
hsm					
"hsm backup" on page 82	✓	✓			
"hsm changepolicy" on page 84	✓				✓
"hsm changepw" on page 86	✓				
"hsm checkcertificates" on page 87	✓	✓	✓		
"hsm displaylicenses" on page 88	✓	✓	✓		
"hsm factoryreset" on page 89	✓				
"hsm firmware rollback" on page 92	✓	✓			✓
"hsm firmware show" on page 94	✓	✓	✓		
"hsm firmware upgrade" on page 95	✓	✓			✓
"hsm generatedak" on page 96	✓	✓			
"hsm information monitor" on page 98	✓	✓	✓		
"hsm information reset" on page 101	✓	✓			
"hsm information show" on page 102	✓	✓	✓		
"hsm init" on page 103	✓				

Command	admin	operator	monitor	audit	hsm or audit login required
"hsm loadcustomercert" on page 106	✓	✓			
"hsm login" on page 107	✓	✓			
"hsm logout" on page 108	✓	✓			✓
"hsm ped connect" on page 110	✓	✓		✓	
"hsm ped deselect" on page 113	✓	✓		✓	
"hsm ped disconnect" on page 114	✓	✓		✓	
"hsm ped select" on page 117	✓	✓		✓	
"hsm ped server delete" on page 119	✓				
"hsm ped server list" on page 120	✓	✓	✓		
"hsm ped server register" on page 121	✓				
"hsm ped set" on page 122	✓				
"hsm ped show" on page 115	✓	✓	✓	✓	
"hsm ped timeout set" on page 124	✓	✓		✓	
"hsm ped timeout show" on page 125	✓	✓	✓	✓	
"hsm ped vector erase" on page 127	✓				
"hsm ped vector init" on page 128	✓				✓
"hsm restore" on page 136	✓	✓			✓
"hsm selftest" on page 138	✓	✓	✓		
"hsm setlegacydomain" on page 139	✓				
"hsm show" on page 140	✓	✓	✓		
"hsm showpolicies" on page 145	✓	✓	✓	✓	
"hsm stc activationtimeout set" on page 150	✓	✓			
"hsm stc activationtimeout show" on page 151	✓	✓			

Command	admin	operator	monitor	audit	hsm or audit login required
"hsm stc cipher disable" on page 153	✓	✓			
"hsm stc cipher enable" on page 154	✓	✓			
"hsm stc cipher show" on page 155	✓	✓			
"hsm stc disable" on page 156	✓	✓			
"hsm stc enable" on page 157	✓	✓			
"hsm stc hmac disable" on page 159	✓	✓			
"hsm stc hmac enable" on page 160	✓	✓			
"hsm stc hmac show" on page 161	✓	✓			
"hsm stc identity create" on page 163	✓	✓			
"hsm stc identity delete" on page 164	✓	✓			
"hsm stc identity initialize" on page 165	✓	✓			
"hsm stc identity partition deregister" on page 167	✓	✓			
"hsm stc identity partition register" on page 168	✓	✓			
"hsm stc identity show" on page 169	✓	✓			
"hsm stc partition export" on page 171	✓	✓			✓
"hsm stc partition show" on page 172	✓	✓			
"hsm stc rekeythreshold set" on page 174	✓	✓			✓
"hsm stc rekeythreshold show" on page 175	✓	✓			
"hsm stc status" on page 176	✓	✓	✓		
"hsm stm recover" on page 178	✓	✓			✓
"hsm stm show" on page 180	✓	✓	✓		
"hsm stm transport" on page 181	✓	✓			✓
"hsm supportinfo" on page 182	✓	✓	✓		

Command	admin	operator	monitor	audit	hsm or audit login required
"hsm tamper clear" on page 184	✓				✓
"hsm tamper show" on page 185	✓	✓	✓		
"hsm update capability" on page 187	✓	✓			
"hsm update show" on page 189	✓	✓			
"hsm zeroize" on page 190	✓				
my					
"my file clear" on page 194	✓	✓	✓	✓	
"my file delete" on page 195	✓	✓	✓	✓	
"my file list" on page 196	✓	✓	✓	✓	
"my password expiry show" on page 198	✓	✓	✓	✓	
"my password set" on page 199	✓	✓	✓	✓	
"my public-key add" on page 201	✓	✓	✓	✓	
"my public-key clear" on page 202	✓	✓	✓	✓	
"my public-key delete" on page 203	✓	✓	✓	✓	
"my public-key list" on page 204	✓	✓	✓	✓	
network					
"network dns add nameserver" on page 208	✓	✓			
"network dns add searchdomain" on page 209	✓	✓			
"network dns delete nameserver" on page 211	✓	✓			
"network dns delete searchdomain" on page 212	✓	✓			
"network hostname" on page 213	✓	✓			
"network interface bonding config" on page 217	✓	✓			
"network interface bonding disable" on page 218	✓	✓			
"network interface bonding enable" on page 219	✓	✓			

Command	admin	operator	monitor	audit	hsm or audit login required
"network interface bonding show" on page 221	✓	✓	✓		
"network interface delete" on page 222	✓	✓			
"network interface dhcp" on page 223	✓	✓			
"network interface slaac" on page 226	✓	✓			
"network interface static" on page 228	✓	✓			
"network ping" on page 231	✓	✓	✓	✓	
"network route add" on page 233	✓	✓			
"network route clear" on page 235	✓	✓			
"network route delete" on page 236	✓	✓			
"network route show" on page 238	✓	✓	✓		
"network show" on page 239	✓	✓	✓	✓	
ntls					
"ntls bind" on page 243	✓	✓			configurable
"ntls certificate monitor disable" on page 247	✓	✓			configurable
"ntls certificate monitor enable" on page 248	✓	✓			configurable
"ntls certificate monitor show" on page 249	✓	✓	✓		
"ntls certificate monitor trap trigger" on page 250	✓	✓			configurable
"ntls certificate show" on page 251	✓	✓	✓		
"ntls information reset" on page 254	✓	✓			configurable
"ntls information show" on page 255	✓	✓	✓		
"ntls ipcheck disable" on page 257	✓	✓			configurable
"ntls ipcheck enable" on page 258	✓	✓			configurable
"ntls ipcheck show" on page 259	✓	✓	✓		

Command	admin	operator	monitor	audit	hsm or audit login required
"ntls show" on page 260	✓	✓	✓		
"ntls tcp_keepalive set" on page 262	✓	✓			configurable
"ntls tcp_keepalive show" on page 264	✓	✓	✓		
"ntls threads set" on page 266	✓	✓			configurable
"ntls threads show" on page 268	✓	✓	✓		
"ntls timer set" on page 270	✓	✓			configurable
"ntls timer show" on page 271	✓	✓	✓		
package					
"package deletelfile" on page 273	✓	✓			
"package erase" on page 274	✓	✓			✓
"package list" on page 275	✓	✓	✓		
"package listfile" on page 276	✓	✓	✓		
"package update" on page 277	✓	✓			✓
"package verify" on page 279	✓	✓			✓
partition					
"partition backup" on page 281	✓	✓			
"partition create" on page 285	✓	✓			✓
"partition delete" on page 287	✓	✓			✓
"partition list" on page 288	✓	✓	✓		
"partition rename" on page 289	✓	✓			✓
"partition resize" on page 290	✓	✓			✓
"partition restore" on page 292	✓	✓			
"partition show" on page 294	✓	✓	✓		
service					

Command	admin	operator	monitor	audit	hsm or audit login required
"service list" on page 297	✓	✓	✓		
"service restart" on page 298	✓	✓			
"service start" on page 300	✓	✓			
"service status" on page 301	✓	✓	✓		
"service stop" on page 302	✓	✓			
status					
"status cpu" on page 305	✓	✓	✓		
"status date" on page 306	✓	✓	✓		
"status disk" on page 307	✓	✓	✓		
"status handles" on page 309	✓	✓	✓		
"status interface" on page 311	✓	✓	✓		
"status mac" on page 312	✓	✓	✓		
"status mem" on page 313	✓	✓	✓		
"status memmap" on page 314	✓	✓	✓		
"status netstat" on page 315	✓	✓	✓		
"status ps" on page 317	✓	✓	✓		
"status sensors" on page 318	✓	✓	✓		
"status sysstat code" on page 322	✓	✓	✓		
"status sysstat show" on page 324	✓	✓	✓		
"status time" on page 325	✓	✓	✓		
"status zone" on page 326	✓	✓	✓		
stc					
"stc activationtimeout set" on page 329	✓	✓			✓
"stc activationtimeout show" on page 330	✓	✓	✓		✓

Command	admin	operator	monitor	audit	hsm or audit login required
"stc cipher disable" on page 332	✓	✓			✓
"stc cipher enable" on page 333	✓	✓			✓
"stc cipher show" on page 334	✓	✓	✓		✓
"stc hmac disable" on page 336	✓	✓			✓
"stc hmac enable" on page 337	✓	✓			✓
"stc hmac show" on page 338	✓	✓	✓		✓
"stc partition export" on page 340	✓	✓			✓
"stc partition show" on page 341	✓	✓	✓		✓
"stc rekeythreshold set" on page 343	✓	✓			✓
"stc rekeythreshold show" on page 344	✓	✓	✓		✓
sysconf					
"sysconf appliance hardreboot" on page 348	✓				
"sysconf appliance poweroff" on page 349	✓	✓			
"sysconf appliance reboot" on page 350	✓	✓			
"sysconf appliance rebootonpanic disable" on page 352	✓	✓			
"sysconf appliance rebootonpanic enable" on page 353	✓	✓			
"sysconf appliance rebootonpanic show" on page 354	✓	✓	✓		
"sysconf banner add" on page 356	✓				
"sysconf banner clear" on page 358	✓				
"sysconf config backup" on page 360	✓				
"sysconf config clear" on page 362	✓				
"sysconf config delete" on page 363	✓				

Command	admin	operator	monitor	audit	hsm or audit login required
"sysconf config export" on page 364	✓				
"sysconf config factoryreset" on page 365	✓				configurable
"sysconf config import" on page 369	✓				
"sysconf config list" on page 370	✓	✓	✓		
"sysconf config restore" on page 371	✓				
"sysconf config show" on page 373	✓	✓	✓		
"sysconf drift init" on page 375	✓	✓			
"sysconf drift reset" on page 376	✓	✓			
"sysconf drift set" on page 377	✓	✓			
"sysconf drift startmeasure" on page 378	✓	✓			
"sysconf drift status" on page 379	✓	✓	✓		
"sysconf drift stopmeasure" on page 380	✓	✓			
"sysconf fingerprint license" on page 382	✓	✓	✓		
"sysconf fingerprint ntlis" on page 383	✓	✓	✓		
"sysconf fingerprint ssh" on page 384	✓	✓	✓		
"sysconf forcesologin disable" on page 387	✓				✓
"sysconf forcesologin enable" on page 388	✓				✓
"sysconf forcesologin show" on page 390	✓				
"sysconf license apply" on page 392	✓				✓
"sysconf license list" on page 393	✓	✓	✓		
"sysconf license revoke" on page 394	✓				✓
"sysconf ntp addserver" on page 396	✓	✓			
"sysconf ntp autokeyauth clear" on page 399	✓	✓			

Command	admin	operator	monitor	audit	hsm or audit login required
"sysconf ntp autokeyauth generate" on page 400	✓	✓			
"sysconf ntp autokeyauth install" on page 402	✓	✓			
"sysconf ntp autokeyauth list" on page 403	✓	✓			
"sysconf ntp autokeyauth update" on page 404	✓	✓			
"sysconf ntp deleteserver" on page 405	✓	✓			
"sysconf ntp disable" on page 406	✓	✓			
"sysconf ntp enable" on page 407	✓	✓			
"sysconf ntp listservers" on page 408	✓	✓	✓		
"sysconf ntp log tail" on page 409	✓	✓			
"sysconf ntp ntpdate" on page 410	✓	✓			
"sysconf ntp show" on page 411	✓	✓	✓		
"sysconf ntp status" on page 412	✓	✓	✓		
"sysconf ntp symmetricauth key add" on page 416	✓	✓			
"sysconf ntp symmetricauth key clear" on page 417	✓	✓			
"sysconf ntp symmetricauth key delete" on page 418	✓	✓			
"sysconf ntp symmetricauth key list" on page 419	✓	✓	✓		
"sysconf ntp symmetricauth trustedkeys add" on page 421	✓	✓			
"sysconf ntp symmetricauth trustedkeys clear" on page 422	✓	✓			
"sysconf ntp symmetricauth trustedkeys delete" on page 423	✓	✓			
"sysconf ntp symmetricauth trustedkeys list" on page 424	✓	✓	✓		

Command	admin	operator	monitor	audit	hsm or audit login required
"sysconf radius addserver" on page 426	✓				
"sysconf radius deleteserver" on page 427	✓				
"sysconf radius disable" on page 428	✓				
"sysconf radius enable" on page 429	✓				
"sysconf radius show" on page 430	✓				
"sysconf regencert" on page 431	✓				configurable
"sysconf reimage start" on page 434	✓				✓
"sysconf reimage tarlog" on page 436	✓				
"sysconf snmp disable" on page 438	✓	✓			
"sysconf snmp enable" on page 439	✓	✓			
"sysconf snmp notification add" on page 441	✓	✓			
"sysconf snmp notification clear" on page 443	✓	✓			
"sysconf snmp notification delete" on page 444	✓	✓			
"sysconf snmp notification list" on page 445	✓	✓	✓		
"sysconf snmp show" on page 446	✓	✓	✓		
"sysconf snmp trap clear" on page 448	✓	✓			
"sysconf snmp trap disable" on page 449	✓	✓			
"sysconf snmp trap enable" on page 450	✓	✓			
"sysconf snmp trap set" on page 451	✓	✓			
"sysconf snmp trap show" on page 452	✓	✓	✓		
"sysconf snmp trap test" on page 453	✓	✓			
"sysconf snmp user add" on page 456	✓	✓			
"sysconf snmp user clear" on page 458	✓	✓			

Command	admin	operator	monitor	audit	hsm or audit login required
"sysconf snmp user delete" on page 459	✓	✓			
"sysconf snmp user list" on page 460	✓	✓	✓		
"sysconf ssh device" on page 462	✓	✓			
"sysconf ssh ip" on page 463	✓	✓			
"sysconf ssh password disable" on page 465	✓	✓			
"sysconf ssh password enable" on page 466	✓	✓			
"sysconf ssh port" on page 467	✓				
"sysconf ssh publickey disable" on page 469	✓	✓			
"sysconf ssh publickey enable" on page 470	✓	✓			
"sysconf ssh regenkeypair" on page 471	✓	✓			
"sysconf ssh show" on page 472	✓	✓	✓		
"sysconf time" on page 473	✓	✓			
"sysconf timezone list" on page 475	✓	✓	✓		
"sysconf timezone set" on page 476	✓	✓			
"sysconf timezone show" on page 477	✓	✓	✓		
"sysconf tls ciphers reset" on page 479	✓				
"sysconf tls ciphers set" on page 482	✓				
"sysconf tls ciphers show" on page 485	✓	✓	✓		
syslog					
"syslog cleanup" on page 488	✓				
"syslog export" on page 489	✓	✓			
"syslog period" on page 490	✓	✓			
"syslog remotehost add" on page 493	✓	✓			
"syslog remotehost clear" on page 494	✓	✓			

Command	admin	operator	monitor	audit	hsm or audit login required
"syslog remotehost delete" on page 495	✓	✓			
"syslog remotehost list" on page 496	✓	✓			
"syslog rotate" on page 491	✓	✓			
"syslog rotations" on page 497	✓	✓			
"syslog severity set" on page 498	✓				
"syslog show" on page 499	✓	✓	✓		
"syslog tail" on page 501	✓	✓	✓		
"syslog tarlogs" on page 503	✓	✓	✓		
token					
"token backup factoryreset" on page 506	✓	✓			
"token backup init" on page 508	✓	✓			
"token backup list" on page 511	✓	✓	✓		
"token backup login" on page 513	✓	✓			
"token backup logout" on page 515	✓	✓			
"token backup partition delete" on page 519	✓	✓			
"token backup partition list" on page 521	✓	✓	✓		
"token backup partition show" on page 523	✓	✓	✓		
"token backup show" on page 525	✓	✓	✓		
"token backup update capability" on page 529	✓	✓			
"token backup update firmware" on page 531	✓	✓			
"token backup update show" on page 533	✓	✓	✓		
user					
"user add" on page 535	✓				
"user delete" on page 536	✓				

Command	admin	operator	monitor	audit	hsm or audit login required
"user disable" on page 537	✓				
"user enable" on page 538	✓				
"user list" on page 539	✓				
"user password" on page 540	✓				
"user radiusadd" on page 541	✓				
"user role add" on page 543	✓				
"user role clear" on page 545	✓				
"user role delete" on page 546	✓				
"user role import" on page 547	✓				
"user role list" on page 548	✓				
webserver					
"webserver bind" on page 550	✓				
"webserver certificate generate" on page 553	✓				
"webserver certificate show" on page 555	✓				
"webserver ciphers set" on page 558	✓				
"webserver ciphers show" on page 559	✓				
"webserver disable" on page 560	✓				
"webserver enable" on page 561	✓				
"webserver show" on page 562	✓				

audit

Access commands that allow the **audit** user to perform HSM auditing tasks.

NOTE Audit commands control HSM audit logging. They are visible only to the audit user, and are hidden from the appliance admin, operator, monitor, or any other non-auditor user.

The audit user also has access to a limited set of commands grouped under the following command menus:

hsm	Provides access to the following: <ul style="list-style-type: none"> > The hsm show command. See "hsm show" on page 140 > All hsm ped commands, except for the hsm ped vector commands. The audit appliance user is allowed to connect and disconnect remote PED connections, adjust timeout, and view connection information, but is not allowed to create (init) or erase a remote PED vector. See "hsm ped" on page 109.
my	Provides a set of commands equivalent to those provided to other non-admin users. See "my" on page 192
network	Provides only the show and ping commands. See "network" on page 205 .

Syntax

audit

changepwd
config
init
log
login
logout
remotehost
secret
show
sync

Argument(s)	Shortcut	Description
changepwd	-ch	Changes the audit user password or PED key. See "audit changepwd" on page 38 .
config	-co	Set the audit parameters. See "audit config" on page 39 .
init	-i	Initialize the audit role. See "audit init" on page 42 .

Argument(s)	Shortcut	Description
log	-log	Access commands that allow you to manage audit log files. See "audit log" on page 44 .
login	-logi	Login as the audit user. See "audit login" on page 54
logout	-logo	Logout the audit user. See "audit logout" on page 56
remotehost	-r	Configure audit logging remote hosts. See "audit remotehost" on page 57 .
secret	-se	Export or import the audit logging secret. See "audit secret" on page 62 .
show	-sh	Display the current audit logging configuration. See "audit show" on page 65
sync	-sy	Synchronizes the HSM time to the host time. See "audit sync" on page 66

audit changepwd

Change the password or PED key contents for the HSM Audit role. Both the old and the new PED key are required for SafeNet Luna Network HSM with PED authentication.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit changepwd [-serial <serialnum>] [-oldpw <password>] [-newpw <password>]

Argument(s)	Shortcut	Description
-newpw <password>	-n	Specifies the new password for the Audit role. If you do not use this parameter, you are prompted to enter and confirm the password. A valid password should be a mix of upper and lower-case letters, digits, and other characters, and must be a minimum of 8 characters long.
-oldpw <password>	-o	Specifies the current password for the HSM Audit role. If you do not use this parameter, you are prompted for the password. This parameter applies to password-authenticated HSMs only.
-serial <serialnum>	-s	Specifies the serial number of the HSM. This option allows the system to distinguish between two connected HSMs, as might occur with a PKI bundle configuration (secondary USB-attached SafeNet Luna USB HSM).

Example

```
lunash:>audit changepwd
```

```
Please enter the old password:
> *****
```

```
Please enter the new password:
> *****
```

```
Please re-enter the new password:
> *****
```

```
Command Result : 0 (Success)lunash:>
```

audit config

Set the configuration parameters for audit logging.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit config -parameter <parameter> **-value** <value> [**-serial** <serialnum>]

Argument(s)	Shortcut	Description
-parameter <parameter>	-p	Specifies the type of parameter to set. Valid values The value enclosed in parentheses [n] indicates a shortcut: <ul style="list-style-type: none"> > [e]vent - Include the list of events specified using the -value parameter in the log. > [r]otation - Rotate the logs as specified by the -value parameter.
-serial <serialnum>	-s	Reserved for future use. Specifies the serial number of the HSM. This option allows the system to distinguish between two connected HSMs.

Argument(s)	Shortcut	Description
-value <value>	-v	<p>Event Values</p> <p>If -parameter is set to event, this specifies a comma-separated list of events to include in the log.</p> <p>Note: In addition to specifying an event category, you must also specify the conditions under which those events are to be logged - either f for failures, or s for successes, or both. See the examples.</p> <p>Valid values</p> <p>The value enclosed in parentheses [n] indicates a shortcut:</p> <ul style="list-style-type: none"> > [f]ailure: log command failures > [s]uccess: log command successes > [a]ccess: log access attempts (logins) > [m]anage: log HSM management (init/reset/etc) > [k]eymanage: key management events (key create/delete) > asymmetri[c]: asymmetric key usage (sig/ver) > fi[r]st: first asymmetric key usage only (sig/ver) > s[y]mmetric: symmetric key usage (enc/dec) > symf[i]rst: first symmetric key usage only (enc/dec) > e[x]ternal: log messages from CA_LogExternal > lo[g]manage: log events relating to log configuration > a[!]: log everything (user will be warned) > [n]one: turn logging off <p>Rotation Values</p> <p>If -parameter is set to rotation, this specifies the log rotation interval.</p> <p>Valid values</p> <p>The value enclosed in parentheses [] indicates a shortcut:</p> <ul style="list-style-type: none"> > [h]ourly > [d]aily > [w]eekly > [m]onthly > [n]ever

Example

The following table provides some command usage examples:

Argument(s)	Description
lunacm:> audit config -parameter event -value all	Log everything.

Argument(s)	Description
<code>lunacm:> audit config -parameter event -value none</code>	Log nothing.
<code>lunacm:> audit config -parameter event -value failure</code>	Log all command failures.
<code>lunacm:> audit config -parameter event -value failure,success,asymmetric</code>	Log all key usage requests, both success and failure.
<code>lunacm:> audit config -parameter rotation -value daily</code>	Rotate the log daily.

audit init

Initialize the Audit role. The **audit init** command is available only to the **audit** user of the HSM appliance and initializes the Audit role on the HSM. This command attaches an audit domain and a role password for password-authenticated HSMs, and creates a white Audit PED key for PED-authenticated HSMs. For PED-auth HSMs audit init also creates an audit domain, or receives an existing domain, so that selected HSMs are able to validate each others' HSM audit log files.

NOTE Because this command destroys any existing Audit role on the HSM, the user is asked to “proceed” unless the **-force** switch is provided at the command line.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit init [-serial <serialnum>] [-domain <auditdomain>] [-defaultdomain] [-password <password>] [-force]

Argument(s)	Shortcut	Description
-defaultdomain	-de	Specifies that the default domain string is to be used as key cloning domain for the HSM. Using the default domain implies that the HSM can be used in HSM Audit Log file validation operations with any other HSM in the world that retains the default domain - retaining the default domain is not recommended. This option is deprecated and will be discontinued in a future release. -defaultdomain and -domain are mutually exclusive -defaultdomain is ignored for PED-authenticated HSMs
-domain <auditdomain>	-do	Specifies the string to be used as key cloning domain for the HSM. If no value is given for a SafeNet Luna HSM with Password Authentication, you are prompted interactively. -defaultdomain and -domain are mutually exclusive -domain is ignored for PED-authenticated HSMs
-force	-f	Force the action without prompting.
-password <password>	-p	Specifies the current password for the HSM Audit role. If you do not use this parameter, you are prompted for the password. This parameter applies to password-authenticated HSMs only.

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the HSM. This option allows the system to distinguish between two connected HSMs, as might occur with a PKI bundle configuration (secondary USB-attached SafeNet Luna USB HSM).

Example

```
lunash:>audit init
```

```
    The AUDIT role will be initialized.
```

```
    Are you sure you wish to continue?
```

```
    Type proceed to continue, or quit to quit now -> proceed
```

```
    Please enter a domain to use for initializing the Audit role:
```

```
> *****
```

```
    Please re-enter domain to confirm:
```

```
> *****
```

```
    Please enter the password:
```

```
> *****
```

```
    Please re-enter password to confirm:
```

```
> *****
```

```
Command Result : 0 (Success)
```

NOTE For PED-authenticated HSMs, after you type "proceed" you are referred to the PED (which must be connected and 'Awaiting command...') which prompts you for domain (red PED key) and Audit authentication (white PED key).

audit log

Access commands that allow you to manage the audit logs.

Syntax

audit log

clear
list
tail
tarlogs
untarlogs
verify

Argument(s)	Shortcut	Description
clear	c	Clears all of the audit logs from an HSM. See "audit log clear" on the next page .
list	l	Lists all of the audit logs on an HSM. See "audit log list" on page 46 .
tail	tai	Displays the most recent entries in an audit log. See "audit log tail" on page 47 .
tarlogs	tar	Archives an audit log. See "audit log tarlogs" on page 49 .
untarlogs	u	Unarchives a previously archived audit log. See "audit log untarlogs" on page 50 .
verify	v	Verifies a set of records within an audit log. See "audit log verify" on page 51 .

audit log clear

Clear all of the audit log files from an HSM.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit log clear [-serial <serialnum>] [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-serial <serialnum>	-s	Specifies the serial number of the HSM from which you want to clear the logs. This option is required only when there are multiple attached HSMs.

Example

```
lunash:>audit log clear
```

```
*** WARNING ***
```

```
All audit logs for this HSM will be destroyed!!!
```

```
Are you sure you wish to continue?
```

```
Type proceed to continue, or quit to quit now -> proceed
```

```
Command Result : 0 (Success)
```

audit log list

Display a list of the audit log files.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit log list [-serial <serialnum>]

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the HSM from which you want to list the logs. This option is required only when there are multiple attached HSMs. Default is the embedded HSM.

Example

```
lunash:>audit log list
```

Logs that are in progress

```
116280 Feb 27 17:03 hsm_66331_0000000a.log
```

Logs that are ready for archive:

```
1624728 Feb 27 17:00 hsm_66331_00000009.log
2224824 Feb 27 16:00 hsm_66331_00000008.log
1902432 Feb 27 15:00 hsm_66331_00000007.log
1923864 Feb 27 14:00 hsm_66331_00000006.log
1910184 Feb 27 13:00 hsm_66331_00000005.log
1925232 Feb 27 12:00 hsm_66331_00000004.log
1937088 Feb 27 11:00 hsm_66331_00000003.log
 445968 Feb 27 10:00 hsm_66331_00000002.log
```

```
Command Result : 0 (Success)
```


Command Result : 0 (Success)

Entries within the last 10 containing "OPEN_SESSION"

```
lunash:>audit log tail -file hsm_66331_00000009.log -entries 10 -search OPEN_SESSION
```

```
301177,17/02/28 02:59:56,S/N 154438865286 session 2 Access 2147483651:3 operation LUNA_OPEN_
SESSION returned RC_OK(0x00000000) session handle 2
301179,17/02/28 02:59:56,S/N 154438865286 session 2 Access 2147483651:3 operation LUNA_OPEN_
SESSION returned RC_OK(0x00000000) session handle 2
301181,17/02/28 02:59:56,S/N 154438865286 session 2 Access 2147483651:3 operation LUNA_OPEN_
SESSION returned RC_OK(0x00000000) session handle 2
301183,17/02/28 02:59:56,S/N 154438865286 session 2 Access 2147483651:3 operation LUNA_OPEN_
SESSION returned RC_OK(0x00000000) session handle 2
```

Command Result : 0 (Success)

audit log tarlogs

Archives log files to audit.tgz file in the user local directory.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit log tarlogs [-serial <serialnum>]

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the HSM from which you want to tar the logs. This option is required only when there are multiple attached HSMs. The default is to use the embedded HSM.

Example

```
lunash:>audit log tarlogs
```

```
WARNING: You will need to export the encrypted log secret 66331.lws
         by running the 'audit secret export' command in order to
         verify these logs on another HSM!
```

Compressing log files:

```
66331/
66331/ready_for_archive/
66331/ready_for_archive/hsm_66331_00000004.log
66331/ready_for_archive/hsm_66331_00000006.log
66331/ready_for_archive/hsm_66331_00000002.log
66331/ready_for_archive/hsm_66331_00000007.log
66331/ready_for_archive/hsm_66331_00000009.log
66331/ready_for_archive/hsm_66331_00000008.log
66331/ready_for_archive/hsm_66331_00000005.log
66331/ready_for_archive/hsm_66331_00000003.log
66331/hsm_66331_0000000a.log
```

The tar file containing logs is now available as file 'audit-66331.tgz'.
If you wish to verify your logs on another SA, scp them to another SA's audit directory then use the 'audit log untar' command.

```
Command Result : 0 (Success)
```

audit log untarlogs

Un-archives a previously archived log file to the local directory. The log file is restored to a subdirectory named with the HSM's serial number.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit log untarlogs [-file <logfilename>]

Argument(s)	Shortcut	Description
-file <logfilename>	-f	Specifies the name of the archived log file to restore.

Example

```
lunash:>audit log untarlogs -file x.tgz
```

```
Cannot find the file in /home/audit/lush_files/
Found files:
66331  audit-66331.tgz
```

```
Command Result : 65535 (Luna Shell execution)
```

```
lunash:>audit log untarlogs -file audit-66331.tgz
```

```
Extracting logs to audit home:
```

```
66331/
66331/ready_for_archive/
66331/ready_for_archive/hsm_66331_00000004.log
66331/ready_for_archive/hsm_66331_00000006.log
66331/ready_for_archive/hsm_66331_00000002.log
66331/ready_for_archive/hsm_66331_00000007.log
66331/ready_for_archive/hsm_66331_00000009.log
66331/ready_for_archive/hsm_66331_00000008.log
66331/ready_for_archive/hsm_66331_00000005.log
66331/ready_for_archive/hsm_66331_00000003.log
66331/hsm_66331_0000000a.log
```

To verify these logs see the 'audit secret import' command to import the HSM's log secret.

```
Command Result : 0 (Success)
```

audit log verify

Verify the audit log records.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit log verify -file <filename> [**-serialtarget** <serialnum>] [**-serialsource** <serialnum>] [**-start** <number>] [**-end** <number>] [**-external**]

Argument(s)	Shortcut	Description
-end <number>	-en	Specifies the final record of the subset of records to be verified from the file.
-external	-ex	Specifies that the file from which log entries are to be verified is from an external HSM. In this case, the audit secret for that HSM must either be the same secret (white PED Key) as is used on the current HSM, or must have been imported to the current HSM. The current HSM's own audit secret cannot verify log files from other HSMs if those were created using independent secrets. The HSM holds only one audit secret at a time, so the secret for the relevant HSM's logs must be brought into the HSM when needed for log verification, if it is not already present.
-file <filename>	-f	Specifies the name of the log file to verify.
-serialsource <serialnum>	-serials	Specifies the serial number of the HSM that generated the log file that is being verified.
-serialtarget <serialnum>	-serialt	Specifies the serial number of the HSM that is performing the verification.
-start <number>	-st	Specifies the starting record of the subset of records to be verified from the file.

Example

Verification of local log file, with local secret

```
lunash:>audit log verify -file hsm_66331_00000002.log
```

```
Log file being verified ready_for_archive/hsm_66331_00000002.log.
```

```
Verifying log on HSM with serial 66331
```

```
Verified messages 270723 to 271699
```

Command Result : 0 (Success)

Verification of external log with external secret:

In this example, we show the process from both HSMs.

```
[myluna72] lunash:> audit secret export
```

The encrypted log secret file 153593.lws now available for scp.

Now that you have exported your log secret, if you wish to verify your logs on another HSM see the 'audit secret import' command. If you wish to verify your logs on another SafeNet Luna Network HSM see the 'audit log tar' command.

Command Result : 0 (Success)

```
[myluna72] lunash:>audit log tar
```

Compressing log files:

```
153593/  
153593/hsm_153593_00000019.log  
153593/153593.lws  
153593/ready_for_archive/  
153593/ready_for_archive/hsm_153593_0000000b.log  
153593/ready_for_archive/hsm_153593_00000003.log  
153593/ready_for_archive/hsm_153593_00000002.log  
153593/ready_for_archive/hsm_153593_00000006.log  
153593/ready_for_archive/hsm_153593_00000001.log
```

The tar file containing logs is now available as file 'audit-153593.tgz'.
If you wish to verify your logs on another SA, scp them to another SA's audit directory then use the 'audit log untar' command.

Command Result : 0 (Success)

Here is where we scp the secret file and the .tgz file to a different SafeNet Luna Network HSM

```
lunash:> audit secret import -serialtarget 150825 -file 153593.lws -serialsource 153593
```

Successfully imported the encrypted log secret 153593.lws

Now that you have imported a log secret if you wish to verify your logs please see the 'audit log verify' command.

Command Result : 0 (Success)

```
[myluna73] lunash:> audit log untarlogs -file audit-153593.tgz
```

Extracting logs to audit home:

```
153593/  
153593/hsm_153593_00000019.log  
153593/153593.lws
```

```
153593/ready_for_archive/  
153593/ready_for_archive/hsm_153593_0000000b.log  
153593/ready_for_archive/hsm_153593_00000003.log  
153593/ready_for_archive/hsm_153593_00000002.log  
153593/ready_for_archive/hsm_153593_00000006.log  
153593/ready_for_archive/hsm_153593_00000001.log
```

To verify these logs see the 'audit secret import' command to import the HSM's log secret.

```
Command Result : 0 (Success)
```

```
[myluna73] lunash:> audit log verify -serialtarget 150825 -file hsm_153593_00000001.log -  
serialsource 153593
```

```
Log file being verified /home/audit/lush_files/153593/ready_for_archive/hsm_153593_00000001.log.
```

```
Verifying log from HSM with serial 153593 on HSM with serial 150825  
Make sure that you have already imported the audit log secret.
```

```
Verified messages 39638 to 39641
```

```
Command Result : 0 (Success)
```

On the verifying HSM ([myluna73] in the example), you just imported a secret (displacing the native secret of the local HSM) and used it to verify logs that were transported from a different HSM ([myluna72] in the example).

If you now wished to verify the second HSM's ([myluna73]) own log files, you would need to re-import that HSM's secret, having replaced it with the other HSM's ([myluna72]'s0 secret for the example operation.

That is, [myluna72]'s log secret that was imported into [myluna73] to allow [myluna73] to verify logs received from [myluna72], is not useful to verify [myluna73]'s own logs. An HSM can have only one log secret at a time, so [myluna73] needs its own secret back if it is to verify its own logs, rather than the logs it received from [myluna72].

audit login

Log in the HSM Audit user.

For SafeNet Luna Network HSM with PED (Trusted Path) Authentication, a new Audit secret is created on the HSM and imprinted on a white PED key, or an existing Audit secret is retrieved from a presented white PED key and imprinted onto the HSM. After initialization, the appropriate white PED key is needed for HSM Audit role login.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit login [-serial <serialNum>] [-password <password>]

Argument(s)	Shortcut	Description
-serial <serialNum>	-s	HSM Serial Number - identifies which HSM is to accept the login if you have multiple HSMs (for example a Backup HSM or a SafeNet Luna USB HSM locally connected to your host).
-password <password>	-p	The password of the HSM you are logging into. Used for Password-authenticated HSMs. If you prefer not to write the password, in the clear, on the command line, leave it out and you will be prompted for it. Ignored for PED-authenticated HSMs. If the audit log area in the HSM becomes full, the HSM stops accepting most commands, and does not prompt for password when login is requested. In that case, provide the password with the command, and the login is accepted. Audit log full does not affect login for PED-authenticated HSMs.

Example

PED-Authenticated HSM

```
lunash:>audit login
```

Luna PED operation required to login as HSM Auditor - use Audit user (white) PED key.

```
'audit
```

```
lunash:>
```

Password authenticated HSM

```
lunash:>audit login
```

```
  Please enter the password:
```

```
> *****
```

```
Command Result : 0 (Success)
```

audit logout

Log out the HSM Audit user.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit logout

Example

```
lunash:>audit logout
```

```
'audit logout' successful.  
Command Result : 0 (Success)
```


audit remotehost

Access commands that allow you to add, delete, or view the remote logging servers.

Syntax

audit remotehost

add
clear
delete
list

Argument(s)	Shortcut	Description
add	a	Adds a Remote Logging Server. See "audit remotehost add" on the next page .
clear	c	Deletes all Remote Logging Servers. See "audit remotehost clear" on page 59 .
delete	d	Delete a Remote Logging Server. See "audit remotehost delete" on page 60 .
list	l	Display a list of all currently configured Remote Logging Servers. See "audit remotehost list" on page 61 .

audit remotehost add

Add an identified Remote Logging Server.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit remotehost add -host <hostnameoripaddress> [**-protocol** <protocol>] [**-port** <port>]

Argument(s)	Shortcut	Description
-host <hostnameoripaddress>	-h	Specifies the Remote Logging Server Host Name or IP address.
-port <port>	-po	Specifies the server port to use for the Remote Logging Server. Range: 0 to 65535 Default: 514
-protocol <protocol>	-pr	Specifies the protocol for remote logging with the specified server. Valid values: tcp,udp Default: udp

Example

```
lunash:>audit remotehost add -host 192.20.11.64
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
```

```
Command Result : 0 (Success)
```

audit remotehost clear

Delete all of the currently configured Remote Logging Servers.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit remotehost clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>audit remotehost clear
```

```

All remote hosts receiving the audit logs will be deleted.
Are you sure you wish to continue?
```

```
Type proceed to continue, or quit to quit now -> proceed
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
```

```
Command Result : 0 (Success)
```

audit remotehost delete

Delete an identified remote logging server.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit remotehost delete -host <hostnameoripaddress>

Argument(s)	Shortcut	Description
-host <hostnameoripaddress>	-h	Specifies the host name or IP address of the remote logging server.

Example

```
lunash:>audit remotehost delete -host 192.20.11.64
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
```

```
Command Result : 0 (Success)
```

audit remotehost list

Display a list of the currently configured remote logging servers.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit remotehost list

Example

```
lunash:>audit remotehost list
```

```
Remote logging server(s):
```

```
=====
```

```
192.20.11.64:514, udp
```

```
Command Result : 0 (Success)
```

audit secret

Access commands that allow you to import or export the audit logging secret.

Syntax

audit secret

export

import

Argument(s)	Shortcut	Description
export	e	Export the audit logging secret. See "audit secret export" on the next page
import	i	Import the audit logging secret. See "audit secret import" on page 64 .

audit secret export

Export the audit logging secret to the user's local directory and log archive directory. This is the secret that can later be used to verify log files and log records produced by the HSM identified by the serial number provided with this command.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit secret export [-serial <serialnum>]

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the HSM whose logging secret you want to export. The default is to use the embedded HSM.

Example

```
lunash:>audit secret export
```

The encrypted log secret file 66331.lws now available for scp.

Now that you have exported your log secret, if you wish to verify your logs on another HSM see the 'audit secret import' command. If you wish to verify your logs on another SA see the 'audit log tar' command.

Command Result : 0 (Success)

audit secret import

Imports the audit logging secret from another HSM, in order to verify log records and log files from that other HSM. The logging secret must first have been exported from the originating (source) HSM using the audit secret export command, and the resulting audit-secret file transported to the location/host of the current (target) HSM.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit secret import -serialtarget <serialnum> **-serialsource** <serialnum> **-file** <filename>

Argument(s)	Shortcut	Description
-file <filename>	-f	Specifies the name of the audit secret file to import.
-serialsource <serialnum>	-serials	Specifies the serial number of the source HSM from which the logging secret was exported.
-serialtarget <serialnum>	-serialt	Specifies the serial number of the target HSM to which the logging secret will be imported.

Example

```
lunash:>audit secret import -serialtarget 532018 -serialsource 66331 -file 66331.lws
```

Successfully imported the encrypted log secret 66331.lws

Now that you have imported a log secret if you wish to verify your logs please see the 'audit log verify' command.

Command Result : 0 (Success)

audit show

Display the current audit logging information. The displayed information varies, depending on whether or not the 'audit' role is logged in.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit show [-serial <serialnum>]

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the HSM whose audit logging information you want to display. The default is to use the embedded HSM.

Example

```
lunash:>audit show
```

```
HSM Logging Status:
```

```
HSM found logging daemon
Logging has been configured
HSM is currently storing 0 log records.
```

```
HSM Audit Role: logged in
```

```
HSM Time   : Mon Dec 17 17:50:35 2012
HOST Time  : Mon Dec 17 17:51:07 2012
```

```
Current Logging Configuration
```

```
-----
event mask      : Log everything
rotation interval : daily
```

```
Command Result : 0 (Success)
```

audit sync

Synchronize the HSM time to the host time.

Any computer's onboard time is subject to drift. This command causes the HSM to adjust its time to match that of the host computer (such as the SafeNet Luna Network HSM appliance). This is especially useful when the host computer is synchronized by NTP, or by local drift correction. Among other benefits, this ensures that the log times of HSM events coincide with file creation and update events in the host file system.

User Privileges

Only specialized Audit users can access audit commands.

Syntax

audit sync

Example

```
lunash:>audit sync
```

```
Command Result : 0 (Success)
```

client

Access commands that allow you to manage the SafeNet Luna HSM clients that are able to use partitions on the appliance.

Syntax

client

assignpartition
delete
fingerprint
hostip
list
register
revokepartition
show

Argument(s)	Shortcut	Description
assignpartition	a	Assign partition access rights to a client. See " client assignpartition " on the next page.
delete	d	Delete a client. See " client delete " on page 69.
fingerprint	f	Display the certificate fingerprint for a registered client. See " client fingerprint " on page 70.
hostip	h	Display or configure the client-to-IP mapping. See " client hostip " on page 71.
list	l	Display a list of the registered clients by client name. See " client list " on page 75.
register	reg	Add a client to the list of clients that can access the SafeNet appliance's NTLS. See " client register " on page 76.
revokepartition	rev	Revoke access privileges to the specified partition from the specified client. See " client revokepartition " on page 77.
show	s	Display the hostname or IP address of a client, and any partitions assigned to the client. See " client show " on page 78.

client assignpartition

Assign access privileges for a registered NTLS client to the specified partitions. To assign a partition to a client, the client must be registered using the **client register** command and the partition must first be created using the **partition create** command.

Partitions can be 'unassigned' via revocation (**client revokepartition**), deletion of a Client association (**client delete**), deletion of the partition from the HSM (**partition delete**), or reinitialization of the HSM (**hsm init**).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client assignpartition -client <clientname> -partition <name>

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client to which a partition will be assigned. Use the client list command to display a list of registered clients.
-partition <name>	-p	Specifies the name of the partition to which the client will gain access. Use the partition list command to obtain the partition name.

Example

```
lunash:>client assignpartition -client 192.20.11.91 -partition par001
```

```
'client assignPartition' successful.
```

```
Command Result : 0 (Success)
```

client delete

Remove a client from the list of clients registered to use the SafeNet appliance. The command requires user interaction to verify that deletion should occur. This can be overridden with the **-force** option.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client delete -client <clientname> [-force]

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client to delete. Use the client list command to display a list of registered clients.
-force	-f	Force the action without prompting.

Example

```
lunash:>client delete -client 192.20.11.91
```

```
CAUTION: Are you sure you wish to delete client named:
          192.20.11.91
          Type 'proceed' to delete the client, or 'quit'
          to quit now.
          > proceed
'client delete' successful.
```

```
Command Result : 0 (Success)
```

client fingerprint

Display the certificate fingerprint for a registered client. Compare this with the client's known certificate fingerprint to verify that the correct client was registered before assigning partitions to the client.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client fingerprint -client <clientname>

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client whose certificate you want to display. Use the client list command to display a list of registered clients,

Example

```
lunash:>client fingerprint -client 192.20.11.91
```

```
Certificate fingerprint: 7D:8F:9F:45:11:13:30:AC:10:86:E0:3B:04:B0:89:DB:91:DE:05:D7
```

```
Command Result : 0 (Success)
```

client hostip

Access commands that allow you to display or configure client-to-IP associations.

If you registered your client by host name, the appliance will need to use a DNS server to look up the device IP address. To ensure that the client is reachable in the event of a DNS failure, you can use these commands to map the client host name to its IP address, and save the mapping locally on the appliance.

Syntax

client hostip

map
show
unmap

Argument(s)	Shortcut	Description
map	m	Map a client to an IP address. See " client hostip map " on the next page.
show	s	Shows current client-host-to-IP mapping. See " client hostip show " on page 73.
unmap	u	Remove a client-to-IP mapping. See " client hostip unmap " on page 74.

client hostip map

Map a client's host name to its IP address.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client hostip map -client <clientname> -ipaddress <ipaddress>

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client for which you want to create the association.
-ip <ipaddress>	-i	Specifies the IP address of the client for which you want to create the association.

Example

```
lunash:>client hostip map -client myPC -ipaddress 168.10.10.254
```

Command Result : 0 (Success)

client hostip show

Display the current client-to-IP mapping.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

client hostip show

Example

```
lunash:>client hostip show
```

Client Name	Host Name	Host IP
myPC	myPC	168.10.10.254

```
Command Result : 0 (Success)
```

client hostip unmap

Remove an association between a client name and an IP address.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client hostip unmap -client <clientname>

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client for which you want to remove the association . Use the client list command to display a list of registered clients,

Example

```
lunash:>client hostip unmap -client myPC
```

```
Command Result : 0 (Success)
```

client list

Display a list of the registered clients by client name.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

client list

Example

```
lunash:>client list
```

```
registered client 1: 10.124.0.87  
registered client 2: 192.20.11.91
```

```
Command Result : 0 (Success)
```

client register

Add a client to the list of clients that can access the SafeNet appliance's NTLS. A client must be registered before you can assign partitions to it.

NOTE The client's certificate file is needed to perform the registration.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client register -client <clientname> [-hostname <hostname>] [-ip <ipaddress>] [-force]

Argument(s)	Shortcut	Description
-client <clientname>	-c	The new client's name. The user may choose any name, so long as it is less than 255 characters, and is unique among all clients on the SafeNet Luna HSM appliance. The client name need not be the hostname of the client.
-force	-f	Force the action without prompting.
-hostname <hostname>	-h	The hostname of the new client. Use this parameter if the client certificate (and server certificates) were created with hostnames. If the certificates were created with IP addresses, use the -ip parameter instead.
-ip <ipaddress>	-i	The IP address of the new client. Use this parameter if the client certificate (and server certificates) were created with IP addresses. If the certificates were created with hostnames, use the -hostname parameter instead.

Example

```
lunash:>client register -client 192.20.11.91 -ip 192.20.11.91
```

```
'client register' successful.
```

```
Command Result : 0 (Success)
```

client revokepartition

Revoke access privileges to the specified partition from the specified client. Obtain a list of clients and the partitions they have access to using the **client -list** and **client -show** commands.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

client revokepartition -client <clientname> **-partition** <partitionname>

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client from which the partition will be revoked. Use the client list command to display a list of registered clients,
-partition <partitionname>	-p	Specifies the name of the partition to which the client will lose access. Use the partition list command to display a list of partitions.

Example

```
lunash:>client revokepartition -client 192.20.11.91 -partition par001
```

```
'client revokePartition' successful.
```

```
Command Result : 0 (Success)
```

client show

Display the hostname or IP address of a client, and any partitions assigned to the client.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

client show -client <clientname>

Argument(s)	Shortcut	Description
-client <clientname>	-c	Specifies the name of the client for which you want to see additional information. Use the client list command to display a list of registered clients.

Example

```
lunash:>client show -client 192.20.11.91
```

```
ClientID:    192.20.11.91
IPAddress:   192.20.11.91
Partitions:  "par001"
```

```
Command Result : 0 (Success)
```

hsm

Access commands that allow you to manage the HSM on the appliance.

NOTE HSM commands from LunaSH are queued along with other demands on the HSM (such as cryptographic operations), and can run more slowly than normal if the HSM is very busy, such as when it is performing high-volume ECDSA signing operations.

Syntax

hsm

backup
changepolicy
changepw
checkcertificates
displaylicenses
factoryreset
firmware
generatedak
information
init
loadcustomercert
login
logout
ped
restore
selftest
setlegacydomain
show
showpolicies
stc
stm
supportinfo
tamper
update
zeroize

Argument(s)	Shortcut	Description
backup	b	Backs up data or objects in the HSM's SO (or HSM Admin) space to a backup token. See " hsm backup " on page 82.
changepolicy	changepo	Sets a policy on or off, or to set it to a certain value if it is a numerical policy. See " hsm changepolicy " on page 84.

Argument(s)	Shortcut	Description
changepw	changepw	Changes the password or PED key contents for the HSM Admin. See "hsm changepw" on page 86 .
checkcertificates	che	Checks the HSM for presence of MAC and DAC. See "hsm checkcertificates" on page 87 .
displaylicenses	d	Display a list of all licenses on the HSM. See "hsm displaylicenses" on page 88 .
factoryreset	fa	Set the HSM back to its factory default settings. Zeroize partitions, roles, and objects, delete the RPV (if any), and reset partition policies to original settings. See "hsm factoryreset" on page 89 .
firmware	fi	Update or rollback the HSM firmware. See "hsm firmware" on page 91 .
generatedak	g	Generate a new DAK pair. See "hsm generatedak" on page 96 .
information	inf	Display HSM information, reset the HSM counters, or monitor HSM performance. See "hsm information" on page 97 .
init	ini	Initialize the HSM. See "hsm init" on page 103 .
loadcustomercert	loa	Load the customer-signed MAC and DAC. See "hsm loadcustomercert" on page 106 .
login	logi	Log in as the HSM Admin. See "hsm login" on page 107 .
logout	logo	Log out the HSM Admin account. See "hsm logout" on page 108 .
ped	p	Display or change the configuration of the PED. See "hsm ped" on page 109 .
restore	r	Restore the contents of the HSM from a backup token. See "hsm restore" on page 136 .
selftest	sel	Test the cryptographic capabilities of the HSM. See "hsm selftest" on page 138 .
setlegacydomain	set	Set the legacy cloning domain on an HSM. See "hsm setlegacydomain" on page 139 .
show	sh	Display a list showing the current configuration of the HSM. See "hsm show" on page 140 .

Argument(s)	Shortcut	Description
showpolicies	showp	Display the current settings for all hsm capabilities and policies, or optionally restrict the listing to only the policies that are configurable. See " hsm showpolicies " on page 145.
stc	stc	Configure and manage the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM SO partition. See " hsm stc " on page 147.
stm	stm	Show the current secure transport mode status, place the HSM in secure transport mode, or recover from secure transport mode. See " hsm stm " on page 177.
supportinfo	su	Get HSM support information. See " hsm supportinfo " on page 182.
tamper	t	Show and clear HSM tamper state. See " hsm tamper " on page 183.
update	u	Display or install any available capability or firmware updates. See " hsm update " on page 186.
zeroize	z	Zeroize the HSM. Destroy all partitions, roles and objects, but preserve the RPV (if one exists) and preserve HSM policy settings. See " hsm zeroize " on page 190.

hsm backup

Backup data or objects in the HSM's SO (or HSM Admin) space to a backup token. The **hsm backup** command copies crucial HSM backup information to a special SafeNet backup device. The connected backup HSM, indicated by its serial number, is initialized and used during this process. The user is prompted to confirm that this destructive command should continue ("destructive" to any contents currently on the backup device, not destructive to the source HSM).

The hsm backup command backs up only data or objects in the HSM's SO (or HSM Admin) space. It does not back up the partition data. For that, you must use the **partition backup** commands.

Dual mode backup tokens are initialized to the same level (SafeNet Luna HSM with Password Authentication or SafeNet Luna HSM with PED (Trusted Path) Authentication) as the HSM.

CAUTION! When labeling HSMs or partitions, *never* use a numeral as the first, or only, character in the name/label. Token backup commands allow a slot-number OR a label as identifier, which can lead to confusion if the label is a string version of a slot number. For example, if the token is initialized with the label "1", the user cannot use the label to identify the target for backup purposes, because VTL parses "1" as the numeric ID of the first slot rather than as a text label for the target in the actual occupied slot.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm backup -serial <serialnumber> [-**password** <password>] [-**tokenadminpw** <password>]

Argument(s)	Shortcut	Description
-serial <serialnumber>	-s	Specifies the serial number of the target backup HSM. This indicates which backup device to work with.
-password <password>	-p	Specifies the source HSM Admin's (or SO's) text password. This parameter is required on password-authenticated HSMs. It is ignored on PED-authenticated HSMs.
-tokenadminpw <password>	-t	Specifies the password of the backup target HSM. On PED-authenticated HSMs, the Luna PED is used for the PIN and this value is ignored. The token password need not be the same password or PED key as used for the HSM partition.

Example

```
lunash:>hsm backup -serial 667788
```

CAUTION: Are you sure you wish to initialize the backup
token named:
no label
Type 'proceed' to continue, or 'quit' to quit now.
> proceed

Luna PED operation required to initialize backup token - use Security Officer (blue) PED key.
Luna PED operation required to login to backup token - use Security Officer (blue) PED key.
Luna PED operation required to generate cloning domain on backup token - use Domain (red) PED key.

Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.
Luna PED operation required to login to backup token - use Security Officer (blue) PED key.
'hsm backup' successful.

Command Result : 0 (Success)

hsm changepolicy

Change HSM Admin-modifiable elements from the HSM policy set. Use this command to set a policy on or off, or to set it to a certain value if it is a numerical policy. Only certain portions of the policy set are user-modifiable. These policies and their current values can be determined using the **hsm showpolicies** command. After a successful policy change, with **hsm changepolicy**, then **hsm showpolicies** displays the new policy value.

NOTE This command must be executed by the HSM Admin. If the HSM Admin is not authenticated, a “user not logged in” error message is returned.

If the policy is destructive, the you are given the choice to proceed or quit. This means that you cannot inadvertently destroy the contents of your HSM - you must acknowledge that you know that will happen before you proceed. Once a policy is changed, the program reports back the new value of the policy.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

hsm changepolicy -policy <hsm_policy_number> -value <hsm_policy_value> [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting. If this option is included in the list for a destructive policy change, the policy will be changed without prompting the user for a confirmation of zeroizing the HSM.
-policy <hsm_policy_number>	-p	Specifies the policy code of the policy to alter. Policy descriptions and codes are obtained with the hsm showpolicies command.
-value <hsm_policy_value>	-v	Specifies the value to assign to the specified policy. When specifying values for an on/off type policy, use '1' for on and '0' for off.

Example

```
lunash:>hsm changepolicy -policy 39 -value 1

    Enabling STC will terminate all existing NTLS connections.

    Type 'proceed' to enable STC on HSM, or 'quit'
    to quit now. > proceed

'hsm changePolicy' successful.

Policy Allow Secure Trusted Channel is now set to value: 1
```

Restarting NTLS and STC services... Done

Command Result : 0 (Success)

lunash:>hsm changepolicy -policy 6 -value 0

CAUTION: Are you sure you wish to change the destructive
policy named:

Allow masking

Changing this policy will result in erasing all partitions
on the HSM! (HSM Admin, Domain, and M of N (where applicable)
will not be modified.)

Type 'proceed' to zeroize your HSM and change the policy,
or 'quit' to quit now.

> proceed

'hsm changePolicy' successful.

Policy Allow masking is now set to value: 0

Command Result : 0 (Success)

hsm changepw

Change the password or PED key contents for the HSM SO. Both the old and the new PED key are required for PED-authenticated HSMs.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

hsm changepw [-oldpw <password> -newpw <password>]

Argument(s)	Shortcut	Description
-newpw <password>	-n	Specifies the new password that is used as the HSM SO's login credential to the HSM. If the new password is not provided on the command line, the you are interactively prompted for the new password, and for confirmation of the new password. A valid password should be a mix of upper and lower-case letters, digits, and other characters, and must be a minimum of 8 characters long.
-oldpw <password>	-o	Specifies the current password for the HSM SO. If the current password is not provided on the command line, the user is interactively prompted for the current password.

Example

```
lunash:>hsm changepw
```

```
Please enter the HSM Administrators' current password:
> *****
```

```
Please enter a new password for the HSM Administrator:
> *****
```

```
Please re-enter password to confirm:
> *****
```

```
'hsm changePw' successful.
```

```
Command Result : 0 (Success)
```

hsm checkcertificates

Check the HSM for presence of MAC and DAC.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm checkcertificates

Example

```
lunash:>hsm checkcertificates
```

```
MAC found -- certificatePolicies: evaluated to FIPS 140-2 Level 3
```

```
DAC found -- certificatePolicies: meets requirements of FIPS 140-2 Level 3
```

```
Command Result : 0 (Success)
```

hsm displaylicenses

Display a list of all licenses on the HSM. Licenses are either HSM upgrade licenses (which may be destructive), or HSM partition creation licenses. This command may be used by the HSM Admin to determine if they have available HSM partition licences, before attempting to create a new HSM partition using the **partition create** command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm displaylicenses

Example

```
lunash:>hsm displaylicenses
```

```
HSM CAPABILITY LICENSES
License ID      Description
=====
621000153-000  K7 base configuration
621010185-003  Key backup via cloning protocol
621000046-002  Maximum 100 partitions
621000135-002  Enable allow decommissioning
621000021-002  Performance level 15
```

```
Command Result : 0 (Success)
```


hsm factoryreset

Set the HSM back to its factory default settings, deleting the HSM SO, all users, and all objects. This command can be run only via a local serial connection; it is not accepted via SSH.

CAUTION! This command deletes all objects and users on the HSM, leaving it in a zeroized state.

This command does not require HSM login. The assumption is that your organization's physical security protocols prevent unauthorized physical access to the HSM. If those protocols failed, an unauthorized person would have no access to the HSM contents, and would be limited to temporary denial of service by destruction of HSM contents.

Because this is a destructive command, you are asked whether to “proceed” unless the **-force** switch is provided at the command line. See ["Comparison of Destruction/Denial Actions" on page 1](#) in the *Administration Guide* to view a table that compares and contrasts various "deny access" events or actions that are sometimes confused.

This command:

- > Erases the currently-initialized Auditor role
- > Resets HSM policies
- > Erases the RPV (Remote PED Vector or orange PED key authentication data)

The RPV data is required for Remote PED operations to function, including remote HSM initialization, if needed, so RPV must be reinstated after **hsm factoryreset** if you want to do any remote administration of the HSM.

NOTE If the operation erases the RPV as described above, and you previously established a remote PED connection (using ["hsm ped connect" on page 110](#)), you must tear down the remote PED connection (using ["hsm ped disconnect" on page 114](#)) before you reinitialize the RPV and establish a new remote PED connection. The **hsm factoryReset** command operates on the internal HSM only, and not on software processes responsible for the remote PED connection.

Related commands

This command affects only the HSM, and not the settings for other components of the appliance. The command ["sysconf config factoryreset" on page 365](#) affects appliance settings external to the HSM. To bring your entire SafeNet Luna Network HSM as close as possible to original configuration, as shipped from the factory, run both commands.

If you wish to zeroize (remove all partitions, roles except Auditor, and contents) while preserving HSM policies and the RPV - that is, zeroize before shipping the HSM off to be remotely configured - use the command ["hsm zeroize" on page 190](#) instead.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

hsm factoryreset [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

Non-local (network connection) attempt:

```
lunash:>hsm factoryreset
```

```
Error: 'hsm factoryReset' can only be run from the local
console. Login as 'admin' using the serial port on
the Luna SA before running this command.
```

```
Command Result : 65535 (Luna Shell execution)
```

Local attempt:

```
lunash:>hsm factoryreset
```

```
CAUTION: Are you sure you wish to reset this HSM to factory
default settings? All partitions and data will be erased.
Partition policies will be reverted to factory settings.
HSM level policies will be reverted to factory settings.
If you want to erase partitions and data only, use zeroize.
Remote PED vector will be erased.
Type 'proceed' to return the HSM to factory default, or
'quit' to quit now.
> proceed
```

```
'hsm factoryReset' successful.
```

```
Please wait while the HSM is reset to complete the process.
The remote PED vector (RPV) has been erased on HSM.
```

```
Command Result : 0 (success)
```

hsm firmware

Upgrade to the version of HSM firmware that is currently on standby in the SafeNet Luna Network HSM appliance.

Rollback to the previous version of HSM firmware, retained in the SafeNet Luna Network HSM appliance.

Syntax

hsm firmware

rollback
upgrade
show

Argument(s)	Shortcut	Description
show	s	Show HSM firmware version info. See " hsm firmware show " on page 94 .
upgrade	u	Update HSM firmware. See " hsm firmware upgrade " on page 95 .
rollback	r	Rollback HSM firmware. See " hsm firmware rollback " on the next page .

hsm firmware rollback

Roll back the HSM firmware to the previously installed version. Only the previously installed version is available for rollback. Rollback allows you to try a new firmware version without permanently committing to the new version.

CAUTION! Firmware rollback is a destructive action; earlier firmware versions may have fewer or older mechanisms and might have security vulnerabilities that a newer version does not. Back up any important materials before running this command.

You must be logged in as HSM SO to use this command. The HSM must be re-initialized after a firmware rollback.

After rollback is complete, the command ["hsm show" on page 140](#) indicates that no further firmware rollback is available.

If you wish to reinstall the newer firmware, use command ["hsm firmware upgrade" on page 95](#). The newer version remains on standby in the appliance, so there is no need to re-upload or to re-install appliance software.

CAUTION! *Update any factory-fresh Network HSM to newer firmware before rolling back.* The firmware rollback feature is intended to return the firmware to the previously installed version. Attempting a firmware rollback on a new appliance received directly from Gemalto factory can result in RMA (return of your HSM to Gemalto).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm firmware rollback [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm firmware rollback
```

```
The HSM Administrator is logged in. Proceeding...
```

```
WARNING: This operation will rollback your HSM to the previous firmware version !!!
```

- (1) This is a destructive operation.
- (2) You will lose all your partitions.

- (3) You might lose some capabilities.
- (4) You must re-initialize the HSM.
- (5) If the PED use is remote, you must re-connect it.

Type 'proceed' to continue, or 'quit' to quit now.

```
> proceed
Proceeding...
```

Rolling back firmware. This may take several minutes.

Command Result : 0 (Success)

hsm firmware show

This command displays the current HSM firmware version, the rollback version, and the version (if any) that is on standby for upgrade.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm firmware show

Example

```
lunash:>hsm firmware show
```

```
Current Firmware:           7.2.0
Rollback Firmware:         7.0.3
Upgrade Firmware:          7.3.0
```

```
Command Result : 0 (Success)
```

hsm firmware upgrade

This command updates the HSM firmware by applying the Firmware Update File that was saved in the standby location by the SafeNet factory, or by your most recent SafeNet Luna Network HSM appliance update. The current HSM firmware version (before this command is run), becomes the rollback version after the command is run. See command ["hsm firmware rollback" on page 92](#), to roll back to the previous firmware version.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm firmware upgrade [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm firmware upgrade
```

```
The HSM Administrator is logged in. Proceeding...
```

```
WARNING: This operation will upgrade the firmware and restart NTLs/STC !!!
```

- (1) All current NTLs and/or STC sessions will be reset.
- (2) If the server keys are in hardware, you must re-activate them.
- (3) If the PED use is remote, you must re-connect it.

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
Update Result : 0 (Success)
```

```
resetting HSM ...
```

```
Stopping ntlsl: [ OK ]
```

```
Starting ntlsl: [ OK ]
```

```
Stopping stcd: [ OK ]
```

```
Starting stcd: [ OK ]
```

```
Command Result : 0 (Success)
```

hsm generatedak

Generate a new DAK pair. These can be used to create a new MAC (Manufacturer's Authentication Certificate) & DAC (Device Authentication Certificate). Use this command if you wish to replace the default objects that were shipped from the SafeNet factory. If you are not using MAC and DAC in your operation, then this command and the related commands for the certificates are not of use to you, and running them will not harm anything. If your operation does use DAK and the derived certificates, use this command only in compliance with your operational procedures.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Synopsis

hsm generatedak [-force]

Example

```
lunash:>hsm generatedak
```

```
CAUTION: Are you sure you wish to re-generate the DAK?  
All existing DACs on the HSM will be erased.
```

```
    Type 'proceed' to generate the DAK, or 'quit'  
    to quit now.
```

```
    > proceed
```

```
'hsm generateDAK' successfully completed.
```

```
Use 'scp' from a client machine to get file named:  
DAKCertRequest.bin
```

```
Command Result : 0 (Success)
```


hsm information

Access commands that allow you to display HSM information, reset the HSM counters, or monitor HSM performance.

Syntax

hsm information

monitor
reset
show

Argument(s)	Shortcut	Description
monitor	m	Monitors the HSM performance. See " hsm information monitor " on the next page.
reset	r	Resets the HSM counters. See " hsm information reset " on page 101.
show	s	Display HSM information. See " hsm information show " on page 102.

hsm information monitor

Sample the HSM to get some statistics, such as, HSM up-time, command counts, and utilization counters.

A single run of this command, without arguments, takes approximately five seconds to complete. One measurement is taken at launch, then after five seconds (the default minimum) a second measurement is taken and compared with the first.

The date and time in the output are derived from:

- > The system time
- > The HSM count of seconds since reset

In the examples, note the line "HSM Last Reset (+/- 5 Secs Error Margin)..." That margin is due to possible variability of the default system clock. To improve the accuracy of the input to those calculations, we suggest that you use NTP for system time. If that is inconvenient, or is blocked by your security regime, then we suggest using "[sysconf drift](#)" on [page 374](#) to precisely set the time, and then manage/prevent clock drift.

NOTE For ongoing/continual collection of such HSM information, we recommend using SNMP.

See "[HSM Performance Monitoring](#)" on [page 1](#).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm information monitor [-serial <integer>] [-interval <integer>] [-rounds <integer>] [-noheader] [-save]

Argument(s)	Shortcut	Description
-interval <integer>	-i	Set the interval over which the HSM is polled, in seconds Range: 5 to 999 Default: 5 seconds.
-noheader	-n	Turn off the header and footer that are normally provided with the displayed or saved records. You might choose to omit the header and footer in a saved file, in order to make the file cleaner for concatenation and parsing by your analysis tools.

Argument(s)	Shortcut	Description
-rounds <integer>	-r	Set the number of samples to collect during the HSM polling. The default is a single round, which includes a first sample at the time the command is launched, followed by the interval (either the default 5 seconds, or the interval that you specified), followed by a second sample which is compared with the first, to complete the round. The maximum number of rounds for one operation of hsm information monitor is 65535 . Range: 1 to 65535 Default: 1
-save	-sa	Save the captured-and-calculated records to a file named hsm_stats , while also displaying the output to your terminal. The filename is not modifiable, so contents are overwritten each time the command is run. Use 'scp' to retrieve the file to a workstation for analysis.
-serial <integer>	-se	Specifies the serial number of HSM to monitor. The default is to use the embedded HSM. This parameter is optional if your SafeNet Luna Network HSM does not have additional HSMs attached. If you have a USB-connected HSM, such as SafeNet Luna USB HSM for PKI, then this command defaults to showing utilization data from the embedded HSM, but the serial parameter allows you to select an HSM other than the default. Data is collected for a single HSM when the command is run.

Example

With no arguments (output to terminal):

```
lunash:>hsm information monitor
```

HSM Uptime (Secs)	HSM Command Counts		HSM Utilization (%)	
	Since HSM Reset	Last 5 Secs	Since HSM Reset	Last 5 Secs
1,115,399	57,468,854	30	1.27	0.21

```
Average HSM Utilization In This Period : 0.21%
```

```
HSM Last Reset      : Mon Jul  4 14:43:20 2016
```

```
HSM Has Been Up For : 9 day(s), 22:30:40
```

```
Command Result : 0 (Success)
```

With arguments (output to file):

```
lunash:>hsm information monitor -interval 6 -rounds 6 -save
```

HSM Uptime (Secs)	HSM Command Counts		HSM Utilization (%)	
	Since HSM Reset	Last 6 Secs	Since HSM Reset	Last 6 Secs
859,370	103,545,072	241	1.03	1.46
859,376	103,545,569	497	1.03	0.46
859,382	103,545,570	1	1.03	0.00
859,388	103,545,571	1	1.03	0.01
859,394	103,545,812	241	1.03	1.46
859,400	103,545,813	1	1.03	0.00

Average HSM Utilization In This Period : 0.57%

HSM Last Reset : Mon Jul 4 14:43:21 2016

HSM Has Been Up For : 9 day(s), 22:43:20

The output has been saved to a file named `hsm_monitor_56726.txt`.

Output is appended if the file already exists.

Use `my file delete hsm_monitor_56726.txt` to remove the file.

Use `scp` to retrieve the file to an external workstation for further analysis.

Command Result : 0 (Success)

hsm information reset

Reset the HSM counters.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm information reset

Example

```
lunash:>hsm information reset
```

```
Command Result : 0 (Success)
```

```
lunash:>
```

hsm information show

Display the contents of the HSM counters.

NOTE The "Operation Requests" counter increments rapidly (often by 42 or 47 counts) because even relatively simple LunaSH commands trigger a number of low-level operations, including checking of firmware version, checking of HSM status, and other actions, before the current high-level command is completed.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm information show

Example

```
lunash:>hsm information show
```

HSM Event Counters:

Operation Requests:	103560569
Operation Errors:	199
Crypto Operation Requests:	88292416
Crypto Operation Errors:	60
Critical Events:	0
Non-Critical Events:	0

Command Result : 0 (Success)

hsm init

Initialize the HSM (key card) in the SafeNet Luna HSM Server. Initialization assigns an HSM label, creates or associates Security Officer (SO) or HSM Admin authentication for the HSM, creates or associates a Cloning Domain (with authentication) for the HSM, and applies other settings that make the HSM available for use.

CAUTION! Initializing the HSM erases all existing data on the key card, including all HSM Partitions and their data. HSM Partitions then must be recreated with the **partition create** command. Because this is a destructive command, the user is asked to “proceed” unless the **-force** switch is provided at the command line. If you invoke **hsm init** and then type **quit** at the prompt, initialization does not take place (meaning that you do not lose existing token/HSM contents), but any current login or activation state is closed, whether you abort the command or not.

For more information, see ["HSM Initialization" on page 1](#) in the *Configuration Guide*.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

```
hsm init -label <hsm_label> [-domain <hsm_domain>] [-password <hsm_admin_password>] [-applytemplate <filename>] [-defaultdomain] [-authtimeconfig] [-force]
```

Argument(s)	Shortcut	Description
-applytemplate <filename>	-ap	Apply an HSM policy template.
-authtimeconfig	-a	Specifies that the SO role must be logged in to configure the time.
-defaultdomain	-de	This option is deprecated. The current and future HSM versions do not allow you to omit providing a domain, unless you include this "-defaultdomain" option, which is an insecure choice and generally not recommended. It is retained for benefit of existing customers who have previously set the default domain, and are constrained to continue with it until they create new objects on an HSM with a properly-named domain. The " -defaultdomain " option applies to Password-authenticated HSMs only. For PED-authenticated HSMs the PED always prompts for a physical PED Key and either reuses the value on the key that you insert, or generates a new value and imprints it on the PED Key.

Argument(s)	Shortcut	Description
-domain <hsm_domain>	-do	Specifies the string to be used as key cloning domain for the HSM. If no value is given for a SafeNet Luna HSM with Password Authentication, you are prompted interactively. The HSM must support cloning, or this value is ignored. This parameter is considered mandatory in password-authenticated HSMs (except if the discouraged and deprecated -defaultdomain is specified). The -domain parameter is ignored in PED-authenticated HSMs.
-force	-f	Force the action without prompting.
-label <hsm_label>	-l	Specifies the label to assign to the HSM. The label has a maximum length of 32 characters. Any data input over 32 characters is truncated.
-password <hsm_admin_password>	-p	Specifies the password to be used as login credential by the HSM Admin. For PED-authenticated HSMs, the Luna PED is used for the HSM Admin PIN/password, and data input for this value is ignored. This parameter is required in password-authenticated HSMs. It is ignored in PED-authenticated HSMs.

Example

PED-authenticated HSMs

If the HSM has been factory reset, then a complete "hard" initialization is performed when you invoke the **hsm init** command.

```
lunash:> hsm init -label myluna
```

```
CAUTION: Are you sure you wish to re-initialize this HSM?
          All partitions and data will be erased.
          Type 'proceed' to initialize the HSM, or 'quit'
          to quit now.
          > proceed
```

```
Luna PED operation required to initialize HSM - use Security Officer (blue) PED Key
Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED Key
Luna PED operation required to generate cloning domain - use Domain (red) PED Key
```

```
'hsm init successful'
```

```
Command result : 0 (Success)
```

```
lunash:>
```

If the HSM is NOT in factory reset condition when you invoke the **hsm init** command, then a "soft" initialization is performed - while the partitions and contents are destroyed, the Security officer/HSM Administrator identity and the Domain are preserved. The SO must be logged into the HSM to run HSM init when the HSM is not in factory reset condition.

```
lunash:> hsm init -label myluna
```

```
Warning: This HSM is not in the factory reset (zeroized) state.
```


You must present the current HSM Admin login credentials to clear the HSM contents.

CAUTION: Are you sure you wish to re-initialize this HSM?
All partitions and data will be erased.
Type 'proceed' to initialize the HSM, or 'quit' to quit now.
> proceed

Luna PED operation required to initialize HSM - use Security Officer (blue) PED Key

'hsm -init successful'

Command result : 0 (Success)

hsm loadcustomercert

Load the customer-signed MAC (Manufacturer's Authentication Certificate) & DAC (Device Authentication Certificate) certificates in the specified file onto the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm loadcustomercert -certfilename <filename>

Argument(s)	Shortcut	Description
-certfilename <filename>	-c	The customer-signed certificate's filename.

hsm login

Log in as the HSM Security Officer (SO).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

```
lunash:> hsm login [-password <password>]
```

Argument(s)	Shortcut	Description
-password <password>	-p	Specify HSM SO password (for password-authenticated HSM only; ignored for PED-authenticated HSM)

Example

```
lunash:>hsm login
```

Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.
'hsm login' successful.

```
Command Result : 0 (Success)
```

hsm logout

Log out the HSM Admin account.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm logout

Example

```
lunash:>hsm logout
```

```
'hsm logout' successful.
```

```
Command Result : 0 (Success)
```

hsm ped

Access commands that allow you to display or change the configuration of the PED.

Syntax

hsm ped

connect
deselect
disconnect
select
server
set
show
timeout
vector

Argument(s)	Shortcut	Description
connect	c	Connect to a Remote PED. See "hsm ped connect" on the next page .
deselect	de	Deselect the currently selected PedServer. See "hsm ped deselect" on page 113
disconnect	di	Disconnect a connected Remote PED. See "hsm ped disconnect" on page 114 .
select	sel	Select a connected PedServer from the list to provide PED operations to the HSM. See "hsm ped select" on page 117 .
server	ser	Display or configure PedServer. See "hsm ped server" on page 118 .
set	se	Configure a default IP address and/or port that are used by the hsm ped connect command when establishing a connection to a Remote PED Server. See "hsm ped set" on page 122 .
show	sh	Display information for the current HSM PED connection. See "hsm ped show" on page 115 .
timeout	t	Set or display the remote PED connection timeout. See "hsm ped timeout" on page 123 .
vector	v	Initialize or erase a remote PED vector. See "hsm ped vector" on page 126 .

hsm ped connect

Connect to a remote PED. This command instructs PedClient to attempt to connect to the Remote PED Server at the IP address and port specified on the command line, or configured using the **hsm ped set** command. See "[hsm ped set](#)" on page 122 for more information.

Behavior when defaults are configured using hsm ped set

The **hsm ped set** command allows you to configure a default IP address and/or port for the Remote PED Server. These values are used if they are not specified when you issue the **hsm ped connect** command. The behavior of the **hsm ped connect** command when defaults are configured using **hsm ped set** is as follows:

Values set with hsm ped set	Parameters specified by hsm ped connect	IP address used	Port used
IP address and port	None	IP address configured with hsm ped set .	Port configured with hsm ped set .
	IP address	IP address specified by hsm ped connect	Port configured with hsm ped set .
	Port	IP address configured with hsm ped set .	Port specified by hsm ped connect
	IP address and port	IP address specified by hsm ped connect	Port specified by hsm ped connect
IP address only	None	IP address configured with hsm ped set .	Port 1503 (default).
	IP address	IP address specified by hsm ped connect	Port 1503 (default).
	Port	IP address configured with hsm ped set .	Port specified by hsm ped connect .
	IP address and port	IP address specified by hsm ped connect	Port specified by hsm ped connect .

Values set with hsm ped set	Parameters specified by hsm ped connect	IP address used	Port used
Port only	None	Error. You must use the -ip parameter to specify an IP address.	Port configured with hsm ped set .
	IP address	IP address specified by hsm ped connect	Port configured with hsm ped set .
	Port	Error. You must use the -ip parameter to specify an IP address..	Port specified by hsm ped connect
	IP address and port	IP address specified by hsm ped connect	Port specified by hsm ped connect

Behavior when no defaults are configured using **hsm ped set**

If no defaults are configured using **hsm ped set**, you must specify at least an IP address. If no port is specified, the default port (1503) is used.

NOTE To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Luna Network HSM, use the "**-serial**" option to specify the target HSM. If "**-serial**" is not specified, then the command acts on the SafeNet Luna Network HSM's internal HSM card.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped connect [-ip <ip_address>] [-port <port>] [-serial <serial_num>] [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-ip <ip_address>	-i	Specifies the IP Address of the PED
-port <port>	-p	Network Port (0-65535). Default: 1503
-serial <serial_num>	-s	Token Serial Number

Example

```
lunash:>hsm ped connect
```

```
Luna PED operation required to connect to Remote PED - use orange PED key(s).
```

```
Command Result : 0 (Success)
```


hsm ped deselect

When a PedServer is connected and selected to provide PED operations to the HSM, use this command to deselect the currently selected PedServer. The PedServer remains connected and remains in the list of available PedServers, but is no longer selected and can no longer provide PED operations for the HSM until it is selected again.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped deselect [-host <hostname>]

Argument(s)	Shortcut	Description
-host <hostname>	-h	The hostname of the PedServer that you are deselecting, as shown in the output of the hsm ped show command. Required if multiple PedServers have established connections; optional if only one PedServer is available.

Example

```
lunash:>lunash:>hsm ped deselect -host WIN-1TFMAA8U4V7
```

```
Host WIN-1TFMAA8U4V7 deselected.
```

```
Command Result : 0 (Success)
```

hsm ped disconnect

For legacy connections only. Disconnect the current/active remote PED. No address information is required since only one remote PED connection can exist at one time.

To disconnect the PED when using a peer-to-peer connection, you must first disconnect from peer mode and return to legacy mode.

NOTE To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Luna Network HSM, use the "**-serial**" option to specify the target HSM. If "**-serial**" is not specified, then the command acts on the SafeNet Luna Network HSM's internal HSM card.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped disconnect [**-serial** <serialnum>] [**-force**]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-serial <serialnum>	-s	Token Serial Number

Example

```
lunash:>hsm ped disconnect
```

If you are sure that you wish to disconnect, then enter 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

hsm ped show

Display information for the current HSM PED connection.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm ped show

Example

```
lunash:>hsm ped show
```

```
Configured Remote PED Server IP address: 192.20.11.64
Configured Remote PED Server Port: 1503
```

```
Ped Client Version 2.0.1 (20001)
Ped Client launched in status mode.
Callback Server is running..
```

```
Callback Server Information:
```

```
  Hostname:          sa7ped
  IP:                192.20.11.40
  Software Version:  2.0.1 (20001)
```

```
Operating Information:
```

```
  Admin Port:        1501
  External Admin Interface: No
```

```
  Callback Server Up Time:          494832 (secs)
  Callback Server Current Idle Time: 3774 (secs)
  Callback Server Total Idle Time:  494098 (secs) (99%)
  Idle Timeout Value:               1800 (secs)
```

```
Number of PED ID Mappings:          1
```

```
PED ID Mapping Table:
```

```
  PED ID:              4
  Server Hostname:     192.20.11.64
  Server Port:         1503
  Status: Not Assigned
```

```
Number of HSMs:                    1
```

```
HSM List:
```

```
  Device Type:         K7 HSM
  HSM Serial Number:   532018
  HSM Firmware Version: 7.0.1
  HSM Cmd Protocol Version: 21
  HSM Callback IO Version: 1
```

```
HSM Callback Protocol Version:    1
HSM Up Time:                      423248 (secs)
HSM Total Idle Time:              422514 (secs) (99%)
HSM Current Idle Time:            3774 (secs)
```

```
Number of Connected PED Server :  0
```

Show command passed.

Command Result : 0 (Success)

hsm ped select

When a PedServer has established a connection to this SafeNet Luna Network HSM appliance in peer-to-peer mode, it could be one of many. Use this command to select one connected PedServer from the list to provide PED operations to the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped select [-host<hostname>] [-serial <serialnum>]

Argument(s)	Shortcut	Description
-host <hostname>	-h	The hostname of the PedServer that you are selecting, as shown in the output of the hsm ped show command. Required if multiple PedServers have established connections; optional if only one PedServer is available.
-serial <serialnum>	-s	Specifies the serial number of the HSM that is to be served by PED operations. Optional unless more than one HSM is present.

Example

```
lunash:>lunash:>hsm ped select -host WIN-1TFMAA8U4V7
```

Luna PED operation required to connect to Remote PED - use orange PED key(s).

Command Result : 0 (Success)

hsm ped server

Access commands that allow you to display or change the configuration of the PED Server.

Syntax

hsm ped server

delete
list
register

Argument(s)	Description
delete	Deregister a PED Server. See "hsm ped server delete" on the next page.
list	List all remote PED Server configurations. See "hsm ped server list" on page 120.
register	Register a PED Server certificate with the appliance. See "hsm ped server register" on page 121.

hsm ped server delete

Delete a previously registered PED Server. This command will prompt the user to continue the removal of the certificate before executing.

If the certificate common name input into the command does not exist, an error is returned.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped server revoke -commonname <certificate common name> [**-force**]

Argument(s)	Shortcut	Description
-commonname <certificate common name>	-c	The common name of the certificate. The name can be retrieved by running the hsm ped server list command.
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm ped server revoke -commonname 192.20.11.64
```

```
CAUTION: Are you sure you wish to delete PED server named:
          192.20.11.64
          Type 'proceed' to delete the PED server, or 'quit'
          to quit now. > proceed
```

```
'hsm ped server delete' successful.
```

```
Command Result : 0 (Success)
```

hsm ped server list

List all remote PED Server configurations.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm ped server list

Example

```
lunash:>hsm ped server list
```

```
    Number of Registered PED Server : 1
```

```
    PED Server 1 : CN = 192.20.11.64
```

```
Command Result : 0 (Success)
```


hsm ped server register

Register a PED Server certificate with the appliance. Once the certificate has been registered, the certificate file is removed from the user's LunaSH home directory.

This command will fail if the same certificate is being registered again.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped server register -certificate <filename> [-force]

Argument(s)	Description
-certificate <filename>	The name of the certificate file stored in the user's LunaSH home directory. The filename can be found by executing the my file list command.
-force	Force the action without prompting.

Example

```
lunash:>hsm ped server register -certificate 192.20.11.64.pem
```

```
'hsm ped server register' successful.
```

```
Command Result : 0 (Success)
```

hsm ped set

Configure a default IP address and/or port that are used by the **hsm ped connect** command when establishing a connection to a Remote PED Server. See "[hsm ped connect](#)" on page 110 for more information.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

hsm ped set [-ip <ip_address>] [-port <port>]

Argument(s)	Shortcut	Description
-ip <ip_address>	-i	Specifies the default IP Address used by the hsm ped connect command.
-port <port>	-p	Specifies the default port used by the hsm ped connect command. Range: 0-65535 Default: 1503

Example

```
lunash:>hsm ped set -ip 192.20.11.64 -port 1503
```

```
Command Result : 0 (Success)
```

hsm ped timeout

Access commands that allow you to set or display the remote PED connection timeout.

Syntax

hsm ped timeout

set
show

Argument(s)	Shortcut	Description
set	se	Set the remote PED connection timeouts. See "hsm ped timeout set" on the next page .
show	sh	Display the currently configured remote PED connection timeout values. See "hsm ped timeout show" on page 125 .

hsm ped timeout set

Set the remote PED connection (**rped**) or PED key interaction (**pedk**) timeout values:

- > **rped** - is the connection inactivity timeout. The default is 1800 seconds (30 minutes). While we do not anticipate any great security risk from having a Remote PED connection left open and unused for long periods, we do suggest that having sessions open indefinitely might be an invitation, so set the **rped** value as long as you realistically need, but not more.
- > **pedk** - is for PED key activities in particular. The default is 200 seconds. It might be useful to increase that timeout if you are initializing your HSM with large values for MofN on some-or-all PED keys. We have tested initializations with all secrets set to the maximum MofN, equal to 16 of 16, and a pedk value of 900 seconds (15 minutes) was adequate to complete the necessary interactions. If you are not using MofN, then leave 'pedk' at its default value.

After **rped** expires, you must re-establish the Remote PED link with **hsm ped disconnect** and **hsm ped connect** before issuing any HSM or application partition commands that require PED interaction. We recommend running disconnect before reconnecting because, although the link normally disconnects cleanly upon timeout, it can happen that the link is left in an indeterminate state, and a disconnect before a connect corrects that.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm ped timeout set -type <type> -seconds <seconds>

Argument(s)	Shortcut	Description
-seconds <seconds>	-s	Specifies the timeout value, in seconds, for the specified type. Range: 1 to 99999 Defaults: 1800 (rped), 200 (pedk)
-type <type>	-t	Specifies the timeout type. Valid values: > rped - set the remote PED connection inactivity timeout. > pedk - set the PED key timeout.

Example

```
lunash:>hsm ped timeout set -type pedk -seconds 30
```

Set the timeout value to 30 seconds.

Command Result : 0 (Success)

hsm ped timeout show

Display the currently configured remote PED connection timeout values.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm ped timeout show

Example

```
lunash:>hsm ped timeout show
```

```
The remote PED connection timeout value (seconds) = 1800  
The PED key interaction timeout value (seconds)    = 200  
The entire PED operation timeout value (seconds)  = 830
```

```
Command Result : 0 (Success)
```

hsm ped vector

Access commands that allow you to initialize or erase a remote PED vector (RPV) on the HSM.

NOTE To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Luna Network HSM, use the **"-serial"** option to specify the target HSM. If **"-serial"** is not specified, then the command acts on the SafeNet Luna Network HSM's internal HSM card.

Syntax

hsm ped vector

erase
init

Argument(s)	Shortcut	Description
erase	e	Erase a remote PED vector. See "hsm ped vector erase" on the next page .
init	i	Initialize a remote PED vector. See "hsm ped vector init" on page 128 .

hsm ped vector erase

Erase a Remote PED vector (RPV) from the current HSM so that it can no longer establish a Remote PED connection with any workstation that has that RPV on an orange PED key.

NOTE To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Luna Network HSM, use the **"-serial"** option to specify the target HSM. If **"-serial"** is not specified, then the command acts on the SafeNet Luna Network HSM's internal HSM card.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

hsm ped vector erase [-serial <serialnum>] [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-serial <serialnum>	-s	Specifies the serial number of the remote PED for which you want to erase the remote PED vector.

Example

```
lunash:>hsm ped vector erase
```

If you are sure that you wish to erase remote PED vector (RPV), then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
```

```
The remote PED vector (RPV) has been erased on HSM.
Ped Client Version 2.0.1 (20001)
Ped Client launched in "Release ID" mode.
Callback Server is running..
ReleaseID command passed.
"Release ID" command passed.
Ped Client Version 2.0.1 (20001)
Ped Client launched in "Delete ID" mode.
Callback Server is running..
DeleteID command passed.
"Delete ID" command passed.
```

```
Command Result : 0 (Success)
```

hsm ped vector init

Initialize a Remote PED vector. This command creates a new Remote PED key by doing the following:

- > Initializing a Remote PED vector (RPV)
- > Imprinting the RPV onto the current HSM as well as onto an orange PED key (RPK).
 - The RPK is kept with the Remote PED, when you set up a Remote PED workstation. The RPK allows a SafeNet Luna Network HSM with that RPV to connect to a Remote PED workstation where the attached PED provides the matching RPV, via the orange RPK.
 - The RPV is a secret that facilitates the secure connection between
 - a particular HSM that has that secret, and
 - a Remote PED Server computer that has the RPK containing the identical secret.

The HSM must be connected to a computer that runs Remote PED client, to manage the HSM's end of the Remote PED connection. More than one HSM can be imprinted with the same RPV, but a single Remote PED Server can connect with only one such remotely located HSM (via its client) at one time.

NOTE If the HSM is initialized, you must be logged in as HSM SO (blue PED key) to initialize the RPV.

If the HSM is uninitialized, you can:

- > initialize the RPV remotely by providing a one-time 8-digit PIN
- > initialize the RPV locally by connecting a Luna PED to the HSM

NOTE To set up or erase a PED vector, or to make or break the Remote PED connection, on an HSM that is externally connected to the SafeNet Luna Network HSM, use the "**-serial**" option to specify the target HSM. If "**-serial**" is not specified, then the command acts on the SafeNet Luna Network HSM's internal HSM card.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

hsm ped vector init [**-serial** <serialnum>] [**-force**]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-serial <serialnum>	-s	Specifies the serial number of the HSM for which you want to erase the remote PED vector.

Example

```
lunash:>hsm ped vector init
```

If you are sure that you wish to initialize remote PED vector (RPV), then enter 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
```

```
Luna PED operation required to initialize remote PED key vector - use orange PED key(s).
```

```
Command Result : 0 (Success)
```

hsm qos metrics

Display Partition Utilization Metrics (counters) to terminal or save to a file, or reset the partition utilization counters.

Syntax

hsm information

```
reset
show
```

Argument(s)	Shortcut	Description
reset	r	Reset the Partition Utilization Metrics. See " hsm qos metrics reset " below.
show	s	Display Partition Utilization Metrics . See " hsm qos metrics show " on page 132.

hsm qos metrics reset

Reset the partition utilization metrics, and optionally display the counts or save to a file.

User Privileges

This command requires that the HSM SO be logged in. Appliance Users with the following privileges can perform this command:

```
> Admin
```

Syntax

```
hsm qos metrics reset [-display] [-export <filename>] [-force]
```

Argument(s)	Shortcut	Description
-display	-d	Display the utilization counts, up to the moment they are reset.
-export <filename>	-e	Export the utilization counts, up to the moment of reset, to the named file.
-force	-f	Force the action without prompting for confirmation.

Example

With no arguments (reset only - no display, no save):

```
lunash:>hsm qos metrics reset
```

CAUTION: Are you sure you wish to reset the utilization counters?
All counters across all partitions will be zeroized.

```
Type 'proceed' to reset the counters, or 'quit'
to quit now.
> proceed
```

Successfully reset all utilization counters and restarted count.

Command Result : 0 (Success)

With arguments (output to terminal):

```
lunash:>hsm qos metrics reset -display
```

CAUTION: Are you sure you wish to reset the utilization counters?
All counters across all partitions will be zeroized.

```
Type 'proceed' to reset the counters, or 'quit'
to quit now.
> proceed
```

Successfully reset all utilization counters and restarted count.

```

Partition
-----
Name          Serial          Operation      Action          Count
-----
test          1230463154880  SIGN          REQUESTS        0
test          1230463154880  VERIFY        REQUESTS        0
test          1230463154880  ENCRYPT        REQUESTS        0
test          1230463154880  DECRYPT        REQUESTS        0
test          1230463154880  KEY_GENERATION REQUESTS        0
test          1230463154880  KEY_DERIVATION REQUESTS        0

par1          1230463154886  SIGN          REQUESTS        4700342794
par1          1230463154886  VERIFY        REQUESTS        4700342747
par1          1230463154886  ENCRYPT        REQUESTS        0
par1          1230463154886  DECRYPT        REQUESTS        0

```

```
par1          1230463154886  KEY_GENERATION  REQUESTS      2
par1          1230463154886  KEY_DERIVATION  REQUESTS      0
```

Summary of metrics across the whole HSM:

```
DECRYPT       :          0
ENCRYPT       :          0
KEY_DERIVATION :          0
KEY_GENERATION :          0
SIGN         :    4700342794
VERIFY       :    4700342747
```

Metrics valid from 26 June 2018 07:18:54 to now.

Command Result : 0 (Success)

With arguments (output to file):

```
lunash:>hsm qos metrics reset -export myparametricsfile
```

CAUTION: Are you sure you wish to reset the utilization counters?
All counters across all partitions will be zeroized.

```
Type 'proceed' to reset the counters, or 'quit'
to quit now.
> proceed
```

Successfully reset all utilization counters and restarted count.

Successfully exported metrics to file.

Command Result : 0 (Success)

With arguments (display and output to file):

```
lunash:>hsm qos metrics reset -export myparametricsfile.csv -display
```

CAUTION: Are you sure you wish to reset the utilization counters?
All counters across all partitions will be zeroized.

```
Type 'proceed' to reset the counters, or 'quit'
to quit now.
> proceed
```

Successfully reset all utilization counters and restarted count.

Partition Name	Serial	Operation	Action	Count
SA_528479	1230460826574	SIGN	REQUESTS	0
SA_528479	1230460826574	VERIFY	REQUESTS	0
SA_528479	1230460826574	ENCRYPT	REQUESTS	0
SA_528479	1230460826574	DECRYPT	REQUESTS	0
SA_528479	1230460826574	KEY_GENERATION	REQUESTS	0
SA_528479	1230460826574	KEY_DERIVATION	REQUESTS	0
metricsPar	1230460826599	SIGN	REQUESTS	4700342794
metricsPar	1230460826599	VERIFY	REQUESTS	4700342747
metricsPar	1230460826599	ENCRYPT	REQUESTS	0

```

metricsPar          1230460826599  DECRYPT          REQUESTS          0
metricsPar          1230460826599  KEY_GENERATION  REQUESTS          2
metricsPar          1230460826599  KEY_DERIVATION  REQUESTS          0

```

Summary of metrics across the whole HSM:

```

DECRYPT      :          0
ENCRYPT      :          0
KEY_DERIVATION :          0
KEY_GENERATION :          0
SIGN        :    4700342794
VERIFY      :    4700342747

```

Metrics valid from 26 June 2018 07:18:54 to now.

Successfully exported metrics to file.

Command Result : 0 (Success)

hsm qos metrics show

Display the partition utilization metrics, or optionally save to file.

User Privileges

This command requires that the HSM SO be logged in. Appliance Users with the following privileges can perform this command:

> Admin

Syntax

hsm qos metrics show [-export <filename>]

Argument(s)	Shortcut	Description
-export <filename>	-e	File to receive the utilization data.
-partition <name_or_number>	-p	A single partition name or serial number, or a comma-delimited list (the list can contain any combination of names and serial numbers). The command output displays utilization information for all valid partition names and numbers from the partition list, and skips any invalid names or numbers, then identifies any incorrect partition names or numbers to assist in correcting the error. If no partitions are identified, the command shows information for all partitions in the HSM.

Example

With no arguments (output to terminal):

```
lunash:>hsm qos metrics show
```

Partition Name	Serial	Operation	Action	Count
test	1230463154880	SIGN	REQUESTS	0
test	1230463154880	VERIFY	REQUESTS	0
test	1230463154880	ENCRYPT	REQUESTS	0
test	1230463154880	DECRYPT	REQUESTS	0
test	1230463154880	KEY_GENERATION	REQUESTS	0
test	1230463154880	KEY_DERIVATION	REQUESTS	0

par2	1230463154886	SIGN	REQUESTS	4700342794
par2	1230463154886	VERIFY	REQUESTS	4700342747
par2	1230463154886	ENCRYPT	REQUESTS	0
par2	1230463154886	DECRYPT	REQUESTS	0
par2	1230463154886	KEY_GENERATION	REQUESTS	0
par2	1230463154886	KEY_DERIVATION	REQUESTS	0

Summary of metrics across the whole HSM:

```
DECRYPT      :          0
ENCRYPT      :          0
KEY_DERIVATION :          0
KEY_GENERATION :          0
SIGN        :    4700342794
VERIFY      :    4700342747
```

Metrics valid from 12 June 2018 11:14:47 to now.

Command Result : 0 (Success)

With arguments (output to file):

```
lunash:>hsm qos metrics show -export myparametricsfile.cvs
```

Successfully exported metrics to file.

Command Result : 0 (Success)

With partition names or numbers (output to terminal):

```
lunash:>hsm qos metrics show -partition test,par1,1230463154887
```

Partition Name	Serial	Operation	Action	Count
test	1230463154880	SIGN	REQUESTS	0
test	1230463154880	VERIFY	REQUESTS	0
test	1230463154880	ENCRYPT	REQUESTS	0
test	1230463154880	DECRYPT	REQUESTS	0
test	1230463154880	KEY_GENERATION	REQUESTS	0
test	1230463154880	KEY_DERIVATION	REQUESTS	0

par1	1230463154886	SIGN	REQUESTS	4700342794
par1	1230463154886	VERIFY	REQUESTS	4700342747
par1	1230463154886	ENCRYPT	REQUESTS	0
par1	1230463154886	DECRYPT	REQUESTS	0
par1	1230463154886	KEY_GENERATION	REQUESTS	0
par1	1230463154886	KEY_DERIVATION	REQUESTS	0
par2	1230463154887	SIGN	REQUESTS	1000
par2	1230463154887	VERIFY	REQUESTS	1000
par2	1230463154887	ENCRYPT	REQUESTS	0
par2	1230463154887	DECRYPT	REQUESTS	0
par2	1230463154887	KEY_GENERATION	REQUESTS	0
par2	1230463154887	KEY_DERIVATION	REQUESTS	0

Summary of metrics across the whole HSM:

```

DECRYPT      :          0
ENCRYPT      :          0
KEY_DERIVATION :          0
KEY_GENERATION :          0
SIGN        :    4700343794
VERIFY      :    4700343747

```

Metrics valid from 12 June 2018 11:14:47 to now.

Command Result : 0 (Success)

With partition names or numbers with incorrect name (output to terminal):

```
lunash:>hsm qos metrics show -partition tesy,par1,1230463154887
```

Partition Name	Serial	Operation	Action	Count
=====	=====	=====	=====	=====
par1	1230463154886	SIGN	REQUESTS	4700342794
par1	1230463154886	VERIFY	REQUESTS	4700342747
par1	1230463154886	ENCRYPT	REQUESTS	0
par1	1230463154886	DECRYPT	REQUESTS	0
par1	1230463154886	KEY_GENERATION	REQUESTS	0
par1	1230463154886	KEY_DERIVATION	REQUESTS	0
par2	1230463154887	SIGN	REQUESTS	1000
par2	1230463154887	VERIFY	REQUESTS	1000
par2	1230463154887	ENCRYPT	REQUESTS	0
par2	1230463154887	DECRYPT	REQUESTS	0
par2	1230463154887	KEY_GENERATION	REQUESTS	0
par2	1230463154887	KEY_DERIVATION	REQUESTS	0

Summary of metrics across the whole HSM:

```

DECRYPT      :          0
ENCRYPT      :          0
KEY_DERIVATION :          0
KEY_GENERATION :          0
SIGN        :    4700343794
VERIFY      :    4700343747

```

Metrics valid from 12 June 2018 11:14:47 to now.

Command Result : 0 (Success)

hsm restore

Restore the contents of the HSM from a backup token.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm restore -serial <serialnum> [**-password** <password>] [**-tokenadminpw** <password>] [**-force**]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-password <password>	-p	Specifies the HSM Admin Password. Passwords are needed only for password-authenticated HSMs, and are not required at the command line. If a password is needed, you are prompted for it, and your response is hidden by asterisk characters (*).
-serial <serialnum>	-s	Specifies the Token Serial Number. The serial number of the backup token is required.
-tokenadminpw <password>	-t	Specifies the Token Admin Password. Passwords are needed only for password-authenticated HSMs, and are not required at the command line. If a password is needed, you are prompted for it, and your response is hidden by asterisk characters (*).

Example

```
lunash:>token backup list
```

```
Token Details:
```

```
=====
```

```
Token Label:                SA78_SIM-21/12/2011
Slot:                       1
Serial #:                   300555
Firmware:                   4.8.6
Hardware Model:             Luna PCM G4
Command Result : 0 (Success)
```

```
lunash:>hsm restore -serial 300555
```

CAUTION: This process will erase the current masking key on this HSM and replace it with the one on the backup token. Any keys masked off any partition on the HSM with the existing masking key will be irretrievable.


```
Type 'proceed' to replace the masking key, or 'quit'
to quit now.
> proceed
```

```
Luna PED operation required to login as HSM Administrator - use Security Officer (blue) PED key.
Warning: You will need to connect Luna PED to the SafeNet Luna Backup HSM to complete
this operation.
```

```
You may use the same Luna PED that you used for SafeNet Luna Network HSM.
```

```
Please type 'proceed' and hit <enter> when you are ready to proceed> proceed
```

```
Luna PED operation required to login to token - use token Security Officer (blue) PED key.
Masking key successfully cloned.
```

```
'hsm restore' successful.
```

```
Command Result : 0 (Success)
```

hsm selftest

Test the cryptographic capabilities of the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm selftest

Example

```
lunash:>hsm selftest
```

```
Self Test. Testing HSM cryptographic capabilities.
```

```
'hsm selfTest' passed.
```

```
HSM working as expected.
```

```
Command Result : 0 (Success)
```

hsm setlegacydomain

Set the legacy cloning domain on an HSM:

- > For password-authenticated HSMs, this is the text string that was used as a cloning domain on the legacy token HSM whose contents are to be migrated to the SafeNet Luna Network HSM.
- > For PED-authenticated HSMs, this is the cloning domain secret on the red PED key for the legacy PED-authenticated token HSM whose contents are to be migrated to the SafeNet Luna Network HSM.

Your target SafeNet Luna Network HSM has, and retains, whatever modern HSM cloning domain was imprinted (on a red PED key) when the HSM was initialized. This command takes the domain value from your legacy HSM's red PED key and associates that with the modern-format domain of the current HSM, to allow the HSM to be the cloning (restore...) recipient of objects from the legacy (token) HSM. The legacy domain associated with your SafeNet Luna Network HSM is attached until the HSM is reinitialized.

Objects from legacy token/HSMs can only be migrated (restored) onto SafeNet Luna HSMs configured to use their legacy domain. In other words, you cannot defeat the security provision that prevents cloning of objects across different domains.

As well, you cannot migrate objects from a Password-authenticated token/HSM to a PED-authenticated SafeNet Luna Network HSM or vice versa. Again, this is a security provision.

See "[About the Migration Guide](#)" on page 1 in the *Migration Guide* for information on the possible combinations of source (legacy) tokens/HSMs and target (modern) HSMs and the disposition of token objects from one to the other.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

hsm setlegacydomain [-domain <domain>]

Argument(s)	Shortcut	Description
-domain <domain>	-d	Specifies the Legacy Cloning Domain name. This parameter is required on password-authenticated HSMs. It is ignored on PED-authenticated HSMs, which retrieve the legacy domain name from the red PED key.

Example

```
lunash:>hsm setlegacydomain
```

Luna PED operation required to set legacy cloning domain - use Domain (red) PED Key.

The PED prompts for the legacy red domain PED Key (notice mention of "raw data" in the PED message).

```
Command result : 0 (Success)
```

hsm show

Display a list showing the current configuration of the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm show

Example

HSM is in a non-zeroized state

```
lunash:>hsm show
```

```
Appliance Details:
```

```
=====
```

```
Software Version:                7.1.0-380
```

```
HSM Details:
```

```
=====
```

```
HSM Label:                       myluna
Serial #:                         700022
Firmware                          7.1.0
HSM Model:                        Luna K7
HSM Part Number:                  808-000048-002
Authentication Method:           PED Keys
HSM Admin login status:          Logged In
HSM Admin login attempts left:    3 before HSM zeroization!
RPV Initialized:                  Yes
Audit Role Initialized:           Yes
Remote Login Initialized:         Yes
Manually Zeroized:                No
Secure Transport Mode:           No
HSM Tamper State:                 No tampers
```

```
Partitions created on HSM:
```

```
=====
```

```
Partition:          700022008, Name: P1
```

```
FIPS 140-2 Operation
```

```
=====
```

```
The HSM is NOT in FIPS 140-2 approved operation mode.
```

```
HSM Storage Information:
```

```
=====
```

```
Maximum HSM Storage Space (Bytes):  2097152
Space In Use (Bytes):                 2097152
Free Space Left (Bytes):               0
```

```

Environmental Information on HSM:
=====
Battery Voltage:                3.093 V
Battery Warning Threshold Voltage: 2.750 V
System Temp:                    35 deg. C
System Temp Warning Threshold:  75 deg. C

```

```
Command Result : 0 (Success)
```

HSM is in a zeroized state

```
lunash:>hsm show
```

```

Appliance Details:
=====
Software Version:  7.0.1-380

```

```

HSM Details:
=====
HSM Label:                no label
Serial #:                  700022
Firmware                   7.1.0
HSM Model:                 Luna K7
HSM Part Number:          808-000048-002
Authentication Method:    PED Keys
HSM Admin login status:   Not Logged In
HSM Admin login attempts left: HSM is zeroized!
Audit Role Initialized:    Yes
RPV Initialized:           Yes
Manually Zeroized:        Yes
Secure Transport Mode:    No
HSM Tamper State:         No tamperers

```

```

Partitions created on HSM:
=====
There are no partitions

```

```

FIPS 140-2 Operation
=====

```

```
The HSM is NOT in FIPS 140-2 approved operation mode.
```

```

HSM Storage Information:
=====
Maximum HSM Storage Space (Bytes):  2097152
Space In Use (Bytes):                0
Free Space Left (Bytes):             2097152

```

```

Environmental Information on HSM:
=====
Battery Voltage:                3.093 V
Battery Warning Threshold Voltage: 2.750 V
System Temp:                    35 deg. C
System Temp Warning Threshold:  75 deg. C

```

```
Command Result : 0 (Success)
```

HSM is in a tamper state

```
lunash:>hsm show
```

Appliance Details:

```
=====
```

```
Software Version:          7.1.0-380
```

HSM Details:

```
=====
```

```
HSM Label:                lunasa7
Serial #:                  29089
Firmware:                  7.1.0
HSM Model:                 Luna K7
HSM Part Number:          808-000048-002
Authentication Method:    Password
HSM Admin login status:   Not Logged In
HSM Admin login attempts left: 3 before HSM zeroization!
RPV Initialized:          No
Audit Role Initialized:   No
Remote Login Initialized: No
Manually Zeroized:        No
Secure Transport Mode:    No
HSM Tamper State:         Tamper(s) detected
```

Partitions created on HSM:

```
=====
```

```
There are no partitions.
```

```
Number of partitions allowed: 100
```

```
Number of partitions created: 0
```

FIPS 140-2 Operation:

```
=====
```

```
The HSM is NOT in FIPS 140-2 approved operation mode.
```

HSM Storage Information:

```
=====
```

```
Maximum HSM Storage Space (Bytes): 33554432
```

```
Space In Use (Bytes): 0
```

```
Free Space Left (Bytes): 33554432
```

Environmental Information on HSM:

```
=====
```

```
Battery Voltage: 3.072 V
```

```
Battery Warning Threshold Voltage: 2.750 V
```

```
System Temp: 35 deg. C
```

```
System Temp Warning Threshold: 75 deg. C
```

```
Command Result: 0 (Success)
```

HSM is not in a tamper state

```
lunash:>hsm show
```

Appliance Details:

```
=====
```

```
Software Version:          7.1.0-380
```

HSM Details:

```
=====
```

```
HSM Label:                lunasa7
```

```
Serial #:                  29089
```

```
Firmware:                  7.1.0
```

```

HSM Model:                Luna K7
HSM Part Number:          808-000048-002
Authentication Method:    Password
HSM Admin login status:   Logged In
HSM Admin login attempts left: 3 before HSM zeroization!
RPV Initialized:          No
Audit Role Initialized:   No
Remote Login Initialized: No
Manually Zeroized:       No
Secure Transport Mode:    No
HSM Tamper State:        No tampers

```

Partitions created on HSM:

```

=====
There are no partitions.
Number of partitions allowed:    100
Number of partitions created:    0

```

FIPS 140-2 Operation:

```

=====
The HSM is NOT in FIPS 140-2 approved operation mode.

```

HSM Storage Information:

```

=====
Maximum HSM Storage Space (Bytes): 33554432
Space In Use (Bytes):              0
Free Space Left (Bytes):           33554432

```

Environmental Information on HSM:

```

=====
Battery Voltage:                3.072 V
Battery Warning Threshold Voltage: 2.750 V
System Temp:                    35 deg. C
System Temp Warning Threshold:  75 deg. C

```

Command Result: 0 (Success)

HSM is experiencing a temperature or battery-voltage excursion

```
lunash:>hsm show
```

Appliance Details:

```

=====
Software Version:                7.1.0-380

```

HSM Details:

```

=====
HSM Label:                      safenet
Serial #:                        521173
Firmware:                        7.1.0
HSM Model:                      Luna K7
HSM Part Number:                808-000048-002
Authentication Method:          Password
HSM Admin login status:         Not Logged In
HSM Admin login attempts left:  3 before HSM zeroization!
RPV Initialized:                No
Audit Role Initialized:         Yes
Remote Login Initialized:       No
Manually Zeroized:              No
Secure Transport Mode:          No
HSM Tamper State:               No tamper(s)

```

Partitions created on HSM:

=====

Partition: 1213450222959, Name: par1

Partition: 1213450222963, Name: par2

Number of partitions allowed: 100

Number of partitions created: 2

FIPS 140-2 Operation:

=====

The HSM is NOT in FIPS 140-2 approved operation mode.

HSM Storage Information:

=====

Maximum HSM Storage Space (Bytes): 33554432

Space In Use (Bytes): 671088

Free Space Left (Bytes): 32883344

Environmental Information on HSM:

=====

Fan 1 Status: standby

Fan 2 Status: active

Battery Voltage: **2.072 V**

Battery Warning Threshold Voltage: 2.750 V

WARNING: Battery Voltage below warning threshold!!

System Temp: **80 deg. C**

System Temp Warning Threshold: 75 deg. C

WARNING: System Temperature above warning threshold!!

Command Result : 0 (Success)

hsm showpolicies

Display the current settings for all HSM capabilities and policies, or optionally restrict the listing to only the policies that are configurable. Include the **-exporttemplate** option to export the current state of all policies to a template file.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm showpolicies [-configonly] [-exporttemplate <filename>]

Argument(s)	Shortcut	Description
-configonly	-c	Restrict the list to configurable policies only.
-exporttemplate <filename>	-e	Export the current state of all HSM policies to a template file.

Example

```
lunash:>hsm showpolicies
```

```
HSM Label:   myLunaHSM
Serial #:    66331
Firmware:    7.3.0
```

The following capabilities describe this HSM, and cannot be altered except via firmware or capability updates.

```
Description                               Value
=====
Enable PIN-based authentication             Allowed
Enable PED-based authentication            Disallowed
Performance level                          15
Enable domestic mechanisms & key sizes     Allowed
Enable masking                             Disallowed
Enable cloning                             Allowed
Enable full (non-backup) functionality     Allowed
Enable non-FIPS algorithms                 Allowed
Enable SO reset of partition PIN           Allowed
Enable network replication                 Allowed
Enable Korean Algorithms                   Disallowed
FIPS evaluated                             Disallowed
Manufacturing Token                        Disallowed
Enable forcing user PIN change             Allowed
Enable portable masking key                Allowed
Enable partition groups                    Disallowed
Enable remote PED usage                    Disallowed
```

```

HSM non-volatile storage space      33554432
Enable unmasking                    Allowed
Maximum number of partitions        100
Enable Single Domain                Disallowed
Enable Unified PED Key              Disallowed
Enable MofN                         Disallowed
Enable small form factor backup/restore Disallowed
Enable Secure Trusted Channel        Allowed
Enable decommission on tamper        Allowed
Enable partition re-initialize       Disallowed
Enable low level math acceleration   Allowed
Enable Fast-Path                    Disallowed
Allow Disabling Decommission         Allowed
Enable Tunnel Slot                  Disallowed
Enable Controlled Tamper Recovery    Allowed
Enable Partition Utilization Metrics Allowed

```

The following policies are set due to current configuration of this HSM and cannot be altered directly by the user.

```

Description                          Value
=====                              =====
PIN-based authentication              True

```

The following policies describe the current configuration of this HSM and may be changed by the HSM Administrator. Changing policies marked "destructive" will erase all HSM partitions on the HSM.

IMPORTANT NOTE: Changing policy 46 (Disable Decommission) will erase all partitions AND zeroize your HSM.

```

Description                          Value      Code      Destructive
=====                              =====
Allow cloning                        On         7         Yes
Allow non-FIPS algorithms             On         12        Yes
SO can reset partition PIN           Off        15        Yes
Allow network replication             On         16        No
Force user PIN change after set/reset On         21        No
Allow offboard storage               On         22        Yes
Allow unmasking                     On         30        No
Current maximum number of partitions 100       33        No
Allow Secure Trusted Channel         Off        39        No
Decommission on tamper               Off        40        Yes
Allow low level math acceleration    On         43        No
Disable Decommission                 Off        46        Yes
Do Controlled Tamper Recovery        On         48        No
Allow Partition Utilization Metrics  Off        49        No

```

Command Result : 0 (Success)

```
lunash:>hsm showpolicies -exporttemplate HSMPT
```

HSM policies successfully written.

Use 'scp' from a client machine to get file named:
HSMPT

Command Result : 0 (Success)

hsm stc

Access the HSM STC-level commands. Use these commands to configure and manage the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

Syntax

hsm stc

activationtimeout
cipher
disable
enable
hmac
identity
partition
rekeythreshold
status

Argument(s)	Shortcut	Description
activationtimeout	a	Set and display the activation timeout for an STC link. See " hsm stc activationtimeout " on page 149.
cipher	ci	Enable, disable, and show the use of a symmetric encryption cipher algorithm for data encryption on the link. See " hsm stc cipher " on page 152.
disable	d	Disable the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM SO partition. See " hsm stc disable " on page 156.
enable	e	Establish a local secure trusted channel (STC) link from the LunaSH shell to the HSM SO partition, and set all the local HSM-related applications in the appliance to communicate to the HSM via this STC link. See " hsm stc enable " on page 157.
hmac	h	Enable, disable, and display the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM. See " hsm stc hmac " on page 158.
identity	i	Manage the HSM SO client identity for the LunaSH STC client token. See " hsm stc identity " on page 162

Argument(s)	Shortcut	Description
partition	p	Export the specified partition's public key to a file, or display that public key. See " hsm stc partition " on page 170.
rekeythreshold	rek	Set or display the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " hsm stc rekeythreshold " on page 173.
status	s	Display status and configuration information for an STC link. See " hsm stc status " on page 176.

hsm stc activationtimeout

Display and set the activation timeout for STC.

Syntax

hsm stc activationtimeout

set
show

Argument(s)	Shortcut	Description
set	se	Set the activation timeout for an STC link. See "hsm stc activationtimeout set" on the next page.
show	sh	Display the STC link activation timeout for the specified partition. See "hsm stc activationtimeout show" on page 151

hsm stc activationtimeout set

Set the activation timeout for the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc activationtimeout set -time <timeout>

Argument(s)	Shortcut	Description
-time <timeout>	-t	Specifies the activation timeout, in seconds. Range: 1 to 240 Default: 120

Example

```
lunash:>hsm stc activationtimeout set -time 30
```

Successfully changed the activation timeout for HSM to 30 seconds.

```
Command Result : 0 (Success)
```

hsm stc activationtimeout show

Display the activation timeout for the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc activationtimeout show

Example

```
lunash:>hsm stc activationtimeout show
```

```
The channel activation timeout for HSM is 120 seconds.
```

```
Command Result : 0 (Success)
```

hsm stc cipher

View, enable, and disable STC cipher algorithms.

Syntax

hsm stc cipher

disable
enable
show

Argument(s)	Shortcut	Description
disable	d	Disable the use of a symmetric encryption cipher algorithm for data encryption on the link. See " hsm stc cipher disable " on the next page .
enable	e	Enable the use of a symmetric encryption cipher algorithm for data encryption on the link. See " hsm stc cipher enable " on page 154
show	s	List the symmetric encryption cipher algorithms you can use for STC data encryption on the specified partition. See " hsm stc cipher show " on page 155 .

hsm stc cipher disable

Disable the use of a symmetric encryption cipher algorithm for data encryption on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command ["hsm stc cipher show" on page 155](#) to show which ciphers are currently enabled/disabled.

NOTE Performance is reduced for larger ciphers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc cipher disable [-all] [-id <cipher_id>] [-force]

Argument(s)	Shortcut	Description
-all	-a	Disable all ciphers.
-id <cipher_id>	-i	Specifies the numerical identifier of the cipher you want to disable, as listed using the command "stc cipher show" on page 334
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc cipher disable -id 3
```

AES 256 Bit with Cipher Block Chaining is now disabled.

Command Result : 0 (Success)

hsm stc cipher enable

Enable the use of a symmetric encryption cipher algorithm for data encryption on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command ["hsm stc cipher show" on the next page](#) to show which ciphers are currently enabled/disabled.

NOTE Performance is reduced for larger ciphers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc cipher enable [-all] [-id <cipher_id>]

Argument(s)	Shortcut	Description
-all	-a	Enable all ciphers.
-id <cipher_id>	-i	Specifies the numerical identifier of the cipher you want to use, as listed using the command "stc cipher show" on page 334 .

Example

```
lunash:>hsm stc cipher enable -id 3
```

```
AES 256 Bit with Cipher Block Chaining is now enabled.
```

```
Command Result : 0 (Success)
```

hsm stc cipher show

List the symmetric encryption cipher algorithms you can use for data encryption on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc cipher show

Example

```
lunash:>hsm stc cipher show
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	No

Command Result : 0 (Success)

hsm stc disable

Disable the secure trusted channel (STC) admin channel link. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

This command terminates the STC link, so that all communications between LunaSH and the HSM are transmitted over a non-encrypted link local to the appliance.

NOTE Disabling the local STC link is service affecting. It causes an STC service restart, which temporarily terminates all existing STC links to the appliance. It also terminates the existing HSM login session.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc disable [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc disable
```

```
Disabling STC on the admin channel will require a restart of STC service.
Any existing STC connections will be terminated.
```

```
Type 'proceed' to disable STC on the admin channel, or 'quit'
to quit now. > proceed
```

```
Successfully disabled STC on the admin channel.
```

```
Command Result : 0 (Success)
```

hsm stc enable

Enable the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

NOTE Enabling the local STC link is service affecting. It causes an STC service restart, which temporarily terminates all existing STC links to the appliance. It also terminates the existing HSM login session.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc enable [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc enable
```

```
Enabling local STC will require a restart of STC service.
Any existing STC connections will be terminated.
```

```
Type 'proceed' to enable STC on the admin channel, or 'quit'
to quit now. > proceed
```

```
Successfully enabled STC on the admin channel.
```

```
Command Result : 0 (Success)
```

hsm stc hmac

Enable, disable, and show STC HMAC algorithms.

Syntax

hsm stc hmac

disable
enable
show

Argument(s)	Shortcut	Description
disable	d	Disable the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) link that is local to the appliance, that is, from the LunaSH shell to the HSM. See "hsm stc hmac disable" on the next page .
enable	e	Enable the use of an HMAC message digest algorithm used for message integrity verification on the specified partition. See "hsm stc hmac enable" on page 160
show	s	List the HMAC message digest algorithms you can use for STC message integrity verification on the specified partition. See "hsm stc hmac show" on page 161 .

hsm stc hmac disable

Disable the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command ["hsm stc hmac show" on page 161](#) to show which HMAC message digest algorithms are currently enabled/disabled.

NOTE You cannot disable all HMAC message digest algorithms.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc hmac disable -id <hmac_id>

Argument(s)	Shortcut	Description
-id <hmac_id>	-i	Specifies the numerical identifier of the HMAC algorithm you want to disable, as listed using the command "hsm stc hmac show" on page 161 .

Example

```
lunash:>hsm stc hmac disable -id 0
```

```
HMAC with SHA 256 Bit is now disabled.
```

```
Command Result : 0 (Success)
```

hsm stc hmac enable

Enable the use of an HMAC message digest algorithm for message integrity verification on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command ["hsm stc hmac show" on the next page](#) to show which HMAC message digest algorithms are currently enabled/disabled.

NOTE You must enable at least one HMAC message digest algorithm.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc hmac enable -id <hmac_id>

Argument(s)	Shortcut	Description
-id <hmac_id>	-i	Specifies the numerical identifier of the HMAC algorithm you want to enable, as listed using the command "hsm stc hmac show" on the next page .

Example

```
lunash:>hsm stc hmac enable -id 0
```

```
HMAC with SHA 256 Bit is now enabled.
```

```
Command Result : 0 (Success)
```


hsm stc hmac show

List the HMAC message digest algorithms you can use for message integrity verification on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc hmac show

Example

```
lunash:>hsm stc hmac show
```

This table lists the HMAC algorithms supported for STC links to the partition. Enabled algorithms are accepted during STC link negotiation with a client. At least one HMAC algorithm must be enabled.

HMAC ID	HMAC Name	Enabled
0	HMAC with SHA 256 Bit	Yes
1	HMAC with SHA 512 Bit	Yes

Command Result : 0 (Success)

hsm stc identity

Create and manage client identities for STC.

Syntax

hsm stc identity

create
delete
initialize
partition
show

Argument(s)	Shortcut	Description
create	c	Create a STC client identity for the LunaSH client. See " hsm stc identity create " on the next page.
delete	d	Delete the LunaSH STC client identity. See " hsm stc identity delete " on page 164.
initialize	i	Initialize the LunaSH STC client token. See " hsm stc identity initialize " on page 165.
partition	p	Remove the HSM SO partition identity public key that is currently registered with the LunaSH STC client token. See " hsm stc identity partition deregister " on page 167
show	s	Display the client name, public key hash, and registered partitions for the LunaSH STC client token. See " hsm stc identity show " on page 169.

hsm stc identity create

Create a client identity for the STC admin channel client token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

After it is created, the LunaSH client identity is exported to the file **HsmClientId.cid**.

NOTE To protect the integrity of any existing STC links, you cannot execute this command if HSM policy 39: Allow Secure Trusted Channel is enabled.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc identity create [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc identity create
```

The client identity successfully created and exported to file: HsmClientId.cid.

```
Command Result : 0 (Success)
```

hsm stc identity delete

Delete the client identity from the STC admin channel identity token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

This command, in conjunction with ["hsm stc identity create" on the previous page](#) allows you to re-generate the token identity key pair if required for security reasons (for example, if the token is compromised), or for administrative reasons (for example, to perform a key rotation).

This command does the following, in the order specified:

1. Deletes the LunaSH STC client identity public key in the HSM SO partition.
2. Deletes the HSM SO partition identity.
3. Deletes the LunaSH STC client identity.

If any of the identities fail to be deleted, the command will report the failure but will continue to delete the client identity.

NOTE To protect the integrity of any existing STC links, you cannot execute this command if HSM policy 39: Allow Secure Trusted Channel is enabled.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc identity delete [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>stc identity delete
```

```
Are you sure you want to delete the client identity HsmClientId?
```

```
All registered HSM partitions will no longer be available to this client token.
```

```
    Type 'proceed' to continue, or 'quit'
    to quit now.
    > proceed
```

```
Successfully deleted client identity.
```

```
Command Result : 0 (Success)
```

hsm stc identity initialize

Re-initialize the STC identity for the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The STC identity for the secure trusted channel (STC) admin channel is automatically initialized when the STC admin channel is enabled. You should only use this command if you need to manually re-establish the STC admin channel.

NOTE To protect the integrity of any existing STC links, you cannot execute this command if HSM policy 39: Allow Secure Trusted Channel is enabled.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc identity initialize [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc identity initialize
```

The client token is already initialized with the following client identity:

```
Public Key SHA1 Hash:          71e31e3c6366caf62327225587c4c69cfe080112
Registered Partition:         No
```

Re-initialization will delete the client identity.

```
    Type 'proceed' to continue, or 'quit'
    to quit now.
    > proceed
```

Successfully re-initialized the client token.

```
Command Result : 0 (Success)
```

hsm stc identity partition

Register and deregister HSM SO partition identities for STC.

Syntax

hsm stc identity partition

deregister
register

Argument(s)	Shortcut	Description
deregister	d	Remove the HSM SO partition identity public key that is currently registered with the LunaSH STC client token. See " hsm stc identity partition deregister " on the next page
register	r	Register the HSM SO partition identity public key with the LunaSH STC client token. See " hsm stc identity partition register " on page 168.

hsm stc identity partition deregister

Remove the HSM SO partition identity public key that is currently registered to the STC admin channel client token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

Use this command only if you need to reconfigure the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the appliance operating system and the HSM SO partition for local services and applications, such as LunaSH and NTLS.

CAUTION! Deregistering the HSM SO partition disables the LunaSH STC link.

NOTE To protect the integrity of any existing STC links, you cannot execute this command if HSM policy 39: Allow Secure Trusted Channel is enabled.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc identity partition deregister [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm stc identity partition deregister
```

```
Are you sure you want to deregister the partition identity?
```

```
    Type 'proceed' to continue, or 'quit'
    to quit now.
    > proceed
```

```
Successfully deregistered the partition identity from the client token.
```

```
Command Result : 0 (Success)
```

hsm stc identity partition register

Register the HSM SO partition to the STC admin channel client token. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

Use this command only if you need to re-register the partition to the client token, for example if the token has been re-initialized.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc identity partition register -file <filename>

Argument(s)	Shortcut	Description
-file <filename>	-f	Specifies the partition public key file.

Example

```
lunash:>hsm stc identity partition register -file 66331.pid
```

Successfully registered the partition identity to the client token.

```
Command Result : 0 (Success)
```


hsm stc identity show

Display the following information for the STC admin channel client token:

- > The public key SHA1 hash for the client identity.
- > Whether the HSM SO partition is registered or not.

The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc identity show

Example

```
lunash:>hsm stc identity show
```

```
Public Key SHA1 Hash:          b28a5876e839715fc62eb3fde264f6f612ef9841
Registered Partition Identity:
  Partition Serial Number:     66331
  Partition Public Key SHA1 Hash: 71a453e3aecf4938b2a04b5096c329645eb5a322
```

```
Command Result : 0 (Success)
```

hsm stc partition

View the public key for the HSM SO partition, and export that public key to a file.

Syntax

hsm stc partition

export

show

Argument(s)	Shortcut	Description
export	e	Export the specified partition's public key to a file. See " hsm stc partition export " on the next page.
show	s	Display the public key and serial number for the current partition. See " hsm stc partition show " on page 172.

hsm stc partition export

Export the public key for the HSM SO partition to a file to be used to configure the STC admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

You must be logged in to the HSM as the SO to perform this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc partition export

Example

```
lunash:>hsm stc partition export
```

```
Successfully exported partition identity for HSM to file: 66331.pid
```

```
Command Result : 0 (Success)
```

hsm stc partition show

Display the public key and serial number for the HSM SO partition. You must be logged into the partition as the SO to perform this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc partition show

Example

```
lunash:>hsm stc partition show
```

```
Partition Serial Number:          66331  
Partition Identity Public Key SHA1 Hash: 71a453e3aecf4938b2a04b5096c329645eb5a322
```

```
Command Result : 0 (Success)
```

hsm stc rekeythreshold

Display and set the rekey threshold for the symmetric key used to encrypt data on the STC admin channel.

Syntax

hsm stc rekeythreshold

set
show

Argument(s)	Shortcut	Description
set	se	Set the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " hsm stc rekeythreshold set " on the next page.
show	sh	Display the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " hsm stc rekeythreshold show " on page 175.

hsm stc rekeythreshold set

Set the rekey threshold for the symmetric key used to encrypt data on the STC admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The symmetric key is used for the number of times specified by the threshold value, after which it is regenerated and the counter is reset to 0. Each command sent to the HSM over the HSM STC link uses one life.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc rekeythreshold set -value <key_life>

Argument(s)	Shortcut	Description
-value <key_life>	-v	An integer that specifies the key life for the STC symmetric key, in millions of messages. Each message sent to the HSM over the STC link uses one life. Range: 0 - 4000 Default: 400

Example

```
lunash:>hsm stc rekeythreshold set -value 500
```

Successfully changed the rekey threshold for HSM to 500 million commands.

```
Command Result : 0 (Success)
```

hsm stc rekeythreshold show

Display the rekey threshold for the symmetric key used to encrypt data on the secure trusted channel (STC) admin channel. The STC admin channel is local to the appliance, and is used to transmit data between the local services and applications running on the appliance (such as LunaSH, NTLS, and the STC service) and the HSM SO partition.

The symmetric key is used the number of times specified by the threshold value, after which it is regenerated and the counter is reset to 0. Each command sent to the HSM over the STC link uses one life.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stc rekeythreshold show

Example

```
lunash:>hsm stc rekeythreshold show
```

```
Current rekey threshold for HSM is 400 million messages.
```

```
Command Result : 0 (Success)
```

hsm stc status

View the current STC policy activated on the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm stc status

Example

```
lunash:>hsm stc status
```

```
HSM STC Policy:      On
Enabled:             Yes
Status:              Connected
Channel ID:          1
Cipher Name:         AES 256 Bit with Cipher Block Chaining
HMAC Name:           HMAC with SHA 512 Bit
```

```
Command Result : 0 (Success)
```


hsm stm

Configure, or display information about Secure Transport Mode (STM).

STM allows you to verify that an HSM has not been tampered while in transit or storage. STM is optional. When invoked, STM provides comparison strings that you can visually verify, and imposes a pause during the STM recover operation where you indicate that you have seen the command output and decided to resume using the HSM, or to leave the HSM in Secure Transport Mode. For more information, see "[Secure Transport Mode](#)" on page 1.

Syntax

hsm stm

```
recover
show
transport
```

Argument(s)	Shortcut	Description
recover	r	Recover an HSM that has been placed in STM. See " hsm stm recover " on the next page.
show	s	Displays the current STM state. See " hsm stm show " on page 180.
transport	t	Place the HSM in STM. See " hsm stm transport " on page 181.

hsm stm recover

Recover the HSM from Secure Transport Mode (STM). If the HSM is in initialized state, you must be logged in as HSM SO to recover from STM; if the HSM is zeroized, no login is required.

When you enter this command, enter the random user string that was generated when the HSM was put into STM. A verification string will be displayed:

- > If the verification string generated matches the string that was displayed when the HSM was put into STM (see ["hsm stm transport" on page 181](#)), the HSM was not interfered with or tampered while in STM.
- > If the verification string generated does not match the verification string generated when you placed the HSM in STM, this might indicate that the HSM has been interfered with or tampered while in STM, or that an incorrect random user string has been entered.

NOTE The random user string is for verification purposes only. Entering a different string will not prevent you from recovering the HSM from STM.

If you are confident the HSM has not been tampered with, you can still enter **"proceed"** to recover from STM. See ["Secure Transport Mode" on page 1](#) for more information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stm recover -randomuserstring <string>

Argument(s)	Shortcut	Description
-randomuserstring <string>	-r	To confirm that the HSM was not tampered with while in STM, enter the random user string generated when it was placed in STM, in the format XXXX-XXXX-XXXX-XXXX.

Example

```
lunash:>hsm stm recover -randomuserstring 4CEd-4HX7-J/YW-pCX6
```

```
Attempting to recover from Secure Transport Mode...
Calculating the verification string (may take a few seconds)...
```

```
Verification String: 59bt-3CXF-7/Tt-qKTx
```

CAUTION: You are attempting to recover the HSM from Secure Transport Mode. If the Verification string does not match the one you were provided out-of-band, there may be an issue with the HSM. Type 'quit' at the prompt to remain in Secure Transport Mode.

If the verification strings match, or if you wish to bypass this check, type 'proceed' to recover from Secure Transport Mode.

```
Type 'proceed' to continue, or 'quit' to quit now.  
> proceed  
Successfully recovered from Secure Transport Mode.
```

```
Command Result : 0 (Success)
```

hsm stm show

Display the current Secure Transport Mode (STM) state. The state is NO or YES, as follows:

NO	The HSM is not in STM, and is ready for use.
YES	The HSM is in STM. You must use the command " hsm stm recover " on page 178 to exit STM before you can use the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm stm show

Example

```
lunash:>hsm stm show
```

```
Secure Transport Mode: NO
```

```
Command Result : No Error
```

hsm stm transport

Place the HSM in Secure Transport Mode (STM). You need to be logged in as the HSM SO to issue this command.

When you enter this command, two strings are displayed: a verification string and a random user string. Record both of these to confirm later that the HSM was not tampered with while in STM. When you recover from STM, enter the random user string and compare the generated verification string to the original one you received. If the strings match, the HSM has not been tampered while in STM (see ["hsm stm recover" on page 178](#)).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm stm transport

Example

```
lunash:>hsm stm transport
```

```
WARNING !! You are about to configure the HSM in secure transport mode.
            If you proceed, the HSM will be inoperable until it is recovered with hsm stm recover
command.
```

```
            If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
```

```
Configuring the HSM for secure transport mode...
```

```
Record the displayed verification & random user strings. These are required to recover from Secure
Transport Mode.
```

```
Verification String: 59bt-3CXF-7/Tt-qKTx
```

```
Random User String: 4CEd-4HX7-J/YW-pCX6
```

```
HSM is now in Secure Transport Mode.
```

```
Command Result : 0 (Success)
```

hsm supportinfo

Generate the **supportInfo.txt** file. The **supportInfo.txt** file includes detailed information about the state and settings of the HSM, as well as other important appliance information, such as the network settings and negotiated link status. You must transfer file from the SafeNet appliance to your client using **scp** (Linux/Unix) or **pscp** (Windows), and sent it to Customer Support.

The file **supportInfo.txt** is generated by executing any of the following commands:

- > hsm supportinfo
- > sysconf appliance reboot
- > sysconf appliance poweroff

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm supportinfo

Example

```
lunash:>hsm supportinfo
```

```
'hsm supportInfo' successful.
```

Use 'scp' from a client machine to get file named:
supportInfo.txt

```
Command Result : 0 (Success)
```

hsm tamper

Show and clear the HSM tamper state.

Syntax

hsm tamper

show
clear

Argument(s)	Shortcut	Description
show	s	Display the HSM tamper state. See "hsm tamper show" on page 185 .
clear	c	Clear the HSM tamper state. See "hsm tamper clear" on the next page .

hsm tamper clear

Clear HSM tamper state. The HSM Security Officer (SO) must be logged in, or an error is returned.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

hsm tamper clear

Example

```
lunash:>hsm tamper clear
```

```
WARNING !! You are about to clear the HSM Tamper State..  
           If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed  
Proceeding...
```

```
HSM Tamper State was successfully cleared.
```

```
Command Result : 0 (Success)
```

hsm tamper show

Show HSM tamper state.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

hsm tamper show

Example

HSM is in a tamper state

```
lunash:>hsm tamper show
```

```
WARNING - Tamper(s) Detected:  
Chassis intrusion
```

```
Command Result : 0 (Success)
```

HSM is not in a tamper state

```
lunash:>hsm tamper show
```

```
No active tampers.
```

```
Command Result : 0 (Success)
```

hsm update

Access commands that allow you to display or install any available capability or firmware updates.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

Syntax

hsm update

capability

show

Argument(s)	Shortcut	Description
capability	c	Apply a capability update. See "hsm update capability" on the next page .
show	s	Display a list of the available HSM updates. See "hsm update show" on page 189 .

hsm update capability

Apply a capability update. You must use **scp** to transfer the capability update from your SafeNet Luna HSM client workstation to the appliance before you can apply it. You can view any packages that have been transferred, but not yet installed, using the **hsm update show** command.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

NOTE The command dialog prompts for a slot on which to act. This is not currently used. Always select slot 0.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm update capability -capability <capability_name> [-force]

Argument(s)	Shortcut	Description
-capability	-c	Specifies the name of the capability update to apply.
-force	-f	Force the action without prompting.

Example

```
lunash:>hsm update capability -capability newcapability
```

CAUTION: This command updates the HSM Capability.
This process cannot be reversed.
Any connected clients will have their connections closed.
All clients should disconnect and the NTLS should be stopped before proceeding.

```
Type 'proceed' to continue, or 'quit'
to quit now.
> proceed
```

CAUTION: This capability update is destructive.

```
All keys and partitions on the HSM or token will be destroyed.
This process cannot be reversed.
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
```

```
SafeNet Firmware/Capability Update Utility
```

```
Enter slot number (0 for the first slot found) : 0
```

```
Success
```

```
Capability "newcapability" updated.
```

```
Command Result : 0 (Success)
```

hsm update show

Display the HSM capability update packages that have been transferred onto the SafeNet appliance; shows both capability packages that have not yet been applied using the **hsm update capability** command, and packages that have been applied.

Firmware rollback can remove any capabilities that were not applied in earlier firmware, or that are not supported by earlier firmware. After rollback or update, the system retains the full list that you had purchased, allowing you to re-install where appropriate.

To verify if a capability has been successfully added, use the **hsm showpolicies** command or the **hsm displaylicenses** command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

hsm update show

Example

```
lunash:>hsm update show
```

```
Capability Updates:
```

```
    newcapability
```

```
Command Result : 0 (Success)
```

hsm zeroize

Removes all partitions and keys from the HSM.

CAUTION! This command puts the HSM in a zeroized state.

- > This command destroys the HSM SO and all users (except Auditor), and their objects.
- > This command can be run only via a local serial connection; it is not accepted via SSH. Because this is a destructive command, the user is asked to “proceed” unless the `-force` switch is provided at the command line. See ["Comparison of Destruction/Denial Actions" on page 1](#) in the *Administration Guide* to view a table that compares and contrasts various "deny access" events or actions that are sometimes confused.
- > This command does not require HSM login. The assumption is that your organization's physical security protocols prevent unauthorized physical access to the HSM. Nevertheless, if those protocols failed, an unauthorized person would have no access to HSM contents, and would be limited to temporary denial of service by destruction of HSM contents.
- > This command does not reset HSM policies, except for policy 39: Allow Secure Trusted Channel. After zeroization, you will need to re-establish your STC links, as described in ["Restoring STC After HSM Zeroization" on page 1](#) in the *Administration Guide*, and in ["Creating an STC Link Between a Client and a Partition" on page 1](#) in the *Configuration Guide*.
- > This command does not erase the RPV (Remote PED Vector or orange PED Key authentication data) from the HSM.
- > This command does not delete the Auditor role.

To also reset HSM policies and destroy the RPV and destroy the Auditor, see ["hsm factoryreset" on page 89](#).

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

hsm zeroize [-force]

Argument(s)	Shortcut	Description
<code>-force</code>	<code>-f</code>	Force the action without prompting.

Example

```
lunash:>hsm zeroize
```

```
CAUTION: Are you sure you wish to zeroize this HSM?
          All partitions and data will be erased.
          HSM level policies will not be changed.
          All current NTLs and/or STC sessions will be terminated.
          If you want policies reverted as well, use factory reset.
```

Type 'proceed' to return the HSM to factory default, or
'quit' to quit now.

> proceed

'hsm zeroize' successful.

Please wait while the HSM is reset to complete the
process.

Command Result : 0 (success)

my

Access commands that allow the currently logged in user to manage their files, passwords, and public keys.

Syntax

my

file
password
public-key

Argument(s)	Shortcut	Description
file	f	Access commands that allow the currently logged in user to manage their files. See "my file" on the next page .
password	pa	Access commands that allow the currently logged in user to manage their password. See "my password" on page 197 .
public-key	pu	Access commands that allow the currently logged in user to manage their public keys. See "my public-key" on page 200 .

my file

Access commands that allow the currently logged in user to manage their files.

Syntax

my file

clear
delete
list

Argument(s)	Shortcut	Description
clear	c	Delete all of the files owned by the currently logged in user. See "my file clear" on the next page .
delete	d	Delete a file owned by the currently logged in user. See "my file delete" on page 195 .
list	l	List the files owned by the currently logged in user. See "my file list" on page 196 .

my file clear

Deletes all of the files owned by the currently logged in user.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my file clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>my file clear
```

```
WARNING !! This command will delete all user files.
```

```
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will abort.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

my file delete

Delete a file owned by the currently logged in user.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my file delete <filename>

Argument(s)	Shortcut	Description
<filename>		Specifies the name of the file to delete.

Example

```
lunash:>my file delete supportInfo.txt
```

```
Command Result : 0 (Success)
```

my file list

List the files owned by the currently logged in user.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Synopsis

my file list

Example

```
lunash:>my file list
```

```
217811 Feb 27 15:28 supportInfo.txt
 681 Feb 27 12:03 DAKCertRequest.bin
 515 Feb 24 13:41 154438865323.pid
 515 Feb 24 13:41 154438865322.pid
 515 Feb 24 13:41 154438865321.pid
 515 Feb 23 10:01 154438865316.pid
 515 Feb 23 10:01 154438865315.pid
 515 Feb 23 10:01 154438865314.pid
 515 Feb 23 10:01 154438865313.pid
 4330 Feb 21 10:21 firstboot.log
```

```
Command Result : 0 (Success)
```

my password

Access commands that allow the currently logged in user to manage their password.

Syntax

my password

expiry show

set

Argument(s)	Shortcut	Description
expiry show	e s	Displays password expiry information for the currently logged in user. See "my password expiry show" on the next page .
set	s	Change the password for the currently logged in user. See "my password set" on page 199 .

my password expiry show

Display password expiry information for the currently logged in user.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my password expiry show

Example

```
lunash:>my password expiry show
```

```
Last password change           : Feb 27, 2017  
Password expires                : never
```

```
Command Result : 0 (Success)
```

my password set

Change the password for the currently logged in user.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my password set

Example

```
lunash:>my password set
```

Changing password for user admin.

You can now choose the new password.

The password must be at least 8 characters long.

The password must contain characters from at least 3 of the following 4 categories:

- Uppercase letters (A through Z)
- Lowercase letters (a through z)
- Numbers (0 through 9)
- Non-alphanumeric characters (such as !, \$, #, %)

New password:

Retype new password:

passwd: all authentication tokens updated successfully.

Command Result : 0 (Success)

my public-key

Access commands that allow the currently logged in user to manage their public keys. Add a public key for your user if you wish to authenticate your sessions using public-key authentication rather than password. The SafeNet Luna Network HSM is shipped with public-key authentication allowed, by default. However, you nevertheless must make your first connections using password authentication, until you have imported a public key from your computer and added it to the appliance with **my public-key add** command.

NOTE The **my public-key** commands manage public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Luna Network HSM are still "[sysconf ssh publickey enable](#)" on page 470 and "[sysconf ssh publickey disable](#)" on page 469.

Syntax

my public-key

add
clear
delete
list

Argument(s)	Shortcut	Description
add	a	Adds an SSH public key for the currently logged in user. See " my public-key add " on the next page.
clear	c	Deletes all SSH public keys for the currently logged in user. See " my public-key clear " on page 202.
delete	d	Deletes an SSH public key for the currently logged in user. See " my public-key delete " on page 203.
list	l	Lists the SSH public keys owned by the currently logged in user. See " my public-key list " on page 204.

my public-key add

Add an SSH public key for the currently logged in user.

NOTE The **my public-key** commands manage public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Luna Network HSM are still "[sysconf ssh publickey enable](#)" on page 470 and "[sysconf ssh publickey disable](#)" on page 469.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my public-key add <lunash_user_public_key>

Argument(s)	Description
<lunash_user_public_key>	Specifies the name of the public key to add.

Example

```
lunash:>my public-key add somekey
```

```
Command Result : 0 (Success)
```

my public-key clear

Delete all SSH public keys for the currently logged in user.

NOTE The **my public-key** commands manage public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Luna Network HSM are still "[sysconf ssh publickey enable](#)" on page 470 and "[sysconf ssh publickey disable](#)" on page 469.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my public-key clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>my public-key clear
```

```
WARNING !! This command will delete all User SSH Public Keys.
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will abort.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

my public-key delete

Delete an SSH public key for the currently logged in user.

NOTE The **my public-key** commands manage public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Luna Network HSM are still "[sysconf ssh publickey enable](#)" on page 470 and "[sysconf ssh publickey disable](#)" on page 469.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my public-key delete <lunash_user_public_key>

Argument(s)	Description
<lunash_user_public_key>	Specifies the name of the public key to delete.

Example

```
lunash:>my public-key delete somekey
```

```
Command Result : 0 (Success)
```

my public-key list

List the SSH public keys owned by the currently logged in user.

NOTE The **my public-key** commands manage public keys for use by ssh sessions, but the commands to enable and disable their use on SafeNet Luna Network HSM are still "[sysconf ssh publickey enable](#)" on page 470 and "[sysconf ssh publickey disable](#)" on page 469.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

my public-key list

Example

```
lunash:>my public-key list
```

```
SSH Public Keys for user 'admin':
```

Name	Type	Bits	Fingerprint
pub1	ssh-rsa	1024	08:95:7b:9c:57:27:2e:cc:6f:f2:99:e4:19:41:1c:e9

```
Command Result : 0 (Success)
```

network

Access commands that allow you to view and configure the network settings for the appliance.

NOTE If the network service has been stopped using the **service stop network** command, all network commands will fail.

Syntax

network

dns
hostname
interface
ping
route
show

Argument(s)	Shortcut	Description
dns	d	Access commands that allow you to configure the appliance DNS settings. See "network dns" on the next page .
hostname	h	Set the network host name. See "network hostname" on page 213 .
interface	i	Configure the network interfaces. See "network interface" on page 214 .
ping	p	Test the network connectivity. See "network ping" on page 231 .
route	r	Access commands that allow you to configure the network routes for the appliance. See "network route" on page 232 .
show	s	Display the current network configuration. See "network show" on page 239 .

network dns

Access commands that allow you to configure the appliance DNS settings.

NOTE If the network service has been stopped using the **service stop network** command, all network commands will fail.

Syntax

network dns

add
delete

Argument(s)	Shortcut	Description
add	a	Add domain name servers and search domains to the network configuration. See "network dns add" on the next page .
delete	d	Delete domain name servers and search domains from the network configuration. See "network dns delete" on page 210 .

network dns add

This command adds a domain name server or search domain to the system.

You must execute the command once for each name server or search domain being added. To see the existing DNS settings, use the **network show** command.

Syntax

network dns add

nameserver
searchdomain

Argument(s)	Shortcut	Description
nameserver	n	Add the specified name server to the DNS table. See " network dns add nameserver " on the next page.
searchdomain	s	Add the specified search domain to the DNS table. See " network dns add searchdomain " on page 209.

network dns add nameserver

Add a domain name server to the network configuration for the appliance. The name server is added to the appliance DNS table. You can add up to three different DNS nameservers to the appliance DNS table. There is one DNS table that applies to all network devices (ports) on the appliance.

When you add a DNS server, you add it to a specific network device on the appliance (eth0, eth1, eth2, eth3, bond0, bond1). When you add a DNS server to a device, it is added to the DNS table for the appliance and becomes available to all devices on the appliance, provided the device you added it to is connected to the network. For example, if you add a DNS server to eth0, all devices will be able to access the DNS server if eth0 is connected to the network. If eth0 is disconnected from the network, access to the DNS server is lost for any devices to which you did not add the DNS server. To ensure that any DNS server you add is available in the event of a network or port failure, it is recommended that you add it to all devices you will use to connect the appliance to the network.

NOTE Although you can use this command to add more than three different DNS nameservers, only the first three that you add are used. Any additional nameservers that you add are ignored.

To display the current DNS settings for the appliance, use the command ["network show" on page 239](#)

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network dns add nameserver <ip_address> **-device**<net_device>

Argument(s)	Shortcut	Description
<ip_address>		Specifies the IP address of the DNS server you want to add to the DNS table on the appliance.
-device <net_device>	-d	Add the specified network device to the DNS table. Valid values: eth0, eth1, eth2, eth3, bond0, bond1

Example

```
lunash:>network dns add nameserver 192.16.0.2 -device eth0
```

Command Result : 0 (Success)

network dns add searchdomain

Add a search domain to the network configuration for the appliance. Search domains allow you to avoid typing the complete address of frequently used Internet domains by automatically appending the search domain to an internet address you specify in LunaSH. For example, if you add the search domain **mycompany.com**, entering the command **network ping hsm1** would search for the domain **hsm1.mycompany.com**. If the domain resolves, it would ping the device with that host name.

The search domain is added to the appliance DNS table. You can add a maximum of six search domains totaling no more than 256 characters.

When you add a DNS search domain, you add it to a specific network device on the appliance (eth0, eth1, eth2, eth3, bond0, bond1). When you add a search domain to a device, it is added to the DNS table for the appliance and becomes available to all devices on the appliance, provided the device you added it to is connected to the network. For example, if you add a search domain to eth0, all devices will use the search domain if eth0 is connected to the network. If eth0 is disconnected from the network, the search domain is not used by any devices to which you did not add the search domain. To ensure that any search domain you add is available in the event of a network or port failure, it is recommended that you add it to all devices you will use to connect the appliance to the network.

NOTE These settings apply to static network configurations only. If you are using DHCP, the DNS search domains configured on the DHCP server are used.

To display the current DNS settings for the appliance, including the search domains, use the command ["network show" on page 239](#)

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network dns add searchdomain <domain> **-device**<net_device>

Argument(s)	Shortcut	Description
<domain>		Add the specified search domain to the DNS table.
-device <net_device>	-d	Add the search domain to the specified network device. Valid values: eth0, eth1, eth2, eth3, bond0, bond1

Example

```
lunash:>network dns add searchdomain gemalto.com -device eth0
```

Command Result: 0 (Success)

network dns delete

Delete a DNS name server or search domain from the appliance network configuration.

To display the current DNS settings for the appliance, use the command ["network show" on page 239](#)

Syntax

network dns delete

nameserver
searchdomain

Argument(s)	Shortcut	Description
nameserver	-n	Delete the specified name server from the DNS table. See "network dns delete nameserver" on the next page
searchdomain	-s	Delete the specified search domain from the DNS table. See "network dns delete searchdomain" on page 212

network dns delete nameserver

Delete a domain name server from the network configuration for the appliance.

When you delete a DNS server, you delete it from a specific network device on the appliance (eth0, eth1, eth2, eth3, bond0, bond1). When you delete a DNS server from a device, it is deleted from the DNS table for the appliance only if it is not configured on any other network devices on the appliance. To completely remove a DNS name server from the DNS table for the appliance, you must delete the DNS name server from each device to which it was added. If you do not delete the the DNS name server from each device to which it was added, it will continue to be listed in the DNS table for the appliance and will be available to all devices on the appliance, provided the device it is added it to is connected to the network.

To display the current DNS settings for the appliance, including the name servers, use the command ["network show" on page 239](#)

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network dns delete nameserver <ip_address> **-device**<net_device>

Argument(s)	Shortcut	Description
<ip_address>		Delete the specified name server from the DNS table.
-device <net_device>	-d	Delete the specified network device from the DNS table. Valid values: eth0, eth1, eth2, eth3, bond0, bond1

Example

```
lunash:>network dns delete nameserver 11.22.33.44 -device eth0
```

Command Result : 0 (Success)

network dns delete searchdomain

Delete a DNS search domain from the network configuration for the appliance.

When you delete a DNS search domain, you delete it from a specific network device on the appliance (eth0, eth1, eth2, eth3, bond0, bond1). When you delete a DNS search domain from a device, it is deleted from the DNS table for the appliance only if it is not configured on any other network devices on the appliance. To completely remove a DNS search domain from the DNS table for the appliance, you must delete the DNS search domain from each device to which it was added. If you do not delete the the DNS search domain from each device to which it was added, it will continue to be listed in the DNS table for the appliance and will be available to all devices on the appliance, provided the device it is added it to is connected to the network.

To display the current DNS settings for the appliance, including the search domains, use the command ["network show" on page 239](#).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network dns delete searchdomain <ip_address> **-device**<net_device>

Argument(s)	Shortcut	Description
<ip_address>		Delete the specified search domain from the DNS table.
-device <net_device>	-d	Delete the specified network device from the DNS table. Valid values: eth0, eth1, eth2, eth3, bond0, bond1

Example

```
lunash:>network dns delete searchdomain gemalto.com -device eth0
```

Command Result : 0 (Success)

network hostname

Configure a host name for the appliance. You can use this command to specify a fully-qualified domain name (FQDN) for the appliance, in the format `<hostname>.<domainname>`, if necessary.

The host name must adhere to the following rules:

- > Have a maximum length of 64 characters
- > Contain only the following characters: a-z, A-Z, 0-9, -, _, and .
- > Not begin or end in a dot (period)
- > Not have two dots (periods) immediately following each other

NOTE If the network service has been stopped using the **service stop network** command, all network commands will fail.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network hostname <hostname>

Argument(s)	Description
<hostname>	Specifies the host name for the appliance. You can specify a simple host name, or a fully-qualified domain name (FQDN), in the format <code><hostname>.<domainname></code> .

Example

```
[local_host] lunash:>network hostname mylunasa
```

```
Success: Hostname mylunasa set.
```

```
Command Result : 0 (Success)
```

```
[mylunasa] lunash:>
```

network interface

Access sub-commands that allow you to configure the appliance network interface ports.

NOTE If the network service has been stopped using the **service stop network** command, all network commands will fail.

Syntax

network interface

bonding
delete
dhcp
slaac
static

Argument(s)	Shortcut	Description
bonding	b	Configure the network interface port bonding. See " network interface bonding " on page 216.
delete	del	Delete the network configuration for a network interface port. See " network interface delete " on page 222.
dhcp	dh	Set dynamic IP configuration. See " network interface dhcp " on page 223.
slaac	sl	Set SLAAC IPv6 Configuration. See " network interface slaac " on page 226.
static	st	Set static IP configuration. See " network interface static " on page 228. This is the default. If you do not specify an interface type, static is assumed.

network interface -device <netdevice> **-ip** <IP_address> **-netmask** <IP_or_prefixlength> [**-gateway** <IP_address>] [**-ipv6**] [**-force**]

Argument(s)	Shortcut	Description
-device <netdevice>	-d	Specifies the network device you want to configure. Valid values: eth0, eth1, eth2, eth3
-force	-f	Force the action without prompting.

Argument(s)	Shortcut	Description
-gateway <IP_address>	-g	Specifies the address of the network gateway. <ul style="list-style-type: none"> > If you are configuring an IPv4 address, you must provide an IPv4 address for the gateway. > If you are configuring an IPv6 address, you must provide an IPv6 address for the gateway.
-ip <IP_address>	-i	Specifies the IP address you want to assign to the device. You can specify an IPv4 or IPv6 address. If you are configuring an IPv6 address, you must also include the -ipv6 flag in the command. When entering an IPv6 address, you can use full or shorthand syntax. For example, the following notations are equivalent: <ul style="list-style-type: none"> > 2001:0db3:8ba3:0000:0000:8a5e:03f0:7384 > 2001:db3:8ba3::8a5e:3f0:7384
-ipv6	-ipv	Specifies that the address specified using the -ip parameter is an IPv6 address.
-netmask <IP_or_prefixlength>	-n	Specifies the network mask for the interface. <ul style="list-style-type: none"> > If you are configuring an IPv4 address, you must specify the network mask in dotted-decimal format (for example, 255.255.255.0) > If you are configuring an IPv6 address, you must specify the prefix length (for example, 64).

network interface bonding

Access commands that allow you to bond two network interfaces into a single virtual device. Creating a bonded interface provides redundant failover in the event of a port failure. You can create bond0 between eth0 and eth1, and bond1 between eth2 and eth3. Bonded interfaces must use static addressing.

Syntax

network interface bonding

config
disable
enable
show

Argument(s)	Shortcut	Description
config	c	Add a network bonding interface. See " network interface bonding config " on the next page.
disable	d	Disable network interface bonding. See " network interface bonding disable " on page 218.
enable	e	Enable network interface bonding. See " network interface bonding enable " on page 219.
show	s	Display the current network interface bonding configuration. See " network interface bonding show " on page 221.

network interface bonding config

Configures network bonding interfaces. A bonded interface provides redundancy in the event of a physical port failure or network connection failure. You can create bond0 between eth0 and eth1, and bond1 between eth2 and eth3. Bonded interfaces must use static addressing.

The bonded port is not active unless port bonding is enabled. To enable port bonding, use the command ["network interface bonding enable" on page 219](#).

Changing the configuration for a bonded interface

If the bonded interface you configure has already been configured, the existing configuration is deleted and is replaced by the new configuration, regardless of whether the existing bonded interface is enabled or not.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface bonding config -ip <ip_address> -netmask <netmask> -name {bond0 | bond1} -gateway <ipaddress>

Argument(s)	Shortcut	Description
-ip <ipaddress>	-i	Specifies the IP address of the bonded virtual network device.
-gateway <ipaddress>	-g	Specifies the gateway/router IP address.
-name {bond0 bond1}	-na	Specifies the network bond you want to configure: <ul style="list-style-type: none"> > bond0 bonds eth0 and eth1 > bond1 bonds eth2 and eth3
-netmask <string>	-ne	Specifies the network mask for the interface. You can specify the network mask in IP address format (for example, 255.255.255.0) or in CIDR format, without the leading slash (for example, 24).

Example

```
lunash:>network interface bonding config -ip 192.20.11.64 -netmask 255.255.255.0 -gateway
192.20.11.10 -name bond1
```

Command Result : 0 (Success)

network interface bonding disable

Disable network interface bond0 or bond1.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface bonding disable -name <netbond>

Argument(s)	Shortcut	Description
-name <netbond>	-n	Specifies the bonded interface you want to disable. Valid values: bond0, bond1

Example

```
lunash:>network interface bonding disable -name bond0
```

Command Result : 0 (Success)

network interface bonding enable

Enable network interface bond0 or bond1.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface bonding enable -name <netbond>

Argument(s)	Shortcut	Description
-name <netbond>	-n	Specifies the bonded interface you want to enable. Valid values: bond0, bond1

Example

```
lunash:>network interface bonding enable -name bond0
```

```
Command Result : 0 (Success)
```

```
lunash:>network show
```

```
Hostname      : sa7pw
Name Server(s) :
Search Domain(s) : <not set>
```

```
Interface settings and status
```

```
HW Address (eth0)      : 00:15:B2:A9:B7:85
Bond master (eth0)    : bond0
Link detected (eth0)  : Yes
```

```
HW Address (eth1)      : 00:15:B2:A9:B7:85
Bond master (eth1)    : bond0
Link detected (eth1)  : Yes
```

```
HW Address (bond0)    : 00:15:B2:A9:B7:85
IP Address (bond0)    : 192.20.11.64/24
Mask (bond0)          : 255.255.255.0
Gateway (bond0)       : 192.20.11.10
DNS (bond0)           :
DNS Search (bond0)    :
IP Protocol (bond0)   : IPv4
Protocol (bond0)      : Static
Auto Connect (bond0) : Yes
Activated (bond0)     : Yes
Link detected (bond0) : Yes
Active Slaves (bond0) : eth1 eth0
```

```
Kernel IP routing table
```

```
Destination      Gateway          Genmask          Flags Metric Ref    Use Iface
0.0.0.0          192.20.11.10    0.0.0.0          UG    301   0      0 bond0
192.20.11.0     0.0.0.0         255.255.255.0    U     300   0      0 bond0
192.20.11.0     0.0.0.0         255.255.255.0    U     301   0      0 bond0
```

Command Result : 0 (Success)

network interface bonding show

Display the current network bonding interface status.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

network interface bonding show

Example

```

lunash:>network interface bonding show
bond0:

Bonding Mode: fault-tolerance (active-backup)
Primary Slave: None
Currently Active Slave: eth1
MII Status: up
MII Polling Interval (ms): 0
Up Delay (ms): 0
Down Delay (ms): 0
ARP Polling Interval (ms): 500
ARP IP target/s (n.n.n.n form): 192.20.11.10

Slave Interface: eth1
MII Status: up
Speed: 1000 Mbps
Duplex: full
Link Failure Count: 1
Permanent HW addr: 00:15:b2:a9:b7:85
Slave queue ID: 0

Slave Interface: eth0
MII Status: up
Speed: 1000 Mbps
Duplex: full
Link Failure Count: 0
Permanent HW addr: 00:15:b2:a9:b7:84
Slave queue ID: 0

Slave status eth0:      Link detected: yes
Slave status eth1:      Link detected: yes
-----
bond1:
bond1 is configured, but not enabled.

Bonding Interface: bond1
Slave devices: eth2 eth3
-----
Command Result : 0 (Success)

```

network interface delete

This command disables a network interface and deletes its current configuration.

NOTE You cannot delete an interface that is a member of an active bond. See ["network interface bonding"](#) on page 216.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface delete -device <netdevice>

Argument(s)	Shortcut	Description
-device <netdevice>	-d	Specifies the network device to delete. Valid values: eth0, eth1, eth2, eth3

Example

```
lunash:>network interface delete -device eth1
```

```
Command Result : 0 (Success)
```

network interface dhcp

Configure a network interface to use DHCP. Using DHCP will automatically update the SafeNet appliance's system name servers and other network settings that are transmitted via DHCP.

NOTE When DHCP is used, the appliance's IP address may change automatically, which may lead to certificate mismatches and client connection issues.

CAUTION! Do not specify DHCP if you intend to use network interface port bonding - a change to the leased IP address disrupts port bonding, which must be manually disabled and then reconfigured before it can be re-enabled.

NOTE You cannot configure an interface that is a member of an active bond. You must first disable the bond. See "[network interface bonding](#)" on page 216

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface dhcp -device <netdevice> [-force] [-ipv6]

Argument(s)	Shortcut	Description
-device <netdevice>	-d	Specifies the network device you want to configure. Valid values: eth0, eth1, eth2, eth3
-force	-f	Force the action without being prompted.
-ipv6	-i	Specifies that you want to obtain an IPv6 address via DHCPv6.

Example

DHCP with IPv4

```
lunash:>network interface dhcp -device eth1
```

NOTICE: The network connection for device eth3 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
```

Command Result : 0 (Success)

```
lunash:>network show
```

```

Hostname       : sa7pw
Name Server(s) : 192.20.10.20      192.16.2.14
Search Domain(s) : <not set>
```

```
Interface settings and status
```

```

HW Address (eth1)   : 00:15:B2:A9:B7:85
IP Address (eth1)   : 192.20.11.84/24
Mask (eth1)        : 255.255.255.0
Gateway (eth1)     : 192.20.11.10
DNS (eth1)         :
DNS Search (eth1)  :
IP Protocol (eth1) : IPv4
Protocol (eth1)    : DHCP
Auto Connect (eth1) : Yes
Activated (eth1)   : Yes
Link detected (eth1) : Yes
```

```
Command Result : 0 (Success)
```

DHCP with IPv6

```
lunash:>network interface dhcp -device eth1 -ipv6
```

NOTICE: The network connection for device eth1 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

```
lunash:>network show
```

```

Hostname       : sa7pw
Name Server(s) : 192.20.10.20      192.16.2.14
Search Domain(s) : <not set>
```

```
Interface settings and status
```

```

HW Address (eth1)   : 00:15:B2:A9:B7:85
IP Address (eth1)   : 2001:db3:8ba3::8a5e:3f0:7384/64
Mask (eth1)        : 2001:db3:8ba3:::/64
Gateway (eth1)     : 2001:db3:a348::6b3a:24:7336
DNS (eth1)         :
DNS Search (eth1)  :
IP Protocol (eth1) : IPv6
Protocol (eth1)    : DHCP
Auto Connect (eth1) : Yes
Activated (eth1)   : Yes
Link detected (eth1) : Yes
```

```
Kernel IPv6 routing table
```

Destination	Next Hop	Flag	Met	Ref	Use	If
fe80::/64	::	U	256	0	0	eth1
::/0	::	!n	-1	1	1	lo
fe80::215:b2ff:fea9:b785/128	::	Un	0	1	0	lo
ff00::/8	::	U	256	1	0	eth1
::/0	::	!n	-1	1	1	lo

Command Result : 0 (Success)

network interface slaac

Configure a network interface to obtain an IPv6 address using the Stateless Address Autoconfiguration (SLAAC) protocol.

Most IPv6-enabled routers have the ability to periodically broadcast router advertisements (RA) messages to all devices on the network. These RA messages include a list of one or more IPv6 prefixes that any device on the local network can use to automatically form a unique IPv6 address. IPv6 client devices, such as the SafeNet Luna Network HSM, listen for these local RA's. When you issue this command, the SafeNet Luna Network HSM claims one of the advertised prefixes and uses it to automatically configure an IPv6 address that uniquely identifies the device on the network.

You must issue this command on each network interface that will be connected using a SLAAC IPv6 configuration.

NOTE The network interface you want to configure must be connected to the network and have access to the local router used to provide the IPv6 prefixes.

NOTE You cannot configure an interface that is a member of an active bond. You must first disable the bond. See ["network interface bonding" on page 216](#)

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface slaac -device <netdevice> [-force]

Argument(s)	Shortcut	Description
-device <netdevice>	-d	Specifies the network device you want to configure. Valid values: eth0, eth1, eth2, eth3
-force	-f	Force the action without prompting.

Example

```
lunash:>network interface slaac -device eth1
```

NOTICE: The network connection for device eth1 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
```

Command Result : 0 (Success)

lunash:>network show

```
Hostname       : sa7pw
Name Server(s) :
Search Domain(s) : <not set>
```

Interface settings and status

```
HW Address (eth1)   : 00:15:B2:A9:B7:85
IP Address (eth1)  : 2001:db3:8ba3::8a5e:3f0:7384/64
Mask (eth1)        : 2001:db3:8ba3:::/64
Gateway (eth1)     : 2001:db3:a348::6b3a:24:7336
DNS (eth1)         :
DNS Search (eth1)  :
IP Protocol (eth1) : IPv6
Protocol (eth1)    : SLAAC
Auto Connect (eth1) : Yes
Activated (eth1)   : Yes
Link detected (eth1) : Yes
```

network interface static

Configure a network interface to use a static IP configuration. You can use this command to configure a static IPv4 address or a static IPv6 address.

You must issue this command on each network interface that will be connected using a static IP configuration.

NOTE You cannot configure an interface that is a member of an active bond. You must first disable the bond. See ["network interface bonding" on page 216](#)

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network interface static -device <netdevice> -ip <IP_address> -netmask <IP_or_prefixlength> [-gateway <IP_address>] [-force] [-ipv6]

Argument(s)	Shortcut	Description
-device <netdevice>	-d	Specifies the network device you want to configure. Valid values: eth0, eth1, eth2, eth3
-force	-f	Force the action without prompting.
-gateway <IP_address>	-g	Specifies the address of the network gateway. <ul style="list-style-type: none"> > If you are configuring an IPv4 address, you must provide an IPv4 address for the gateway. > If you are configuring an IPv6 address, you must provide an IPv6 address for the gateway.
-ip <IP_address>	-i	Specifies the IP address you want to assign to the device. You can specify an IPv4 or IPv6 address. If you are configuring an IPv6 address, you must also include the -ipv6 flag in the command. When entering an IPv6 address, you can use full or shorthand syntax. For example, the following notations are equivalent: <ul style="list-style-type: none"> > 2001:0db3:8ba3:0000:0000:8a5e:03f0:7384 > 2001:db3:8ba3::8a5e:3f0:7384
-ipv6	-ipv	Specifies that the address specified using the -ip parameter is an IPv6 address.

Argument(s)	Shortcut	Description
-netmask <IP_address>	-n	Specifies the network mask for the interface. <ul style="list-style-type: none"> > If you are configuring an IPv4 address, you must specify the network mask in dotted-decimal format (for example, 255.255.255.0) > If you are configuring an IPv6 address, you must specify the prefix length (for example, 64).

Example

IPv4 configuration

```
lunash:>network interface static -device eth0 -ip 192.20.11.78 -gateway 192.20.11.10 -netmask
255.255.255.0
```

NOTICE: The network connection for device eth0 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
```

Command Result : 0 (Success)

```
lunash:>network show
```

```
Hostname       : sa7pw
Name Server(s) :
Search Domain(s) : <not set>
```

Interface settings and status

```
HW Address (eth0)   : 00:15:B2:A9:B7:84
IP Address (eth0)   : 192.20.11.78/24
Mask (eth0)        : 255.255.255.0
Gateway (eth0)     : 192.20.11.10
DNS (eth0)         :
DNS Search (eth0)  :
IP Protocol (eth0) : IPv4
Protocol (eth0)    : Static
Auto Connect (eth0) : Yes
Activated (eth0)   : Yes
Link detected (eth0) : Yes
```

Command Result : 0 (Success)

IPv6 configuration

```
lunash:>network interface static -device eth1 -ip 2001:0db3:8ba3:0000:0000:8a5e:03f0:7384 -netmask
64 -gateway 2001:0db3:a348:0000:0000:6b3a:0024:7336 -ipv6
```

NOTICE: The network connection for device eth1 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

```
lunash:>network show
```

```
Hostname      : sa7pw
Name Server(s) :
Search Domain(s) : <not set>
```

```
Interface settings and status
```

```
HW Address (eth1)      : 00:15:B2:A9:B7:85
IP Address (eth1)      : 2001:db3:8ba3::8a5e:3f0:7384/64
Mask (eth1)            : 2001:db3:8ba3::/64
Gateway (eth1)         : 2001:db3:a348::6b3a:24:7336
DNS (eth1)             :
DNS Search (eth1)      :
IP Protocol (eth1)     : IPv6
Protocol (eth1)        : Static
Auto Connect (eth1)    : Yes
Activated (eth1)       : Yes
Link detected (eth1)   : Yes
```

network ping

Test the network connectivity to the specified host. This command sends an ICMP ECHO message to another computer, to verify the presence and alertness of the target computer on the network.

NOTE If the network service has been stopped using the **service stop network** command, all network commands will fail.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

network ping <hostname_or_IPAddress> [-ipv6]

Argument(s)	Shortcut	Description
<hostname_or_IPAddress>		Specifies the host name or IP address of the host you want to ping.
-ipv6	-i	Specifies that the host you want to ping uses IPv6 addressing.

Example

```
lunash:>network ping 192.20.11.40

PING 192.20.11.40 (192.20.11.40) 56(84) bytes of data.
64 bytes from 192.20.11.40: icmp_seq=1 ttl=64 time=0.525 ms

--- 192.20.11.40 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 0ms
rtt min/avg/max/mdev = 0.525/0.525/0.525/0.000 ms

Command Result : 0 (Success)
```

network route

Access commands that allow you to configure the network routes for the appliance.

NOTE If the network service has been stopped using the **service stop network** command, all network commands will fail.

Syntax

network route

add
clear
delete
show

Argument(s)	Shortcut	Description
add	a	Add a network route. See "network route add" on the next page .
clear	c	Delete all network routes. See "network route clear" on page 235 .
delete	d	Delete the specified network route. See "network route delete" on page 236 .
show	s	Display the current network route configuration. See "network route show" on page 238 .

network route add

Add a manually configured network route to the current configuration. This command should be used only on the advice of a network administrator.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network route add <routetype> <IP_address> **-device** <netdevice> [**-metric** <metric>] [**-netmask** <string>] [**-gateway** <IP_address>] [**-force**] [**-ipv6**]

Argument(s)	Shortcut	Description
<routetype>		Specifies the type of route (network or host) you want to add. Valid values: host, network
<IP_address>		Specifies the IP address of the network or host you want to add to the routing table. You can specify an IPv4 or IPv6 address. If you are configuring an IPv6 address, you must also include the -ipv6 flag in the command. When entering an IPv6 address, you can use full or shorthand syntax. For example, the following notations are equivalent: > 2001:0db3:8ba3:0000:0000:8a5e:03f0:7384 > 2001:db3:8ba3::8a5e:3f0:7384
-device <netdevice>	-d	Specifies the network device to which you want to add the route. Valid values: eth0, eth1, eth2, eth3
-force	-f	Force the action without prompting
-gateway <IP_address>	-g	Specifies the gateway/router IP address if this is not a locally connected network or host.
-ipv6	-i	Specifies that the route you are adding uses IPv6 addressing.
-metric <metric>	-m	Specifies the routing metric to use for the route. Range: 0 to 65535 Default: 0

Argument(s)	Shortcut	Description
-netmask <string>	-n	<p>Specifies the network mask.</p> <p>Include this option only if you are adding a network route. If not specified, the default netmask is used.</p> <ul style="list-style-type: none"> > If you are configuring an IPv4 route, you must specify the network mask in dotted-decimal format (for example, 255.255.255.0) > If you are configuring an IPv6 route, you must specify the prefix length (for example, 64) <p>Default:</p> <ul style="list-style-type: none"> > <routetype> = network IPv4: 255.255.255.0 IPv6: 64 > <routetype> = host IPv4: 255.255.255.255 IPv6: 128

Example

Adding an IPv4 route

```
lunash:>network route add host 123.45.67.89 -device eth2 -metric 1000
```

NOTICE: The network connection for device eth2 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
```

Proceeding...

Command Result : Success

Adding an IPv6 route

```
lunash:>network route add network 2001:db8::1 -device eth2 -netmask 64 -gateway fe80::20c:29ff:fe9e:5f79 -ipv6
```

NOTICE: The network connection for device eth2 will be restarted for new network settings to take effect.

If you are sure that you wish to restart the device connection, then type 'proceed', otherwise type 'quit'

```
> proceed
```

Proceeding...

Routing table successfully updated.

Command Result : 0 (Success)

network route clear

Delete all manually configured static routes (as set with **network route add**). Since this operation may delete valuable configuration data, you are prompted to confirm the action unless you use the **-force** option.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network route clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting

Example

```

lunash:>ne r c
WARNING !! This command deletes all manually configured routes and restarts the network service.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.

> proceed
Proceeding...
Routing table successfully updated.

Command Result : 0 (Success)

```

network route delete

Delete a manually configured network route from the current configuration. This command should be used only on the advice of a network administrator.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

network route delete <roudtype> <ipaddress> **-device** <netdevice> [**-metric** <metric>] [**-netmask** <ipaddress>] [**-gateway** <ipaddress>] [**-force**] [**-ipv6**]

Argument(s)	Shortcut	Description
<roudtype>		Set to "network" or "host" for network or host specific routes respectively. Valid values: host, network
<ipaddress>		Specifies the IP address of the target network or host to be deleted. You can specify an IPv4 or IPv6 address. If you are deleting an IPv6 address, you must also include the -ipv6 flag in the command. When entering an IPv6 address, you can use full or shorthand syntax. For example, the following notations are equivalent: > 2001:0db3:8ba3:0000:0000:8a5e:03f0:7384 > 2001:db3:8ba3::8a5e:3f0:7384
-device <netdevice>	-d	Specifies a specific network device for the route. Valid values: eth0, eth1, eth2, eth3
-force	-f	Force the action without prompting
-gateway <ipaddress>	-g	Specifies the gateway/router IP address to be deleted if this is not a locally connected network or host.
-metric <metric>	-m	Specifies a routing metric. Range: 0 to 65535 Default: 0

Argument(s)	Shortcut	Description
-netmask <ipaddress>	-n	<p>Specifies the network mask.</p> <p>Include this option only if you are deleting a network route. If not specified, the default netmask is used.</p> <ul style="list-style-type: none"> > If you are deleting an IPv4 route, you must specify the network mask in dotted-decimal format (for example, 255.255.255.0) > If you are deleting an IPv6 route, you must specify the prefix length (for example, 64) <p>Default:</p> <ul style="list-style-type: none"> > <routetype> = network IPv4: 255.255.255.0 IPv6: 64 > <routetype> = host IPv4: 255.255.255.255 IPv6: 128

Example

```
lunash:>network route delete host 123.45.67.89 -device eth2 -metric 1000
```

NOTICE: The network connection for device eth2 will be restarted for new network settings to take effect.

```
If you are sure that you wish to restart the device connection, then type 'proceed', otherwise
type 'quit'
> proceed
```

```
Proceeding...
```

```
Command Result : Success
```

network route show

Display the current network route configuration.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

network route show

Example

```
lunash:>network route show
```

Manually configured routes

```
2018:1:2:3::/64 via fe80::20c:29ff:fe9e:5f79
```

Kernel IP routing table

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
0.0.0.0	192.20.9.10	0.0.0.0	UG	100	0	0	eth1
0.0.0.0	192.20.9.10	0.0.0.0	UG	101	0	0	eth0
192.20.9.0	0.0.0.0	255.255.255.0	U	0	0	0	eth0
192.20.9.0	0.0.0.0	255.255.255.0	U	100	0	0	eth0
192.20.9.10	0.0.0.0	255.255.255.255	UH	100	0	0	eth1

Kernel IPv6 routing table

Destination	Next Hop	Flag	Met	Ref	Use	If
2018:1:2:3::206/128	::	Ue	256	0	0	eth3
2018:1:2:3::/64	fe80::20c:29ff:fe9e:5f79	UG	100	0	0	eth2
2018:1:2:3::/64	::	U	256	0	0	eth2
fe80::/64	::	U	256	0	0	eth3
fe80::/64	::	U	256	0	0	eth2
::/0	::	!n	-1	1	10840	lo
2018:1:2:3::206/128	::	Un	0	1	29	lo
2018:1:2:3::abcd/128	::	Un	0	1	0	lo
fe80::215:b2ff:fea8:fd44/128	::	Un	0	1	0	lo
fe80::215:b2ff:fea8:fd45/128	::	Un	0	1	239	lo
ff00::/8	::	U	256	1	0	eth3
ff00::/8	::	U	256	1	0	eth2
::/0	::	!n	-1	1	10840	lo

Command Result : 0 (Success)

network show

Display the network configuration for each network device on the appliance. Verbose mode also includes detailed capability information for each device, such as the supported and active link modes and auto-activation setting. This information is also collected in the **hsm supportinfo** command.

NOTE If the network service has been stopped using the **service stop network** command, all network commands, including **network show**, will fail.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

network show [-verbose]

Argument(s)	Shortcut	Description
-verbose	-v	Display additional capability and configuration information for each network device.

Example

Normal mode

```
lunash:>network show
```

```

Hostname       : 192.20.9.109
Name Server(s) :
Search Domain(s) : 20.9.109

```

Interface settings and status

```

HW Address (eth0) : 00:15:B2:A8:FD:A8
IP Address (eth0) : 192.20.9.109/24
Mask (eth0)       : 255.255.255.0
Gateway (eth0)    : 192.20.9.10
DNS (eth0)        :
DNS Search (eth0) :
IP Protocol (eth0) : IPv4
Protocol (eth0)   : Static
Auto Connect (eth0) : Yes
Activated (eth0)  : Yes
Link detected (eth0) : Yes

HW Address (eth1) : 00:15:B2:A8:FD:A9

```

```

IP Address (eth1)      : 192.20.9.102
Mask (eth1)           : 255.255.255.0
Gateway (eth1)        : 192.20.9.10
DNS (eth1)            :
DNS Search (eth1)     :
IP Protocol (eth1)    : IPv4
Protocol (eth1)       : Static
Auto Connect (eth1)   : Yes
Activated (eth1)      : No
Link detected (eth1)  : No

HW Address (eth2)     : 00:15:B2:A8:FD:AA
IP Address (eth2)     : 2019:2:3:4:215:b2ff:fea8:fda2
Mask (eth2)           : 2019:2:3:4::/64
Gateway (eth2)        : fe80::c800:5ff:fe95:8
DNS (eth2)            :
DNS Search (eth2)     : sfnt.local.com
IP Protocol (eth2)    : IPv6
Protocol (eth2)       : SLAAC
Auto Connect (eth2)   : Yes
Activated (eth2)      : No
Link detected (eth2)  : No

HW Address (eth3)     : 00:15:B2:A8:FD:AB
IP Address (eth3)     :
Mask (eth3)           :
Gateway (eth3)        :
DNS (eth3)            :
DNS Search (eth3)     :
IP Protocol (eth3)    : IPv4
Protocol (eth3)       : DHCP
Auto Connect (eth3)   : No
Activated (eth3)      : No
Link detected (eth3)  : No

Status (bond0)        : Not configured

Status (bond1)        : Not configured

```

Kernel IP routing table

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
0.0.0.0	192.20.9.10	0.0.0.0	UG	100	0	0	eth0
192.20.9.0	0.0.0.0	255.255.255.0	U	100	0	0	eth0

Kernel IPv6 routing table

Destination	Next Hop	Flag	Met	Ref	Use	If
::1/128	::	U	256	0	0	lo
fe80::/64	::	U	256	0	0	eth0
::/0	::	!n	-1	1	1	lo
::1/128	::	Un	0	1	69	lo
fe80::215:b2ff:fea8:fda8/128	::	Un	0	1	0	lo
ff00::/8	::	U	256	0	0	eth0
::/0	::	!n	-1	1	1	lo

Command Result : 0 (Success)

Verbose mode

```

lunash:>network show -verbose
.
.
Device and Connection Details
===== eth0 =====
BOOT PROTOCOL:                static
=====
Settings for eth0:
  Supported ports: [ TP ]
  Supported link modes:   10baseT/Half 10baseT/Full
                        100baseT/Half 100baseT/Full
                        1000baseT/Full
  Supported pause frame use: Symmetric
  Supports auto-negotiation: Yes
  Advertised link modes:  10baseT/Half 10baseT/Full
                        100baseT/Half 100baseT/Full
                        1000baseT/Full
  Advertised pause frame use: Symmetric
  Advertised auto-negotiation: Yes
  Speed: 100Mb/s
  Duplex: Full
  Port: Twisted Pair
  PHYAD: 1
  Transceiver: internal
  Auto-negotiation: on
  MDI-X: on (auto)
  Supports Wake-on: pumbg
  Wake-on: g
  Current message level: 0x00000007 (7)
                        drv probe link

  Link detected: yes

===== eth0 =====

Command Result: : 0 (Success)
lunash:>

```

ntls

Access commands that allow you to manage the network trust link service (NTLS) on the appliance.

Syntax

ntls

bind
certificate
information
ipcheck
show
tcp_keepalive
threads
timer

Argument(s)	Shortcut	Description
bind	b	Set the NTLS binding. See "ntls bind" on the next page .
certificate	c	Access commands that allow you to manage the NTLS certificates. See "ntls certificate" on page 245 .
information	in	Access commands that allow you to display NTLS status information. See "ntls information" on page 253 .
ipcheck	ip	Access commands that allow you to manage the NTLS client source IP validation configuration. See "ntls ipcheck" on page 256 .
show	sh	Show the NTLS binding. See "ntls show" on page 260 .
tcp_keepalive	tc	Access commands that allow you to manage TCP keepalive. See "ntls tcp_keepalive" on page 261 .
threads	th	Access commands that allow you to manage the NTLS worker threads. See "ntls threads" on page 265 .
timer	ti	Access commands that allow you to manage the NTLS timer. See "ntls timer" on page 269 .

ntls bind

Binds the network trust link service (NTLS) to a network device. You can bind NTLS to a specific device (eth0, eth1, eth2, or eth3), all devices (eth0, eth1, eth2, and eth3) or to a bonded interface (bond0 or bond1). See ["network interface bonding" on page 216](#) for more information about creating a bonded interface.

NOTE You can bind your NTLS traffic to an IPv4 or IPv6 device, but not to both IPv4 and IPv6 devices simultaneously. If some of the network devices on your SafeNet Luna Network HSM are configured with IPv4 addresses, while others are configured with IPv6 addresses, the **ntls bind all** command will bind NTLS to all IPv4 devices, while the **ntls bind all -ipv6** command will bind NTLS to all IPv6 devices.

You must restart the NTLS service for the change to take effect (see ["service restart" on page 298](#)):

- > if the device you are binding to is configured and active, the NTLS traffic is bound to the new device immediately after NTLS restarts.
- > if the device you are binding to is not configured or is inactive, the NTLS binding configuration is updated, but the NTLS traffic keeps its current binding. The NTLS traffic will begin using the new configuration only after you configure and connect the interface so that it becomes active, and restart the NTLS service.

If you wish, client traffic restriction could complement SSH traffic restriction using the command ["sysconf ssh ip" on page 463](#) or ["sysconf ssh device" on page 462](#), which restrict administrative traffic (over SSH) to a specific IP address or device name on your SafeNet Luna Network HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls bind <netdevice> [-force] [-ipv6]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-ipv6	-i	Use with ntls bind all to bind all IPv6 devices. This parameter is not required when binding to a specific IPv6 device (eth0, eth1, eth2, or eth3), or a specific bonded device (bond0 or bond1).

Argument(s)	Shortcut	Description
<netdevice>		<p>Specifies the network device you want to bind to the NTLS service. All NTLS traffic to the appliance will use the specified network device.</p> <p>Valid values:</p> <p>all: Bind to all devices. Use without the -ipv6 parameter to bind to all IPv4 devices. Use with the -ipv6 parameter to bind to all IPv6 devices.</p> <p>bond0: Bind to the bond0 interface. See "network interface bonding" on page 216.</p> <p>bond1: Bind to the bond1 interface.</p> <p>eth0: Bind to the eth0 device.</p> <p>eth1: Bind to the eth1 device.</p> <p>eth2: Bind to the eth2 device.</p> <p>eth3: Bind to the eth3 device.</p> <p>Default:</p> <p>all (0.0.0.0). This will bind to all IPv4 devices.</p>

Example

```
lunash:>ntls bind eth0
```

NTLS binding set to network device eth0.
You must restart the NTLS service for the new settings to take effect.

If you are sure that you wish to restart NTLS, then type 'proceed', otherwise type 'quit'

```
>proceed
Proceeding...
Restarting NTLS service...
Stopping ntlsl: [ OK ]

Starting ntlsl: [ OK ]
```

Command Result : 0 (Success)

ntls certificate

Access commands that allow you to manage the NTLS certificates.

Syntax

ntls certificate

monitor
show

Argument(s)	Shortcut	Description
monitor	m	Access commands that allow you to manage certificate expiry monitoring. See "ntls certificate monitor" on the next page .
show	s	Show the NTLS server certificate. See "ntls certificate show" on page 251 .

ntls certificate monitor

Access commands that allow you to manage certificate expiry monitoring.

Syntax

ntls certificate monitor

disable
enable
show
trap trigger

Argument(s)	Shortcut	Description
disable	d	Disable certificate expiry monitoring. See " ntls certificate monitor disable " on the next page.
enable	e	Enable certificate expiry monitoring. See " ntls certificate monitor enable " on page 248.
show	s	Show the certificate expiry monitor status. See " ntls certificate monitor show " on page 249.
trap trigger	t t	Set the NTLS certificate expiry SNMP trap trigger. See " ntls certificate monitor trap trigger " on page 250.

ntls certificate monitor disable

Disable NTLS certificate expiry monitoring.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls certificate monitor disable

Example

```
lunash:>ntls certificate monitor disable
```

```
NTLS Server Cert Monitor disabled  
Stopping certmonitord:
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

ntls certificate monitor enable

Enable NTLS certificate expiry monitoring. The NTLS certificate used by the SafeNet appliance is only valid for a limited period. This command turns on lifetime monitoring so that as the expiry date nears, an SNMP trap notifies an administrator of the impending expiry of the certificate.

The SNMP trap must be configured before the NTLS certificate expiry trap can be sent even if the monitor daemon is enabled.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls certificate monitor enable

Example

```
lunash:>ntls certificate monitor enable
```

```
NTLS Server Cert Monitor enabled  
Starting certmonitord:
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

ntls certificate monitor show

Report when the NTLS certificate will expire and whether certificate monitoring is enabled.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls certificate monitor show

Example

```
lunash:>ntls certificate monitor show
```

```
NTLS Server Certificate Expiry Monitor is enabled.
```

```
NTLS Server Certificate will expire on "Feb 22 15:19:21 2027 GMT"
```

```
Certificate expiry trap will be sent 30 days before the Certificate expiry day "Feb 22 15:19:21 2027 GMT" and on every 6 hour(s)
```

```
Command Result : 0 (Success)
```

ntls certificate monitor trap trigger

Set the NTLS certificate expiry SNMP trap. This command defines when, and how often, an SNMP trap is sent when the NTLS certificate is about to expire.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls certificate monitor trap trigger -preexpiry <days> -trapinterval <hours>

Argument(s)	Shortcut	Description
-preexpiry <days>	-p	Specifies the number of days before the certificate expires that the trap is triggered. Range: 1 to 366
-trapinterval <hours>	-t	Specifies the interval, in hours, that the trap is sent once it has been triggered. Range: 1 to 720

Example

```
lunash:>ntls certificate monitor trap trigger -preexpiry 30 -trapinterval 6
```

Certificate expiry trap is configured to be sent 30 days before the Certificate expiry day "Feb 22 15:19:21 2027 GMT" and on every 6 hour(s)

Stopping certmonitord: [OK]

Starting certmonitord: [OK]

Command Result : 0 (Success)

ntls certificate show

Display the contents of the NTLS server certificate.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls certificate show

Example

```
lunash:>ntls certificate show
```

```
NTLS Server Certificate:
```

```
Data:
```

```
Version: 3 (0x2)
```

```
Serial Number: 0 (0x0)
```

```
Signature Algorithm: sha256WithRSAEncryption
```

```
Issuer: C=CA, ST=Ontario, L=Ottawa, O=Chrysalis-ITS, CN=66331
```

```
Validity
```

```
Not Before: Feb 20 15:19:21 2017 GMT
```

```
Not After : Feb 22 15:19:21 2027 GMT
```

```
Subject: C=CA, ST=Ontario, L=Ottawa, O=Chrysalis-ITS, CN=66331
```

```
Subject Public Key Info:
```

```
Public Key Algorithm: rsaEncryption
```

```
Public-Key: (2048 bit)
```

```
Modulus:
```

```
00:cf:7b:9b:49:a8:77:dc:00:a4:0b:4a:6a:cc:5f:
```

```
53:51:8a:c2:71:e0:e1:c2:81:15:fd:5a:e9:ee:bb:
```

```
cf:fd:28:72:dc:f2:5a:3b:2b:5e:00:23:bb:4e:f9:
```

```
ab:c3:bf:5d:c7:7f:46:37:b0:33:a5:30:19:01:df:
```

```
db:2d:f7:72:6e:2f:9f:94:e6:49:83:33:71:e0:5c:
```

```
09:71:4a:00:1f:65:53:a5:9a:c8:8c:3d:bf:f7:ac:
```

```
d0:be:4e:0d:9a:c1:58:9a:17:43:10:59:ef:15:35:
```

```
66:09:54:84:d5:0e:42:43:0b:99:11:99:44:89:ca:
```

```
16:9c:70:03:bb:25:85:63:eb:29:7a:4e:8a:27:e7:
```

```
ac:0b:4e:a8:67:d6:3d:c7:89:a9:b9:74:9a:68:f1:
```

```
47:c1:85:09:a5:c8:b6:66:20:a2:51:8e:fe:5a:a5:
```

```
53:b2:42:7c:be:53:56:86:77:2e:ed:94:65:a8:ee:
```

```
f6:bc:01:53:9b:25:91:12:be:68:05:c1:04:0d:69:
```

```
44:91:d1:13:5b:42:db:a4:f8:38:f3:b2:92:9d:6e:
```

```
2b:02:e9:a8:c0:16:21:af:51:3b:39:3b:97:c0:52:
```

```
20:e1:c7:bd:c4:02:4e:eb:87:55:a8:5c:51:be:70:
```

```
9d:5e:52:fe:8f:3c:fa:9c:03:89:90:26:7a:d5:8f:
```

```
a2:ad
```

```
Exponent: 65537 (0x10001)
```

```
Signature Algorithm: sha256WithRSAEncryption
```

```
c3:91:3a:bc:ec:82:ac:a9:27:08:26:3d:9e:cc:ed:12:2b:bd:
```

```
73:d1:ea:7b:f9:93:48:c9:2b:5a:4d:58:71:87:a6:9a:8f:ca:
```

```
74:d1:d3:a6:92:7e:f9:b8:ff:54:6e:29:93:53:b3:b8:76:e2:
```

```
f7:39:6a:0e:f9:fc:a0:9f:91:a8:8f:b4:65:ff:c4:3f:2e:b5:
5c:fd:f1:a9:2e:93:b3:41:e8:a8:2d:da:b3:1f:d4:c2:29:62:
a6:e5:0d:9e:87:fd:71:8a:f3:13:31:3c:5b:e1:1b:0d:db:4a:
6c:d9:47:21:b4:0a:b3:e6:d5:5f:d1:77:c7:42:e1:c0:54:93:
d4:ca:85:f7:40:db:6e:5f:39:4e:03:8b:60:e9:7c:94:7a:d8:
3e:62:7f:23:02:44:f7:58:2d:b2:a7:ae:33:48:96:8d:8b:ff:
b0:b1:e7:55:41:a4:40:3a:2e:f0:9a:02:d5:8a:e3:ea:74:e7:
1e:66:48:d6:99:a5:8a:fb:0f:a4:8f:05:d2:89:33:67:2f:7b:
2c:be:9f:0e:21:f9:6b:2c:86:22:77:68:d9:1a:62:55:28:ea:
92:39:b3:58:9a:68:17:25:05:a8:ee:57:8b:ca:45:3a:ae:5a:
f2:f2:09:0a:ea:1f:42:ff:04:86:21:5f:f0:28:9d:d3:69:fc:
7d:f6:64:77
```

Command Result : 0 (Success)

ntls information

Access commands that allow you to display information about the NTLS connection or reset the NTLS counters.

Syntax

ntls information

reset
show

Argument(s)	Shortcut	Description
reset	r	Reset the NTLS counters. See "ntls information reset" on the next page .
show	s	Display NTLS information. See "ntls information show" on page 255 .

ntls information reset

Reset the NTLS counters.

NOTE Resetting counters produces what is known as a "counter discontinuity" in the SNMP agent. The use of this functionality is therefore discouraged. Counter discontinuities may result in SNMP management applications recording large false positive or negative spikes if rates are being monitored using delta methods. If you are not using SNMP, then this is not an issue.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls information reset

Example

```
lunash:>ntls information reset
```

```
Command Result : 0 (Success)
```

ntls information show

Display information about the NTLS connection. The following information is displayed:

Operational Status	An unsigned 32-bit integer that indicates the status of the NTLS connection. The status is reported as follows. Note that this value will generally agree with the output of the service status ntls command: up: The NTLS service appears to be running OK. (Should be "up" when front panel LED is green.) down: the NTLS service appears not to be running. This could indicate a fault or that NTLS is not started yet, or has been purposely disabled with (for example) service stop ntls or that there is a software upgrade in progress. unknown: The NTLS service status cannot be determined.
Connected Clients	An unsigned 32-bit integer that indicates the current number of clients using the NTLS connection.
Links	An unsigned 32-bit integer that indicates the current number of links on the NTLS connection.
Successful Client Connections	A 64-bit integer counter that indicates the number of client sessions that have successfully connected to the HSM using the NTLS connection. This value can be reset using the ntls information reset command.
Failed Client Connections	A 64-bit integer counter that indicates the number of client sessions that did not successfully connect to the HSM using the NTLS connection. This value can be reset using the ntls information reset command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls information show

Example

```
lunash:>ntls information show
```

```
NTLS Information:
  Operational Status:          1 (up)
  Connected Clients:          2
  Links:                       2
  Successful Client Connections: 112
  Failed Client Connections:   1
```

ntls ipcheck

Access commands that allow you to enable, disable or view the configuration of NTLS client source IP validation.

Syntax

ntls ipcheck

disable
enable
show

Argument(s)	Shortcut	Description
disable	d	Disable NTLS client source IP validation. See " ntls ipcheck disable " on the next page.
enable	e	Enable NTLS client source IP validation. See " ntls ipcheck enable " on page 258.
show	s	Display the current client source IP validation configuration. See " ntls ipcheck show " on page 259.

ntls ipcheck disable

Disable client source IP address validation by NTLS upon an NTLA client connection. Use this command, for example, when you have network address translation (NAT) between your client(s) and the SafeNet Luna Network HSM appliance. The checking is enabled by default.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls ipcheck disable

Example

```
lunash:>ntls ipcheck disable
```

```
NTLS client source IP validation disabled
```

```
Command Result : 0 (Success)
```

ntls ipcheck enable

Enable client source IP address validation by NTLS upon an NTLA client connection. The checking is enabled by default. The best security of your client-to-SA link is in force when ipcheck remains enabled. Keep it enabled if you do not have network address translation (NAT) between your client(s) and the SafeNet Luna Network HSM appliance, or other situations where the ipcheck interferes with operation.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls ipcheck enable

Example

```
lunash:>ntls ipcheck enable
```

```
NTLS client source IP validation enabled
```

```
Command Result : 0 (Success)
```

ntls ipcheck show

Display the current NTLS Client source IP validation configuration.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls ipcheck show

Example

```
lunash:>ntls ipcheck show
```

```
NTLS client source IP validation : Enable
```

```
Command Result : 0 (Success)
```

ntls show

You can bind the NTLS traffic to a specific device on the appliance. Use this command to display the following information for the NTLS binding:

- > the network device that is configured to bind the NTLS traffic.
- > the network device that is currently being used to bind the NTLS traffic.

Use the command ["ntls bind" on page 243](#) to configure NTLS binding. The device you configure using the ["ntls bind" on page 243](#) is not used until the following conditions have been met:

- > it has been configured with a valid IP address.
- > it is active on the network.
- > the NTLS service is restarted.

This allows you to preconfigure the NTLS binding and have it become active only after you have completed your network configuration.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls show

Example

NTLS bound to a configured, active interface

```
lunash:>ntls show
```

```
NTLS is currently bound to IP Address: "192.20.11.78" (eth0)
```

```
Command Result : 0 (Success)
```

NTLS is bound to an inactive interface, or has not been restarted

```
lunash:>ntls show
```

```
NTLS is configured to bind to eth1, but it is not active at this time.  
NTLS will bind to eth1 if it's active and has a valid IP address when NTLS restarts.  
NTLS is currently bound to IP Address: "192.20.11.78" (eth0)
```

```
Command Result : 0 (Success)
```

ntls tcp_keepalive

Access commands that allow you to view or configure the NTLS TCP keep alive settings.

Syntax

ntls tcp_keepalive

set
show

Argument(s)	Shortcut	Description
set	-se	Configure the NTLS TCP keep alive settings. See " ntls tcp_keepalive set " on the next page.
show	-sh	Display the current NTLS TCP keep alive configuration. See " ntls tcp_keepalive show " on page 264.

ntls tcp_keepalive set

Configure the NTLS TCP keep alive settings.

TCPKeepAlive is a TCP stack option, available at the LunaClient, and at the SafeNet Luna Network HSM appliance. For SafeNet purposes, it is controlled via an entry in the Chrystoki.conf /crystoki.ini file on the LunaClient, and in an equivalent file on SafeNet Luna Network HSM. For SafeNet Luna HSM 6.1 and newer, a fresh client software installation includes an entry "TCPKeepAlive=1" in the "LunaSA Client" section of the configuration file Chrystoki.conf (Linux/UNIX) or crystoki.ini (Windows). Config files and certificates are normally preserved through an uninstall, unless you explicitly delete them.

As such, if you update (install) LunaClient software where you previously had an older LunaClient that did not have a TCPKeepAlive entry, one is added and set to "1" (enabled), by default. In the case of update, if TCPKeepAlive is already defined in the configuration file, then your existing setting (enabled or disabled) is preserved.

On the SafeNet Luna Network HSM appliance, where you do not have direct access to the file system, the TCPKeepAlive= setting is controlled by the LunaSH command **ntls tcp_keepalive set**.

The settings at the appliance and the client are independent. This allows a level of assurance, in case (for example) a firewall setting blocks in one direction.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls tcp_keepalive set -idle <seconds> -interval <seconds> -probes <number>

Argument(s)	Shortcut	Description
-idle <seconds>	-id	Specifies the TCP keep alive idle timer, in seconds. This is the initial wait until a keep alive is issued. Recommended value is 200. Range: 10 to 10,000 Default: 10
-interval <seconds>	-in	Specifies the TCP keep alive interval time, in seconds. This is the duration between any two successive keep alive transmissions. Recommended value is 150. Range: 10 to 360 Default: 10

Argument(s)	Shortcut	Description
-probes <number>	-p	Specifies the number of retries to attempt if a transmission is not acknowledged. Recommended value is 15. Range: 1 to 30 Default: 2

NOTE The default values are simply starting points intended to keep the feature "out of the way" until you configure for your particular network conditions. The recommended values are conservative, and address a common situation where a flurry of network activity might allow the probe count to be reached before the acknowledgment packets are able to return to the HSM appliance, which would cause the appliance to reset the connection.

Example

```
lunash:>ntls tcp_keepalive set -idle 200 -interval 150 -probes 15
```

NOTICE: The NTLS service must be restarted for new settings to take effect.

Command Result : 0 (Success)

ntls tcp_keepalive show

Display the NTLS TCP keep alive configuration.

TCPKeepAlive is a TCP stack option, available at the LunaClient, and at the SafeNet Luna Network HSM appliance. For SafeNet purposes, it is controlled via an entry in the Chrystoki.conf /crystoki.ini file on the LunaClient, and in an equivalent file on SafeNet Luna Network HSM. For SafeNet Luna HSM 6.1 and newer, a fresh client software installation includes an entry "TCPKeepAlive=1" in the "LunaSA Client" section of the configuration file Chrystoki.conf (Linux/UNIX) or crystoki.ini (Windows). Config files and certificates are normally preserved through an uninstall, unless you explicitly delete them. As such, if you update (install) LunaClient software where you previously had an older LunaClient that did not have a TCPKeepAlive entry, one is added and set to "1" (enabled), by default. In the case of update, if TCPKeepAlive is already defined in the configuration file, then your existing setting (enabled or disabled) is preserved.

On the SafeNet Luna Network HSM appliance, where you do not have direct access to the file system, the TCPKeepAlive= setting is controlled by the LunaSH command **ntls tcp_keepalive set**.

The settings at the appliance and the client are independent. This allows a level of assurance, in case (for example) a firewall setting blocks in one direction.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls tcp_keepalive show

Example

```
lunash:>ntls tcp_keepalive show
```

```
NTLS TCP keepalive is configured as follows :
```

```
TCP_KEEPIDLE   : 200
TCP_KEEPINTVL  : 150
TCP_KEEPCNT    : 15
```

```
Command Result : 0 (Success)
```


ntls threads

Access commands that allow you to view or configure the NTLS worker threads settings.

Syntax

ntls threads

set
show

Argument(s)	Shortcut	Description
set	se	Configure the NTLS Datapath, CMD processor, and I/O service worker threads. See " ntls threads set " on the next page.
show	sh	Show the NTLS worker thread settings. See " ntls threads show " on page 268.

ntls threads set

Configure the datapath and command processor threads for the NTLS service.

NOTE You must configure each member of an HA group to use the same settings. Failure to do so may result in unexpected behavior.

Determining the optimal number of threads for your environment and use cases

The default settings provide optimal performance for the majority of use cases. Increasing the number of threads does not necessarily increase throughput. The higher the number, the more task switching occurs within the process - this is the major trade-off that limits the number of threads that can provide optimum performance.

If you experience performance or latency issues, you may need to experiment with different settings to determine the combination that provides the best performance and latency figures in your environment. It is recommended that you do not change these settings without first consulting with Gemalto Support.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls threads set [-datapath <number>] [-cmdprocessor <number>]

Argument(s)	Shortcut	Description
-cmdprocessor <number>	-c	Specifies the number of threads used in the command processor to submit HSM requests to the HSM key card inside the appliance. The default value provides optimal performance for the majority of applications. Changing this value from the default may result in lower maximum throughput of some crypto operations, such as RSA Sign. Range: 1 to 70 Default: 20
-datapath <number>	-d	Specifies the number of worker thread pairs used to process inbound and outbound socket events. In practical terms, this value specifies the number of different NTLS clients, from different sockets, that the data path can support in parallel. You may need to increase this value if NTLS must service a high number of client connections. Range: 1 to 15 Default: 5

Example

```
lunash:>ntls threads set -cmdprocessor 40 -datapath 10
```

NOTICE: The NTLS and STCD services must be restarted for new settings to take effect.

```
Command Result : 0 (Success)
```

ntls threads show

Display the configured number of NTLS worker threads that can run simultaneously.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls threads show

Example

```
lunash:>ntls threads show
```

```
Data path      : 10 threads  
CMD processor  : 40 threads
```

```
Command Result : 0 (Success)
```

ntls timer

Access commands that allow you to view or configure the NTLS receive timeout setting.

Syntax

ntls timer

set
show

Argument(s)	Shortcut	Description
set	se	Configure the NTLS receive timeout value. See "ntls timer set" on the next page .
show	sh	Display the NTLS receive timeout value. See "ntls timer show" on page 271 .

ntls timer set

Set the number of seconds that NTLS will wait before kicking out an unauthorized connection to port 1792. Default 20 secs. Setting this parameter does not require an NTLS restart.

This command must be set individually and manually on all members of an HA group. Mixing settings across group members is untested and unsupported.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

ntls timer set -timeout <seconds>

Argument(s)	Shortcut	Description
-timeout <seconds>	-t	Specifies the timeout, in seconds. Range: 10 to 300 Default: 20

Example

```
lunash:>ntls timer set -timeout 30
```

```
Command Result : 0 (Success)
```

ntls timer show

Display the configured NTLS timeout period.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

ntls timer show

Example

```
lunash:>ntls timer show
```

```
NTLS Receive timeout timer is set to default at 20 seconds.
```

```
Command Result : 0 (Success)
```

package

Access commands that allow you to manage secure package updates. Use these commands after you have copied the package files to the SafeNet Luna Network HSM, using the **scp** utility.

Syntax

package

deletefile
erase
list
listfile
update
verify

Argument(s)	Shortcut	Description
deletefile	d	Delete a package file. See "package deletefile" on the next page .
erase	e	Delete a package . See "package erase" on page 274 .
list	l	List the installed packages. See "package list" on page 275 .
listfile	listf	List the uninstalled package files. See "package listfile" on page 276 .
update	u	Update the package file. See "package update" on page 277 .
verify	v	Verify the package file. See "package verify" on page 279 .

package deletefile

Deletes a named package file from the SafeNet appliance.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

package deletefile <package_name>

Argument(s)	Description
<package_name>	Specifies the name of the package you want to delete.

Example

```
lunash:>package deletefile lunacuf_update-1.0.0-1.testCert.spkg
```

```
Command Result : 0 (Success)
```

package erase

Erase the specified package. This command attempts to erase/uninstall the specified package from the SafeNet appliance. Package erase will not work if other packages are dependent upon the specified package. Only packages marked as “SOFTWARE” can be erased.

CAUTION! This command should never be used without the assistance or at the direction of Thales Group Technical Support staff.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

package erase <package_name>

Argument(s)	Description
<package_name>	Specifies the name of the package to erase. For a list of package names, use the package list command. (Do not specify version numbers of packages. For example, for package_abc.1.0.2-0, specify only package_abc).

Example

Please contact Thales Group Technical Support for an example of this command.

package list

Display the list of all installed packages on the system. Packages are divided into system packages (cannot be erased) and software packages.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

package list

Example

```
lunash:>package list
```

```
RPM LIST (SYSTEM)
-----
libestr-0.1.9-2.el7.x86_64
centos-release-7-2.1511.el7.centos.2.10.x86_64
kernel-3.10.0-327.36.3.el7.x86_64
filesystem-3.2-20.el7.x86_64
NetworkManager-1.0.6-31.el7_2.x86_64
langtable-0.0.31-3.el7.noarch
pciutils-3.2.1-4.el7.x86_64
basesystem-10.0-7.el7.centos.noarch

... (clip) ...

glib-networking-2.42.0-1.el7.x86_64
hwdata-0.252-8.1.el7.x86_64
json-c-0.11-4.el7_0.x86_64
```

```
RPM LIST (SOFTWARE)
-----
```

```
Command Result : 0 (Success)
```

package listfile

Displays a list of package files that have been transferred to the SafeNet Luna Network HSM and are available to install.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

package listfile

Example

```
lunash:>package listfile
```

```
    10562  Mar 15 2017 10:18 lunacuf_update-1.0.0-1.testCert.spkg
    82028450 Mar 15 2017 10:52 lunasa_update-7.0.0-2.x86_64.rpm.spkg
    82348418 Mar 15 2017 16:53 lunasa_update-7.0.0-4.spkg
```

```
Command Result : 0 (Success)
```

package update

Update an existing secure package on the SafeNet appliance. All packages from Thales Group are signed and encrypted and come with an authcode that must be provided to decrypt and use the package. Use this command to update packages that can be seen when using the **package listfile** command. You can verify a package with the **package verify** command.

CAUTION! Use an uninterruptible power supply (UPS) to power your HSM. There is a small chance that a power failure during an update could leave your HSM in an unrecoverable condition.

If a version of this package is already installed, an error occurs:

```
Command failed: RPM update for original filename (fwupdateK7_RealCert-7.0.2-RC2.i386.rpm)
```

NOTE You must log into the HSM before you run this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

package update <filename> **-authcode** <authcode> [**-des3** | **-useevp**] [**-force**]

Argument(s)	Shortcut	Description
<filename>		The name of the update package file.
-authcode <authcode>	-a	Specifies the secure package authorization code provided by SafeNet with the secure package - the authorization code is checked during package installation to ensure that the package was encrypted and signed by Thales Group.
-des3	-d	Use DES3 Cipher for backward compatibility with older secure package updates (cannot be used simultaneously with -useevp).
-force	-f	Force the action - useful when scripting; this option causes the command to proceed without confirmation.
-useevp	-u	Use the OpenSSL EVP (Digital EnVeloPe library) API to decrypt and validate the update package in appliance software without need for HSM SO login. If this option is not specified, the default action is to refer update verification to the HSM (cannot be used simultaneously with -des3).

Example

```
lunash:>package update lunasa_update-7.1.0-380.spkg -authcode 5/Rd79MAGd/G9EY5
```

```
WARNING!! Appliance software upgrade is a one-way operation: you
cannot downgrade the appliance software.
```

```
If you are sure that you wish to proceed, type 'proceed', otherwise type 'quit'. >proceed
```

```
Command succeeded: decrypt package
```

```
Command succeeded: verify package certificate
```

```
Command succeeded: verify package signature
```

```
Preparing packages...
```

```
lunasa_update-7.1.0-380.x86_64
```

```
Running update script
```

```
Version file found.
```

```
Proceeding with upgrade.
```

```
BEGINNING UPDATE.....
```

```
    Updating to Luna SA Release 7.1.0-380
```

```
UNPACKING UPDATE FILES.....
```

```
VERIFYING SOFTWARE PACKAGES.....
```

```
1...Passed 2...Passed 3...Passed 4...Passed 5...Passed 6...Passed 7...Passed 8...Passed
9...Passed 10...Passed 11...Passed 12...Passed 13...Passed 14...Passed 15...Passed
16...Passed 17...Passed 18...Passed 19...Passed 20...Passed 21...Passed 22...Passed
23...Passed 24...Passed 25...Passed 26...Passed 27...Passed 28...Passed 29...Passed
30...Passed 31...Passed 32...Passed 33...Passed
```

```
INSTALLING SOFTWARE PACKAGES.....
```

```
1...Passed 2...Passed 3...Passed 4...Passed 5...Passed 6...Passed 7...Passed 8...Passed
9...Passed 10...Passed 11...Passed 12...Passed 13...Passed 14...Passed 15...Passed
16...Passed 17...Passed 18...Passed 19...Passed 20...Passed 21...Passed 22...Passed
23...Passed 24...Passed 25...Passed 26...Passed 27...Passed 28...Passed 29...Passed
30...Passed 31...Failed 32...Failed 33...Failed
```

```
CLEANING UP FILES.....
```

```
CLEANUP AFTER REMOVAL.....
```

```
SOFTWARE UPDATE COMPLETED!
```

```
The system MUST now be rebooted for the changes to take effect.
```

```
Please ensure all client connections are terminated prior to rebooting the system.
To reboot, use the command "sysconf appliance reboot".
```

```
Update Completed
```

```
Copied all update log files, current and previous
```

```
Command Result : 0 (Success)
```

package verify

Verifies that the specified package is from Thales Group, and that the provided authcode is correct.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

package verify <package_name> **-authcode** <authcode> [**-des3**] [**-useevp**]

Option	Shortcut	Description
<filename>	.	Verify the package file
-authcode <authcode>	-a	Specifies the secure package authorization code provided by SafeNet with the secure package
-des3	-d	Use DES3 Cipher
-useevp	-u	Use OpenSSL EVP API

Example

```
lunash:>package verify lunasa_update-7.1.0-380.spkg -authcode 5/Rd79MAGd/G9EY5
```

```
Command succeeded: decrypt package
```

```
Command succeeded: verify package certificate
```

```
Command succeeded: verify package signature
Preparing packages...
```

```
Command Result : 0 (Success)
```

partition

Access commands used to manage partitions on the HSM. These commands are used by the HSM SO to create, delete, or resize partitions on the HSM. The partitions are owned by the Partition SO, and configured using LunaCM.

Syntax

partition

backup
create
delete
list
rename
resize
restore
show

Argument(s)	Shortcut	Description
backup	b	Backup the contents of an HSM partition to a backup HSM. See "partition backup" on the next page .
create	c	Create an HSM partition on the HSM. See "partition create" on page 285 .
delete	d	Delete an HSM partition from the HSM. See "partition delete" on page 287 .
list	l	Display a list of the accessible partitions. See "partition list" on page 288 .
rename	ren	Renames the specified partition. See "partition rename" on page 289 .
resize	resi	Resizes the storage space for a partition. See "partition resize" on page 290 .
restore	rest	Restore the contents of an HSM partition from a backup HSM. See "partition restore" on page 292 .
show	s	Display information for a partition. See "partition show" on page 294 .

partition backup

Backup the HSM partition contents to a backup HSM. This command copies the contents of a HSM Partition to a special SafeNet backup token. The backup token is initialized during this process. The user is prompted to verify if this destructive command should continue (in case the token has any data on it).

The backup token is initialized to the same access control level as the HSM Partition being backed up.

This command requires the HSM's domain (string or PED Key) and the HSM Partition's Owner password (or PED Key and Partition password). If you chose MofN (values for N and for M greater than 1) at partition creation time, then quantity M of the black key are needed.

Because this is a destructive command (it initializes the backup token) , the user is given the option to proceed/quit before continuing. The SafeNet appliance admin may wish to use the **token show** command to see the label of a token before issuing this destructive command.

Password-authenticated HSMs

If the passwords and domain aren't provided via the command line, the user is interactively prompted for them. User input is echoed as asterisks. The user is asked to confirm new token Admin and user passwords (if needed).

PED-authenticated HSMs

SafeNet Luna Network HSM with Trusted Path Authentication backup tokens do not use text Partition Passwords in addition to PED Keys – they require only the PED Keys. Also, the passwords and blue/black PED Keys used for the backup token need not be the same as those used with the HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

```
partition backup -partition <name> -tokenpar <name> -serial <serialnum> [-password <password>] [-tokensopwd <password>] [-domain <domain>] [-defaultdomain] [-tokenpw <password>] [-add] [-replace] [-force]
```

Argument(s)	Shortcut	Description
-partition <partition_name>	-par	The name of the HSM partition from which all data/key objects are backed up. Obtain the HSM partition name by using the partition list command.

Argument(s)	Shortcut	Description
-tokenpar <backup_partition_name>	-tokenpa	This is the name of the partition on the backup HSM, to which the backup objects are to be cloned. If a partition exists on the backup HSM with the name that you provide, here, that partition is selected. If no partition exists with the supplied label, then one is created. Note: Do not begin your partition label with a numeral. This can later be misinterpreted by some commands as a slot number, rather than a text label, resulting in failure of the command.
-serial <serial_number>	-s	Specifies the backup token serial number.
-password <partition password>	-pas	The application partition Crypto Officer's text password to be used for login. If you do not supply this value on the command line, you are prompted for it. This parameter is mandatory for password-authenticated HSMs and PED-authenticated HSMs that have created a challenge for the Crypto Officer role. It is ignored for PED-authenticated HSMs that have not created a challenge for the Crypto Officer role.
-tokensopwd <backup_HSM_SO_pwd>	-tokens	Token Admin (or Security Officer) password. This is the password to be used as login credential for the Backup HSM's security officer. The token SO password need not be the same password or PED Key as used for the source HSM Admin.

Argument(s)	Shortcut	Description
-domain <domain>	-do	<p>Specifies the text domain string that was used when creating the partition. This parameter is optional on password-authenticated HSMs. It is ignored on PED-authenticated HSMs. See the notes, below, for more information.</p> <p>Note 1: For SafeNet Luna HSMs with Trusted Path Authentication, the red PED Key used for initializing the partition on the source HSM must be used for the backup HSM, as well. Ensure that a new domain is not created on the PED Key by answering NO to the Luna PED question “Do you wish to create a new domain?”.</p> <p>Note 2: When you call for a cloning operation (such as backup or restore), the source HSM transfers a single object, encrypted with the source domain. The target HSM then decrypts and verifies the received blob.</p> <p>If the verification is successful, the object is stored at its destination – the domains are a match. If the verification fails, then the blob is discarded and the target HSM reports the failure. Most likely the domain string or the domain PED Key, that you used when creating the target partition, did not match the domain of the source HSM partition. The source HSM moves to the next item in the object list and attempts to clone again, until the end of the list is reached.</p> <p>This means that if you issue a backup command for a source partition containing several objects, but have a mismatch of domains between your source HSM partition and the backup HSM partition, then you will see a separate error message for every object on the source partition as it individually fails verification at the target HSM.</p> <p>Note 3: If you do not specify a domain in the command line when creating a partition (partition create command), then you are prompted for it.</p> <p>The character string that you type at the prompt becomes the domain for the partition.</p> <p>When you run the partition backup command, you are again prompted for a domain for the target partition on the backup HSM. You can specify a string at the command line, or omit the parameter at the command line and specify a string when prompted. The domain that you apply to a backup HSM must match the domain on your source HSM partition.</p>
-defaultdomain	-de	<p>Use the default domain string. Deprecated. This is retained only for benefit of customers who have previously used the default domain, and are constrained to continue using it, until they create new objects on an HSM with a proper domain. For security reasons, avoid using this option.</p>

Argument(s)	Shortcut	Description
-tokenpw <backup_partition_password>	-tokenpw	The token user password . This is the equivalent of Crypto Officer password for the backup partition on the Backup HSM. This parameter is mandatory for password-authenticated HSMs. It is ignored for PED-authenticated HSMs.
-add	-a	Add objects to the named backup HSM partition. Incremental backup (append). If any of the source objects already exist on the target partition, they are not duplicated, and they are not overwritten. The system flags an error and continues to the next object. This parameter is mandatory for pre-existing target partitions, if -replace is not specified. Note: This parameter is not needed if the target partition did not already exist and is being created by the partition backup command. If the target partition exists, then there is no default - you must specify whether to add/append to whatever exists on the partition, or overwrite it.
-replace	-r	Clone objects to the target partition, overwriting whatever might already exist there. This parameter is mandatory for pre-existing target partitions, if -add is not specified. Note: This parameter is not needed if the target partition did not already exist and is being created by the partition backup command. If the target partition exists, then there is no default - you must specify whether to add/append to whatever exists on the partition, or overwrite it.
-force	-f	Force the action without prompting.

Example

```
lunash:>partition backup -partition sa78par1 -tokenpar sa78par1backup -serial 496771
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Please enter a password for the user on the backup token:
```

```
> *****
```

```
Please enter the cloning domain set when the HSM user partition was created:
```

```
> *****
```

```
Object "MT RSA 4096-bit Private KeyGen" (handle 70) cloned to handle 14 on target
Object "MT RSA 4096-bit Public KeyGen" (handle 69) cloned to handle 18 on target
Object "MT RSA 4096-bit Private KeyGen" (handle 53) cloned to handle 19 on target
Object "MT RSA 4096-bit Public KeyGen" (handle 54) cloned to handle 23 on target
Object "MT RSA 4096-bit Private KeyGen" (handle 52) cloned to handle 24 on target
Object "MT RSA 4096-bit Public KeyGen" (handle 47) cloned to handle 28 on target
'partition backup' successful.
```

```
Command Result : 0 (Success)
```

partition create

Create an HSM partition on the HSM. This command creates a new HSM partition on the HSM. You must be logged in to the HSM as HSM SO to use this command.

Use the LunaCM **partition init** command to initialize the partition.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

partition create -partition <name> [-size <size>] [-allfreestorage] [-force]

Argument(s)	Shortcut	Description
-allfreestorage	-a	Create the partition using all the remaining unused storage space on the HSM. After you create a partition with this option, you cannot create another without first deleting or resizing partitions to regain some space.
-force	-f	Force the partition creation with no prompting - you are still prompted by Luna PED, if yours is a PED authenticated HSM.
-partition <name>	-pa	Specifies the name to assign to the HSM Partition. The name must be unique among all HSM Partitions on the HSM.
-size <size>	-s	Specifies the size, in bytes, to allocate to the partition, from the remaining storage available on the HSM. If you specify a size, the HSM attempts to use it after calculating overhead requirements. If you do not specify a size, the HSM creates the partition with the default size, as determined by your purchased options for number of partitions and total storage on the HSM.

Example

```
lunash:>partition create -partition partition1
```

```
    Type 'proceed' to create the partition, or
    'quit' to quit now.
    > proceed
```

```
'partition create' successful.
```

```
Command Result : 0 (Success)
```

```
lunash:>partition create -partition partition2 -size 400000
```

On completion, you will have 2 partition(s) with 32811040 bytes remaining for up to 98 more partitions.

```
    Type 'proceed' to create the partition, or  
    'quit' to quit now.
```

```
    > proceed
```

```
'partition create' successful.
```

```
Command Result : 0 (Success)
```

partition delete

Delete an HSM Partition from the HSM. This command deletes a HSM Partition on the HSM and frees the license used by the HSM Partition. To use the **partition delete** command you must be logged in to the HSM as HSM Admin.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

partition delete -partition <partition_name> [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-partition <partition_name>	-p	The name of the HSM partition to deactivate. Obtain the HSM partition name by using the partition list command.

Example

```
lunash:>partition delete -partition partition2
```

```
CAUTION: Are you sure you wish to delete the partition named:
          partition2
          Type 'proceed' to delete the partition, or 'quit'
          to quit now.
          > proceed
'partition delete' successful.
```

```
Command Result : 0 (Success)
```

partition list

Display a list of the accessible partitions on the HSM, including the number of objects on the partition, the partition size, and the used and free space.

NOTE The HSM firmware needs approximately 2K bytes of memory to manage each partition and data objects in it. To avoid you having to calculate the exact memory space available for data storage -- with you deducting the memory used by internal data structures -- the **partition list** command adjusts the memory size attributes for you. Thus, the total available memory reported by **partition list** will be different than that reported by **token backup show** and **token backup partition list**.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

partition list

Example

```
lunash:>partition list
```

Partition	Name	Objects	Storage (bytes)		
			Total	Used	Free
154438865289	partition1	6	150000	1232	148768
154438865290	partition2	0	325873	0	325873
154438865291	partition3	0	325891	0	325891
154438865292	partition4	0	325909	0	325909
154438865293	partition5	0	325928	0	325928

```
Command Result : 0 (Success)
```


partition rename

Renames the specified partition. This command does not affect the label set by the Partition SO during initialization.

You must be logged in as HSM SO to run this command.

NOTE This feature has software and/or firmware dependencies. See "[Version Dependencies by Feature](#)" on page 1 for more information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

partition rename -partition <name> -newname <name> [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting for confirmation.
-newname	-n	Specifies the new partition name. To include spaces in the partition name, enclose the new partition name in quotation marks.
-partition	-p	Specifies the current name of the partition to be renamed.

Example

```
lunash:>partition rename -partition parl -newname "user partition1"
```

CAUTION: Are you sure you wish to make the following changes to partition "parl"?:

```
Partition name:  user partition1
Partition label: no change
```

```
Type 'proceed' to change the partition name/label, or 'quit'
to quit now.
```

```
> proceed
```

```
Partition name successfully updated in the partition file list.
```

```
Partition name successfully updated in the Client Authenticate Configuration File.
```

```
'partition rename' successful.
```

```
Command Result : 0 (Success)
```

partition resize

Resizes the storage space of the named partition.

You must be logged into the HSM administrative partition to run this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

partition resize -partition <name> [-size <bytes>] [-allfreestorage] [-force]

Argument(s)	Shortcut	Description
-allfreestorage	-a	Resize this partition using all the remaining, unused storage space on the HSM. After creating or resizing a partition with this option, you cannot create another without first deleting or resizing partitions to regain some space.
-force	-f	Force the action without prompting.
-partition <name>	-p	Specifies the name of the partition.
-size <bytes>	-s	Specifies the size, in bytes, to allocate to the partition, from the remaining storage available on the HSM. If you specify a size (rather than the other option, -allfreestorage), the HSM attempts to use it after calculating overhead requirements that consider your purchased options for number of partitions and total storage remaining on the HSM.

Example

```
lunash:>partition show
```

```
Partition Name:                partition1
Partition SN:                  154438865289
Partition Label:               jon
Partition SO   PIN To Be Changed:  no
Partition SO   Zeroized:          no
Partition SO   Login Attempts Left: 10
Crypto Officer PIN To Be Changed:  no
Crypto Officer Locked Out:        no
Crypto Officer Login Attempts Left: 10
Crypto User    PIN To Be Changed:  no
Crypto User    Locked Out:         no
Crypto User    Login Attempts Left: 10
Legacy Domain Has Been Set:     no
Partition Storage Information (Bytes): Total=324096, Used=1232, Free=322864
```

```
Partition Object Count:                6

Command Result : 0 (Success)

lunash:>partition resize -partition partition1 -size 150000

'partition resize' successful.

Command Result : 0 (Success)

lunash:>partition show

Partition Name:                partition1
Partition SN:                  154438865289
Partition Label:               jon
Partition SO      PIN To Be Changed:  no
Partition SO      Zeroized:          no
Partition SO      Login Attempts Left: 10
Crypto Officer   PIN To Be Changed:  no
Crypto Officer   Locked Out:         no
Crypto Officer   Login Attempts Left: 10
Crypto User      PIN To Be Changed:  no
Crypto User      Locked Out:         no
Crypto User      Login Attempts Left: 10
Legacy Domain Has Been Set:     no
Partition Storage Information (Bytes): Total=150000, Used=1232, Free=148768
Partition Object Count:        6

Command Result : 0 (Success)
```

partition restore

Restores the contents of an HSM partition from a backup token. This command securely moves contents from a backup token to an HSM partition on the HSM. The SafeNet Luna Network HSM administrator executing this command has the option of replacing the objects existing on the HSM partition or adding to them. Note that if objects are added to the HSM partition it is possible that the same object may exist twice on the HSM partition with two different object handles.

Because replacing data in a partition is destructive, if this option is selected the user is prompted to proceed/quit.

If the passwords are not provided via the command line, the user is prompted for them interactively. User input is echoed as asterisks.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

partition restore -partition <name> -tokenpar <name> -serial <serialnum> {-add | -replace} [-password <password>] [-tokenpw <password>] [-force]

Argument(s)	Shortcut	Description
-add	-a	Use this switch (no argument) to specify that the data objects on the backup token shall be added to those already existing on the specified HSM Partition. Note that even objects on the backup token that are identical to objects in the HSM Partition will be added to the HSM Partition when specifying this switch; thus it is possible that the HSM Partition may have two identical objects on it as a result of this command. You must specify either -add or -replace .
-force	-f	Force the action without prompting.
-partition <name>	-par	Specifies the name of the HSM partition from which all data/key objects are to be restored. Obtain the HSM partition name by using the partition -list command.
-password <password>	-pas	Specifies the HSM Partition Owner's (or Crypto Officer's) text password. This parameter is mandatory for password-authenticated HSMs. It is ignored on PED-authenticated HSMs.

Argument(s)	Shortcut	Description
-replace	-r	Use this switch (no argument) to erase any data/key objects existing on the specified HSM Partition before loading the keys from the backup token. You must specify either -add or -replace .
-serial <serialnum>	-s	Specifies the token serial number.
-tokenpar <name>	-tokenpa	Specifies the token partition name.
-tokenpw <password>	-tokenpw	The password for the user on the backup token. If this is a Secure Authentication & Access Control token, then Luna PED is required and any value provided here is ignored. If you do not enter this parameter you will be prompted for it. This parameter is mandatory for password-authenticated HSMs. It is ignored on PED-authenticated HSMs.

Example

```
lunash:>partition restore -partition sa78par1 -tokenpar sa78par1backup -size 496771 -add
```

```
Please enter the password for the token user partition:
```

```
> *****
```

```
Please enter the password for the HSM user partition:
```

```
> *****
```

```
Object "MT RSA 4096-bit Private KeyGen" (handle 14) cloned to handle 46 on target
Object "MT RSA 4096-bit Public KeyGen" (handle 18) cloned to handle 49 on target
Object "MT RSA 4096-bit Private KeyGen" (handle 19) cloned to handle 52 on target
Object "MT RSA 4096-bit Public KeyGen" (handle 23) cloned to handle 48 on target
Object "MT RSA 4096-bit Private KeyGen" (handle 24) cloned to handle 57 on target
Object "MT RSA 4096-bit Public KeyGen" (handle 28) cloned to handle 70 on target
'partition restore' successful.
```

```
Command Result : 0 (Success)
```

partition show

Display a detailed list of accessible partitions with relevant information. This command outputs information about one or all partitions on the SafeNet appliance's key card (the HSM). It is not necessary to be logged in as HSM Admin to execute this command.

For each partition that is present, the following information is displayed:

- > Partition serial number
- > Partition name
- > Primary authentication status (activated or not)
- > Partition auto-authenticate status
- > User lock-out status
- > HSM serial number
- > HSM label
- > HSM firmware version

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

partition show [-partition <partition_name>] [-all]

Argument(s)	Shortcut	Description
-partition <partitionname>	-p	Specifies the name of the partition for which to display information. By default information about all partitions is shown. Obtain the partition name by using the partition list command.
-all	-a	All partitions

Example

```
lunash:>partition show
```

```
Partition Name:                partition1
Partition SN:                  154438865289
Partition Label:               jon
Partition SO      PIN To Be Changed:  no
Partition SO      Zeroized:          no
Partition SO      Login Attempts Left: 10
Crypto Officer    PIN To Be Changed:  no
```

```
Crypto Officer   Locked Out:           no
Crypto Officer  Login Attempts Left: 10
Crypto User     PIN To Be Changed:    no
Crypto User     Locked Out:           no
Crypto User     Login Attempts Left: 10
Legacy Domain Has Been Set: no
Partition Storage Information (Bytes): Total=324096, Used=1232, Free=322864
Partition Object Count: 6
```

Command Result : 0 (Success)

service

Access commands that allow you to view or manage services.

Syntax

service

list
restart
start
status
stop

Argument(s)	Shortcut	Description
list	l	Display a list of the services. See "service list" on the next page .
restart	r	Restart a service. See "service restart" on page 298 .
start	star	Start a service. See "service start" on page 300 .
status	stat	Display the status for a service. See "service status" on page 301 .
stop	sto	Stop a service. See "service stop" on page 302 .

service list

Lists the services that the user can start, stop, restart, or for which the user can request status information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

service list

Example

```
lunash:>service list
```

The following are valid luna SA service names:

```
cbs          - HSM callback service
lsta         - Luna SNMP trap agent service
network     - Network service (Needed for ntlm, ssh and scp)
ntlm        - Network trust link service
ntp         - Network time protocol service
snmp        - SNMP agent service
ssh         - Secure shell service (Needed for ssh and scp)
stc         - Secure trusted channel service
syslog      - Syslog service
sysstat     - System status monitoring (controls LCD)
webserver   - REST API service
```

```
Command Result : 0 (Success)
```

service restart

Restart a service on the SafeNet appliance. Services require restarting if their configurations have changed. For example, after changing any network settings using the **network** commands, you should restart the network service to ensure the new settings take affect. Also, after regenerating the server certificate with the **sysconf regencert** command, you must restart the NTLS service so that the new certificate is used for the NTLA. For a list of services that can be restarted, use the **service list** command.

Restarting a service isn't always the same as doing a service stop followed by a service start. If you restart the network service while connected to the SafeNet appliance via the network (SSH), you will not lose your connection (assuming no changes were made that would cause a connection loss). However, if you were to stop the network service, you would immediately lose your connection, and you would need to log in via the local console to start the service again. The same applies for the sshd service.

NOTE It can sometimes take slightly more than a minute for NTLS to fully restart, depending on where the system was in its normal cycle of operation when you initiated the restart. This is relatively rare, with the usual NTLS restart time being on the order of ten seconds. We mention it here in case you notice an entry like **vtspd: Error: Server Listening Port could not Bind** in the logs. One or more occurrences can be normal behavior unless there is no recovery and no successful restart.

NOTE **service restart sysstat** also restarts the ["Front-panel LCD Display" on page 1](#).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

service restart <service_name> [-force]

Argument(s)	Shortcut	Description
<service_name>		Specifies the service to restart. Valid values: cbs, lsta, network, ntlis, ntp, snmp, ssh, stc, syslog, sysstat, webserver
-force	-f	Force the action without prompting.

Example

```
lunash:>service restart syslog
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

Command Result : 0 (Success)

```
lunash:>service restart ntl
```

Checking for connected clients before stopping NTLS service:

WARNING !! There are 1 client(s) connected to this Luna SA appliance. It is recommended that you disconnect all clients before stopping or restarting the NTLS service.

If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'

> proceed

Proceeding...

Stopping ntl: [OK]

Starting ntl: [OK]

Command Result : 0 (Success)

service start

Start a named service on the SafeNet appliance. Services usually need to be started only if they were stopped with a service stop command, or if the service stopped unexpectedly.

Use the **service list** command to display a list of services that you can stop.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

service start <service_name>

Argument(s)	Description
<service_name>	Specifies the service to start. Valid values: cbs,lsta,network,ntls,ntp,snmp,ssh,stc,syslog,sysstat,webserver

Example

```
lunash:>service start syslog
```

```
Starting syslog: [ OK ]
```

```
Command Result : 0 (Success)
```

service status

Display the current status (running/stopped) for the specified service. You may wish to run this command to ensure that specific services are running properly. For example, if troubleshooting a problem with the NTLA, it is wise to ensure that the NTLS service is properly started. If it is not, the server may not be able to resolve itself by the hostname in the server certificate.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

service status <service_name>

Argument(s)	Description
<service_name>	Specifies the service for which you want to display the status. Valid values: cbs, lsta, network, ntlis, ntp, snmp, ssh, stc, syslog, sysstat, webserver

Example

```
lunash:>service status network
```

```
eth0 is up
eth1 is down
eth2 is down
eth3 is down
bond0 is down
bond1 is down
```

```
Command Result : 0 (Success)
```

service stop

Stop a service on the SafeNet appliance. Customer support might ask you to stop a particular service. Or, you may wish to control which functions are available on the SafeNet appliance. For example, if you are performing maintenance and prefer that nobody be able to use the NTLA to connect to the SafeNet Luna Network HSM, you can stop the NTLS service. A user performing maintenance via the serial port can stop the SSH service to prevent anyone from accessing the SafeNet appliance.

Use the **service list** command to display a list of services that you can stop.

NOTE Issuing **service stop network** stops the network service. Stopping the network service stops all network traffic (SSH, NTLS, etc.), and any network commands issued thereafter will fail. You can start the network service using the **service start network** command from a serial port connection or by rebooting the appliance using the **sysconf appliance reboot** command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

service stop <servicename>

Argument(s)	Shortcut	Description
<service_name>		Specifies the service to stop. Valid values: cbs,lsta,network,ntls,ntp,snmp,ssh,stc,syslog,sysstat,webserver
-force	-f	Force the action without prompting.

Example

```
lunash:>service stop ntl
```

```
Checking for connected clients before stopping NTLS service:
```

```
There are no connected clients. Proceeding...
```

```
Stopping ntl: [ OK ]
```

```
Command Result : 0 (Success)
```

status

Access commands that allow you to view the current system status.

Syntax

status

cpu
date
disk
interface
handles
mac
mem
memmap
netstat
ps
sensors
sysstat
time
zone

Argument(s)	Shortcut	Description
cpu	c	Display the current CPU load. See "status cpu" on page 305 .
date	da	Display the current date and time. See "status date" on page 306 .
disk	di	Display the current disk usage. See "status disk" on page 307 .
handles	h	Display the open handle count for each process. See "status handles" on page 309 .
interface	i	Display the current network interface information. See "status interface" on page 311 .
mac	ma	Display the current MAC address configuration. See "status mac" on page 312 .
mem	me	Display the current memory usage. See "status mem" on page 313 .
memmap	memm	Display the Process Memory Map. See "status memmap" on page 314 .
netstat	n	Display the current network connections. See "status netstat" on page 315 .

Argument(s)	Shortcut	Description
ps	ps	Display the current status of processes. See " status ps " on page 317
sensors	se	Display the sensors output. See " status sensors " on page 318 .
sysstat	sy	Display system status monitor information. See " status sysstat " on page 321 .
time	t	Display the current time. See " status time " on page 325 .
zone	z	Display the current time zone. See " status zone " on page 326 .

status cpu

Display the current CPU load. The CPU load data is presented as a series of five entries, as follows:

1. The average CPU load for the previous minute. This value is 0.30 in the example below.
2. The average CPU load for the previous five minutes. This value is 0.22 in the example below.
3. The average CPU load for the previous ten minutes. This value is 0.18 in the example below.
4. The number of currently running processes and the total number of processes. The example below shows 2 of 325 processes running.
5. The last process ID used. This value is 27794 in the example below.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status cpu

Example

```
lunash:>status cpu
```

```
CPU Load Averages:  
0.30 0.22 0.18 2/365 27794
```

```
System uptime:  
At Wed Mar 1 09:24:11 EST 2017, I am up 17:24
```

```
Command Result : 0 (Success)
```

status date

Display the current date and time.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status date

Example

```
lunash:>status date
```

```
Wed Mar 1 09:27:45 EST 2017
```

```
Command Result : 0 (Success)
```

status disk

Display the current disk usage information from the SMART monitoring service.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status disk

Example

```
lunash:>status disk
```

```
===== Hard Disk utilization =====
Filesystem      1K-blocks    Used Available Use% Mounted on
/dev/sda5        8125880  108244   7581824   2% /
/dev/sda8        41153760 1159100   37881124   3% /usr
/dev/sda6        1998672    80204   1797228   5% /boot
/dev/sda12       57667680   53540   54661744   1% /home
/dev/sda9        3997376    86724   3684556   3% /var
/dev/sda7        3997376   118996   3652284   4% /tmp
/dev/sda10       1998672    6144    1871288   1% /var/tmp
/dev/sda13       231063860  61476  219241952   1% /var/audit
/dev/sda11       10190100   38916   9610512   1% /var/log
/dev/sda14       10190100   39160   9610268   1% /var/log/audit

===== Hard Disk SMART Report =====

=== START OF INFORMATION SECTION ===
Device Model:      HGST HUS726020ALE611
Serial Number:    N4G55WPS
LU WWN Device Id: 5 000cca 245c25bfa
Firmware Version: APGNV7J0
Copyright (C) 2002-13, Bruce Allen, Christian Franke, www.smartmontools.org

=== START OF READ SMART DATA SECTION ===
SMART overall-health self-assessment test result: PASSED

SMART Attributes Data Structure revision number: 16
Vendor Specific SMART Attributes with Thresholds:
ID# ATTRIBUTE_NAME          FLAG     VALUE WORST THRESH TYPE      UPDATED  WHEN_FAILED RAW_VALUE
  1 Raw_Read_Error_Rate     0x000b   100   100   016   Pre-fail Always    -         0
  2 Throughput_Performance  0x0005   136   136   054   Pre-fail Offline   -        108
  3 Spin_Up_Time            0x0007   131   131   024   Pre-fail Always    -        227
(Average 228)
  4 Start_Stop_Count       0x0012   100   100   000   Old_age  Always    -         14
  5 Reallocated_Sector_Ct   0x0033   100   100   005   Pre-fail Always    -         0
  7 Seek_Error_Rate         0x000b   100   100   067   Pre-fail Always    -         0
  8 Seek_Time_Performance   0x0005   128   128   020   Pre-fail Offline   -        18
```

9	Power_On_Hours	0x0012	100	100	000	Old_age	Always	-	4385
10	Spin_Retry_Count	0x0013	100	100	060	Pre-fail	Always	-	0
12	Power_Cycle_Count	0x0032	100	100	000	Old_age	Always	-	14
192	Power-Off_Retract_Count	0x0032	100	100	000	Old_age	Always	-	185
193	Load_Cycle_Count	0x0012	100	100	000	Old_age	Always	-	185
194	Temperature_Celsius	0x0002	206	206	000	Old_age	Always	-	29 (Min/Max 23/35)
196	Reallocated_Event_Count	0x0032	100	100	000	Old_age	Always	-	0
197	Current_Pending_Sector	0x0022	100	100	000	Old_age	Always	-	0
198	Offline_Uncorrectable	0x0008	100	100	000	Old_age	Offline	-	0
199	UDMA_CRC_Error_Count	0x000a	200	200	000	Old_age	Always	-	0

SMART Error Log Version: 1
No Errors Logged

Command Result : 0 (Success)

status handles

Gets the open handle count for each process.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status handles

Example

```
lunash:>status handles
```

HANDLES	PID	CMD
55	1	/usr/lib/systemd/systemd
4	2	[kthreadd]
4	3	[ksoftirqd/0]
4	5	[kworker/0:0H]
4	7	[migration/0]
4	8	[rcu_bh]
4	9	[rcuob/0]
4	10	[rcuob/1]
4	11	[rcuob/2]
4	12	[rcuob/3]
4	13	[rcuob/4]
4	14	[rcuob/5]
4	15	[rcuob/6]
4	16	[rcuob/7]

... (clip) ...

22	2417	/usr/lunasa/bin/pedClient
29	2426	/usr/lunasa/vts/stcd_vtsd
4	9587	[kworker/3:1]
4	11108	[kworker/u16:2]
0	11666	sleep
16	11667	/bin/bash
4	12764	[kworker/3:0]
15	14383	/bin/bash
33	14400	/usr/lunasa/vts/ntls_vtsd
4	15853	[kworker/1:1]
73	18956	sshd:
15	18988	-lush
4	19861	[kworker/u16:1]
4	23551	[kworker/2:0]
4	23655	[kworker/3:3]
4	25593	[kworker/3:4]
4	29384	[kworker/0:1]
4	30314	[kworker/1:2]
44	32204	/usr/sbin/rsyslogd

```
4 32442 [kworker/u16:0]
```

```
1557 Total handles allocated.
```

```
Command Result : 0 (Success)
```

status interface

Display network interface information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status interface

Example

```
lunash:>status interface
```

```
1: lo: <LOOPBACK,UP,LOWER_UP> mtu 65536 qdisc noqueue state UNKNOWN
   link/loopback 00:00:00:00:00:00 brd 00:00:00:00:00:00
   inet 127.0.0.1/8 scope host lo
       valid_lft forever preferred_lft forever
2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq state UP qlen 1000
   link/ether 00:15:b2:a9:b7:84 brd ff:ff:ff:ff:ff:ff
   inet 192.20.11.78/24 brd 192.20.11.255 scope global dynamic eth0
       valid_lft 107785sec preferred_lft 107785sec
3: eth1: <NO-CARRIER,BROADCAST,MULTICAST,UP> mtu 1500 qdisc mq state DOWN qlen 1000
   link/ether 00:15:b2:a9:b7:85 brd ff:ff:ff:ff:ff:ff
4: eth2: <NO-CARRIER,BROADCAST,MULTICAST,UP> mtu 1500 qdisc mq state DOWN qlen 1000
   link/ether 00:15:b2:a9:b7:86 brd ff:ff:ff:ff:ff:ff
5: eth3: <NO-CARRIER,BROADCAST,MULTICAST,UP> mtu 1500 qdisc mq state DOWN qlen 1000
   link/ether 00:15:b2:a9:b7:87 brd ff:ff:ff:ff:ff:ff
```

```
Command Result : 0 (Success)
```

status mac

Display the network interface MAC addresses.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status mac

Example

```
lunash:>status mac
```

```
eth0 00:15:b2:a9:b7:84  
eth1 00:15:b2:a9:b7:85  
eth2 00:15:b2:a9:b7:86  
eth3 00:15:b2:a9:b7:87
```

```
Command Result : 0 (Success)
```


status mem

Display the current memory usage.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status mem

Example

```
lunash:>status mem
```

	total	used	free	shared	buff/cache	available
Mem:	3958580	169292	3303072	17120	486216	3558836
Swap:	4064252	0	4064252			

```
Command Result : 0 (Success)
```

status memmap

Display the current memory usage.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status memmap

Example

```
lunash:>status memmap
```

PID	CMD	MAPPED (K)	WR/PR (K)	SHARED (K)
1	/usr/lib/systemd/systemd	45092	5176	0
2	[kthreadd]	0	0	0
3	[ksoftirqd/0]	0	0	0
5	[kworker/0:0H]	0	0	0
7	[migration/0]	0	0	0
8	[rcu_bh]	0	0	0
9	[rcuob/0]	0	0	0
10	[rcuob/1]	0	0	0
11	[rcuob/2]	0	0	0
12	[rcuob/3]	0	0	0

... (clip) ...

2417	/usr/lunasa/bin/pedClient	390372	43500	16
2426	/usr/lunasa/vts/stcd_vtsd	782544	558944	24
3555	[kworker/u16:2]	0	0	0
11442	[kworker/1:2]	0	0	0
12764	[kworker/3:0]	0	0	0
14383	/bin/bash	115380	548	28
14400	/usr/lunasa/vts/ntls_vtsd	1012848	592120	40
14555	[kworker/u16:1]	0	0	0
16198	sshd:	125332	1172	2560
16693	-lush	12932	660	0
18956	sshd:	125332	1172	2560
18988	-lush	12932	660	0
19305	[kworker/3:1]	0	0	0
23551	[kworker/2:0]	0	0	0
23823	[kworker/u16:0]	0	0	0
24051	sleep	0	0	0
24052	/bin/bash	9516	388	0
25512	[kworker/1:0]	0	0	0
25593	[kworker/3:4]	0	0	0
29384	[kworker/0:1]	0	0	0
32204	/usr/sbin/rsyslogd	299876	25772	16384

Command Result : 0 (Success)

status netstat

Display the current network connections.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status netstat

Example

```
lunash:>status netstat
```

Active Internet connections (servers and established)

Proto	Recv-Q	Send-Q	Local Address	Foreign Address	State
tcp	0	0	0.0.0.0:22	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:5656	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:8443	0.0.0.0:*	LISTEN
tcp	0	0	127.0.0.1:1501	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:1792	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:9697	0.0.0.0:*	LISTEN
tcp	0	192	192.20.11.78:22	10.124.0.87:60890	ESTABLISHED
tcp	0	0	192.20.11.78:22	10.124.0.87:60485	ESTABLISHED
tcp6	0	0	:::22	:::*	LISTEN
udp	0	0	0.0.0.0:12262	0.0.0.0:*	
udp	0	0	0.0.0.0:68	0.0.0.0:*	
udp6	0	0	:::45596	:::*	

Active UNIX domain sockets (servers and established)

Proto	RefCnt	Flags	Type	State	I-Node	Path
unix	2	[ACC]	STREAM	LISTENING	11782	/var/run/dbus/system_bus_socket
unix	2	[]	DGRAM		7448	/run/systemd/notify
unix	2	[]	DGRAM		7450	/run/systemd/cgroups-agent
unix	2	[ACC]	STREAM	LISTENING	7458	/run/systemd/journal/stdout
unix	5	[]	DGRAM		7461	/run/systemd/journal/socket
unix	19	[]	DGRAM		7463	/dev/log
unix	2	[ACC]	SEQPACKET	LISTENING	7993	/run/udev/control
unix	2	[]	DGRAM		8007	/run/systemd/shutdown

... (clip) ...

unix	3	[]	STREAM	CONNECTED	12103	/var/run/dbus/system_bus_socket
unix	2	[]	DGRAM		15471	
unix	2	[]	DGRAM		10738	
unix	3	[]	STREAM	CONNECTED	17213	
unix	3	[]	STREAM	CONNECTED	13199	
unix	3	[]	STREAM	CONNECTED	15861	
unix	3	[]	STREAM	CONNECTED	11788	/run/systemd/journal/stdout
unix	3	[]	STREAM	CONNECTED	15426	
unix	3	[]	STREAM	CONNECTED	12131	/var/run/dbus/system_bus_socket
unix	2	[]	DGRAM		3528172	

```
unix 3      [ ]      STREAM   CONNECTED 14336   /run/systemd/journal/stdout
unix 2      [ ]      DGRAM    3528167
unix 2      [ ]      DGRAM    12133
```

Command Result : 0 (Success)

status ps

Display the status of the appliance processes.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status ps

Example

```
lunash:>status ps
```

USER	PID	%CPU	%MEM	VSZ	RSS	TTY	STAT	START	TIME	COMMAND
root	1	0.5	0.1	45092	7844	?	Ss	Feb28	5:40	/usr/lib/systemd/systemd --
switched-root --system --deserialize 20										
root	2	0.0	0.0	0	0	?	S	Feb28	0:00	[kthreadd]
root	3	0.0	0.0	0	0	?	S	Feb28	0:00	[ksoftirqd/0]
root	5	0.0	0.0	0	0	?	S<	Feb28	0:00	[kworker/0:0H]
root	7	0.0	0.0	0	0	?	S	Feb28	0:02	[migration/0]
root	8	0.0	0.0	0	0	?	S	Feb28	0:00	[rcu_bh]
root	9	0.0	0.0	0	0	?	S	Feb28	0:00	[rcuob/0]
root	10	0.0	0.0	0	0	?	S	Feb28	0:00	[rcuob/1]
root	11	0.0	0.0	0	0	?	S	Feb28	0:00	[rcuob/2]

... (clip) ...

root	14383	0.0	0.0	115380	1780	?	Ss	Feb28	0:00	/bin/bash
/usr/lunasa/sbin/services/ntls start										
root	14400	0.0	0.3	1012848	13700	?	S<l	Feb28	0:19	/usr/lunasa/vts/ntls_vtsd --
application NTLS										
root	14555	0.0	0.0	0	0	?	S	10:02	0:00	[kworker/u16:1]
root	16198	0.0	0.1	125332	4572	?	Ss	10:03	0:00	sshd: admin@pts/1
root	16693	0.0	0.0	12932	1540	pts/1	Ss+	10:03	0:00	-lush
root	18956	0.0	0.1	125332	4572	?	Ss	09:20	0:00	sshd: admin@pts/0
root	18988	0.0	0.0	12932	1560	pts/0	Ss+	09:20	0:00	-lush
root	19305	0.0	0.0	0	0	?	S	10:04	0:00	[kworker/3:1]
root	23551	0.0	0.0	0	0	?	S	09:07	0:00	[kworker/2:0]
root	23823	0.0	0.0	0	0	?	S	09:36	0:00	[kworker/u16:0]
root	25512	0.0	0.0	0	0	?	S	09:52	0:00	[kworker/1:0]
root	25593	0.0	0.0	0	0	?	S	Feb28	0:01	[kworker/3:4]
root	29155	0.0	0.0	0	0	?	S	10:08	0:00	[kworker/u16:2]
root	29384	0.0	0.0	0	0	?	S	09:25	0:00	[kworker/0:1]
root	32204	0.0	0.2	299876	10816	?	Ss1	Feb28	0:01	/usr/sbin/rsyslogd -n

Command Result : 0 (Success)

status sensors

Displays the fan speed, temperature and voltage of the motherboard and power supply units.

Depending upon when you purchased your SafeNet Luna Network HSM appliance, the baseboard management controller firmware may be at a revision that reports more data on the power supply units than earlier BMC versions. The first example below shows the output from an earlier version of the BMC firmware. The second example shows the output from a more recent version. In this second example, the right PSU (facing the front of SafeNet Luna Network HSM) has no A/C power connected to it (it is in an audible alarm state).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status sensors [-log]

Argument(s)	Shortcut	Description
-log	-l	Show sensors event logs.

Example

```
lunash:>status sensors
```

This command displays the fan speed, temperature and voltage of the motherboard and power supply units.

Sensor	Reading	Unit	status	Thresholds
Fan1A	. 3700.000	RPM	ok	1000.000 2000.000 na na
Fan1B	. 4900.000	RPM	ok	1000.000 2000.000 na na
Fan2A	. 3700.000	RPM	ok	1000.000 2000.000 na na
Fan2B	. 5100.000	RPM	ok	1000.000 2000.000 na na
Fan3A	. 3800.000	RPM	ok	1000.000 2000.000 na na
Fan3B	. 5100.000	RPM	ok	1000.000 2000.000 na na
CPU	. 26.000	degrees C	ok	na na 95.000 100.000
VRD	. 28.000	degrees C	ok	na na 105.000 110.000
PCH	. 29.000	degrees C	ok	na na 99.000 104.000
Inlet	. 24.000	degrees C	ok	na na 87.000 97.000
CHA DIMM 0	. 11.000	degrees C	ok	na na 87.000 97.000
CHA DIMM 1	. na	degrees C	na	na na 87.000 97.000
CHB DIMM 0	. na	degrees C	na	na na 87.000 97.000
CHB DIMM 1	. na	degrees C	na	na na 87.000 97.000
RAM TMax	. 11.000	degrees C	ok	na na na na
+12V	. 12.240	Volts	ok	na 11.160 12.900 na
+5V	. 5.250	Volts	ok	na 4.650 5.370 na

3VMain	.		3.420		Volts		ok		na		3.060		3.540		na
5VSB	.		5.250		Volts		ok		na		4.650		5.370		na
3VSB	.		3.400		Volts		ok		na		3.060		3.540		na
CPU_VCORE	.		0.330		Volts		ok		na		na		na		na
VCCSA	.		1.060		Volts		ok		na		0.980		1.130		na
VCCIO	.		0.970		Volts		ok		na		0.880		1.020		na
1V2	.		1.250		Volts		ok		na		1.130		1.290		na
2V5_VPP	.		2.540		Volts		ok		na		2.320		2.680		na
1V0_PCH	.		1.010		Volts		ok		na		0.930		1.080		na
1V5_BMC	.		1.550		Volts		ok		na		1.470		1.930		na
1V26_BMC	.		1.270		Volts		ok		na		1.170		1.350		na
1V8_AUX	.		1.820		Volts		ok		na		1.670		1.930		na
VBAT	.		3.220		Volts		ok		2.100		2.500		na		na
PSU1_+12V_value.		12.360		Volts		ok		na		10.800		13.200		na	
PSU1 Temp_value.		33.000		degrees C		ok		na		na		50.000		na	
PSU1 FAN_value .		4600.000		RPM		ok		1000.000		1300.000		na		na	
PSU2_+12V_value.		0.000		Volts		CR *		na		10.800		13.200		na	
PSU2 Temp_value.		0.000		degrees C		ok		na		na		50.000		na	
PSU2 FAN_value .		0.000		RPM		NR *		1000.000		1300.000		na		na	
PSU1_Status	.		0x0		discrete		0x0180		na		na		na		na
PSU2_Status	.		0x0		discrete		0x0080		na		na		na		na
CPU_Thermtrip	.		0x0		discrete		0x0080		na		na		na		na
Watchdog	.		0x0		discrete		0x0080		na		na		na		na

Notes:

NR: Not Reading (Error)

CR: Critical

0.00 RPM means fan unplugged, failed, or sensors not readable

DIMM: Dual In-Line Memory Module

PSU1: Power Supply Unit 1

PSU2: Power Supply Unit 2

Fan1, Fan2 and Fan3 are pluggable modules on the front of the appliance.

Each fan unit contains two fans: A and B.

----- Power Supplies Status -----

```
PSU1_Status . | Presence detected
PSU2_Status . | Presence detected
CPU_Thermtrip . | OK
Watchdog . | OK
```

----- Front Cooling Fans Status -----

```
Fan1A . | OK | 3700 RPM
Fan1B . | OK | 4900 RPM
Fan2A . | OK | 3700 RPM
Fan2B . | OK | 5100 RPM
Fan3A . | OK | 3800 RPM
Fan3B . | OK | 5100 RPM
PSU1 FAN_value . | OK | 4800 RPM
PSU2 FAN_value . | OK | 4800 RPM
```

----- chassis status -----

```
System Power : on
Power Overload : false
Power Interlock : inactive
Main Power Fault : false
Power Control Fault : false
Power Restore Policy : previous
Last Power Event : ac-failed
Chassis Intrusion : inactive
Front-Panel Lockout : inactive
Drive Fault : false
Cooling/Fan Fault : true
```

```
Sleep Button Disable : not allowed  
Diag Button Disable  : not allowed  
Reset Button Disable : allowed  
Power Button Disable : allowed  
Sleep Button Disabled: false  
Diag Button Disabled : false  
Reset Button Disabled: false  
Power Button Disabled: false
```

```
Command Result : 0 (Success)
```


status sysstat

Access commands that allow you to display system status monitor service information and status code descriptions.

Syntax

status sysstat

code
show

Argument(s)	Shortcut	Description
code	c	Display descriptive text for a status code. See " status sysstat code " on the next page.
show	s	Display system status monitor service information. See " status sysstat show " on page 324.

status sysstat code

Display descriptions for the system status codes displayed on the appliance front-panel LCD. You can display information for all of the codes, or you can specify a specific code for which you want to display a description.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status sysstat code {all | <status_code>}

Argument(s)	Shortcut	Description
all	a	Display descriptions for all system status codes. See " Front-panel LCD Display " on page 1 in the <i>Appliance Administration Guide</i> for a detailed description of all of the possible status codes.
<status_code>		Specifies the system status code for which you want to display information.

Example

```
lunash:>status sysstat code all
```

```
Code   State   Description
=====
0      ISO     In service and operational.
15     OOS     The cluster service is not running.
       Run "cluster show" and commands to view log files for more information.
20     OOS     The NTLS service is not running.
       Run commands to display NTLS status for more information.
25     OOS     The NTLS is not bound to an Ethernet device.
       Run commands to display NTLS status and to view log files for more information.
       See help on how to bind an NTLS interface.
30     OOS     The HSM service has experienced one or more errors.
       Or the HSM service has experienced one or more critical events.
       Run "hsm show" and commands to view HSM log files for more information.
40     OOS     The cobradb service is not running.
       Run commands to show network connection details and to view log files for more
information.
50     OFL     No Ethernet interfaces are connected to the network.
       Run commands to display network status and to view log files for more information.
60     ISO     eth0 is offline.
       Run the command to restart the network service if it is not running.
       Run the command to show network status for more information.
61     ISO     eth1 is offline.
       Run the command to restart the network service if it is not running.
       Run the command to show network status for more information.
```

62 ISO eth2 is offline.
Run the command to restart the network service if it is not running.
Run the command to show network status for more information.

63 ISO eth3 is offline.
Run the command to restart the network service if it is not running.
Run the command to show network status for more information.

70 IST The logging service is not running.
Run commands to display the logging service status and to view log files for more information.
Run the command to restart the logging service if it is not running.

80 ISO The STC service is not running.
Run commands to display STC status for more information.

90 IST The SSH service is not running.
Run commands to display the SSH service status and to view log files for more information.
Run the command to restart the SSH service if it is not running.

95 ISO The webserver service is not running.
Run commands to display webserver status for more information.

100 ISO The SNMP service is not running.
Run commands to display the SNMP service status and to view log files for more information.
Run the command to restart the SNMP service if it is not running.

110 IST One or more partitions on the disk drive are reaching maximum capacity.
Run commands to delete files and clear logs to free some disk space.

Command Result : 0 (Success)

status sysstat show

Display system status monitor service information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status sysstat show

Example

```
lunash:>status sysstat show
```

```

Volatile State:
sysstat is running
Service Status: sysstat is running

```

```

Non-volatile State:
Enabled

```

```

System Status Monitor - Current Status
=====
Hostname:          sa7pw
Interface eth0:    192.20.11.78
Interface eth1:    not configured
Interface eth2:    not configured
Interface eth3:    not configured
Software Version:  SA:7.0.0-880
System Status:     ISO
System Status Code: 100,61,62,63,95
Status Check Time: 10:17 on 01/03/2017

```

System State Description

```

ISO (In Service Okay):      The appliance is online and the necessary subsystems are
operational.
IST (In Service with Trouble): The appliance is online and the necessary subsystems are
operational with some troubles.
OFL (Off Line):             The appliance is not currently connected to the Ethernet network
and cannot provide service.
OOS (Out Of Service):       The appliance is online but the necessary subsystems are NOT
operational.

```

```
Command Result : 0 (Success)
```

status time

Display the current time, using the 24 hour clock.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status time

Example

```
lunash:> status time
```

```
10:23.11
```

```
Command Result : 0 (Success)
```

status zone

Displays the current time zone. This command is equivalent to the **sysconf timezone show** command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

status zone

Example

```
lunash:>status zone
```

```
EST
```

```
Command Result : 0 (Success)
```

stc

Use these commands to configure and manage secure trusted channel (STC) partition-client network links.

You must be logged in as the HSM SO to use the **stc** commands.

Syntax

stc

activationtimeout
cipher
hmac
partition
rekeythreshold

Argument(s)	Shortcut	Description
activationtimeout	a	Set the activation timeout for an STC link. See " stc activationtimeout " on the next page.
cipher	ci	Disable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. See " stc cipher " on page 331.
hmac	h	Disable the use of an HMAC message digest algorithm for identity verification on an STC link. See " stc hmac " on page 335.
partition	p	Export the specified partition's public key to a file. " stc partition " on page 339.
rekeythreshold	rek	Set the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " stc rekeythreshold " on page 342.

stc activationtimeout

Control and monitor the STC activation timeout.

You must be logged in as the HSM SO to use the **stc activationtimeout** commands.

Syntax

stc activationtimeout

set
show

Argument(s)	Shortcut	Description
set	se	Set the activation timeout for an STC link. See " stc activationtimeout set " on the next page.
show	sh	Display the STC link activation timeout for the specified partition. See " stc activationtimeout show " on page 330

stc activationtimeout set

Set the activation timeout for an STC link. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc activationtimeout set -partition <partition_name> **-time** <timeout>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the name of the partition for which you want to set the STC link activation timeout.
-time <timeout>	-t	Specifies the activation timeout, in seconds. Range: 1 to 240 Default:

Example

```
lunash:>stc activationtimeout set -partition partition2 -time 60
```

Successfully changed the activation timeout for partition partition2 to 60 seconds.

Command Result : 0 (Success)

stc activationtimeout show

Display the activation timeout for an STC link. The activation timeout is the maximum time allowed to establish the STC link before the channel request is dropped.

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

stc activationtimeout show -partition <partition_name>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the name of the partition for which you want to display the STC link activation timeout.

Example

```
lunash:>stc activationtimeout show -partition partition2
```

The channel activation timeout for partition partition2 is 120 seconds.

Command Result : 0 (Success)

stc cipher

Control the use of symmetric encryption ciphers for STC.

You must be logged in as the HSM SO to use the **stc cipher** commands.

Syntax

stc cipher

disable
enable
show

Argument(s)	Shortcut	Description
disable	d	Disable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. See "stc cipher disable" on the next page .
enable	e	Enable the use of a symmetric encryption cipher algorithm used for data encryption on an STC link. See "stc cipher enable" on page 333 .
show	s	List the symmetric encryption cipher algorithms you can use for STC data encryption on the specified partition. See "stc cipher show" on page 334 .

stc cipher disable

Disable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command `"stc cipher show"` on page 334 to show which ciphers are currently enabled/disabled.

Disabling all of the ciphers turns off symmetric encryption on the link.

You must be logged in as the HSM SO to use this command.

NOTE Performance is reduced for larger ciphers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc cipher disable -partition <partition_name> [-all] [-id] <cipher_id> [-force]

Argument(s)	Shortcut	Description
-all	-a	Disable all ciphers
-force	-f	Force the action without prompting
-id <cipher_id>	-i	Specifies the numerical identifier of the cipher you want to disable, as listed using the command <code>"stc cipher show"</code> on page 334. Valid values: 1,2,3
-partition <partition_name>	-p	Specifies the name of the partition on which to disable the cipher (s).

Example

```
lunash:>stc cipher disable -partition partition2 -id 2
```

```
AES 192 Bit with Cipher Block Chaining is now disabled.
```

```
Command Result : 0 (Success)
```

stc cipher enable

Enable the use of a symmetric encryption cipher algorithm for data encryption on an STC link. All data transmitted over the STC link will be encrypted using the cipher that is both enabled and that offers the highest level of security. For example, if AES 192 and AES 256 are enabled, and AES 128 is disabled, AES 256 will be used. You can use the command ["stc cipher show" on the next page](#) to show which ciphers are currently enabled/disabled.

You must be logged in as the HSM SO to use this command.

NOTE Performance is reduced for larger ciphers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc cipher enable -partition <partition_name> [-all] [-id] <cipher_id>

Argument(s)	Shortcut	Description
-all	-a	Enable all ciphers.
-id <cipher_id>	-i	Specifies the numerical identifier of the cipher you want to use, as listed using the command "stc cipher show" on the next page .
-partition <partition_name>	-p	Specifies the name of the partition for which you want to enable the specified cipher.

Example

```
lunash:>stc cipher enable -partition partition2 -id 2
```

```
AES 192 Bit with Cipher Block Chaining is now enabled.
```

```
Command Result : 0 (Success)
```

stc cipher show

List the symmetric encryption cipher algorithms you can use for data encryption on an STC link. If all ciphers are disabled, symmetric encryption is not used on the link.

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

stc cipher show -partition <partition_name>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the partition for which you want to display the available ciphers.

Example

```
lunash:>stc cipher show -partition partition2
```

This table lists the ciphers supported for STC links to the partition. Enabled ciphers are accepted during STC link negotiation with a client. If all ciphers are disabled, STC links to the partition are not encrypted.

STC Encryption: On

Cipher ID	Cipher Name	Enabled
1	AES 128 Bit with Cipher Block Chaining	Yes
2	AES 192 Bit with Cipher Block Chaining	Yes
3	AES 256 Bit with Cipher Block Chaining	Yes

Command Result : 0 (Success)

stc hmac

Enable, disable, and monitor the use of HMAC algorithms for STC.

You must be logged in as the HSM SO to use the **stc hmac** commands.

Syntax

stc hmac

disable

enable

show

Argument(s)	Shortcut	Description
disable	d	Disable the use of an HMAC message digest algorithm for identity verification on an STC link. See "stc hmac disable" on the next page .
enable	e	Enable the use of an HMAC message digest algorithm for integrity verification on an STC link. See "stc hmac enable" on page 337
show	s	List the HMAC message digest algorithms you can use for STC message integrity verification on the specified partition. See "stc hmac show" on page 338

stc hmac disable

Disable the use of an HMAC message digest algorithm for message integrity verification on an STC link. The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command ["stc hmac show" on page 338](#) to show which HMAC message digest algorithms are currently enabled/disabled.

NOTE All STC links use message integrity verification, so at least one HMAC algorithm must be enabled.

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc hmac disable -partition <partition_name> **-id** <hmac_id>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the partition for which you want to disable an HMAC algorithm.
-id <hmac_id>	-i	Specifies the numerical identifier of the HMAC algorithm you want to disable, as listed using the command "stc hmac show" on page 338 .

Example

```
lunash:>stc hmac disable -partition partition2 -id 1
```

HMAC with SHA 512 Bit is now disabled.

Command Result : 0 (Success)

stc hmac enable

Enable the use of an HMAC message digest algorithm for message integrity verification on an STC link. The HMAC algorithm that is both enabled and that offers the highest level of security is used. For example, if SHA 256 and SHA 512 are enabled, SHA 512 is used. You can use the command ["stc hmac show" on the next page](#) to show which HMAC message digest algorithms are currently enabled/disabled.

NOTE All STC links use message integrity verification, so at least one HMAC algorithm must be enabled.

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc hmac enable -partition <partition_name> **-id** <hmac_id>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the partition for which you want to enable the HMAC algorithm.
-id <hmac_id>	-i	Specifies the numerical identifier of the HMAC algorithm you want to enable, as listed using the command "stc hmac show" on the next page .

Example

```
lunash:>stc hmac enable -partition partition2 -id 1
```

HMAC with SHA 512 Bit is now enabled.

Command Result : 0 (Success)

stc hmac show

List the HMAC message digest algorithms you can use for message integrity verification on an STC link. You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

stc hmac show -partition <partition_name>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the partition for which you want to display the available HMAC algorithms.

Example

```
lunash:>stc hmac show -partition partition2
```

This table lists the HMAC algorithms supported for STC links to the partition. Enabled algorithms are accepted during STC link negotiation with a client. At least one HMAC algorithm must be enabled.

HMAC ID	HMAC Name	Enabled
0	HMAC with SHA 256 Bit	Yes
1	HMAC with SHA 512 Bit	Yes

Command Result : 0 (Success)

stc partition

Export the STC partition identity.

You must be logged in as the HSM SO to use the **stc partition** commands.

Syntax

stc partition

export
show

Argument(s)	Shortcut	Description
export	e	Export the specified partition's public key to a file. See " stc partition export " on the next page.
show	s	Display the public key and serial number for the current partition. See " stc partition show " on page 341.

stc partition export

Export the specified partition's public key to a file. You must be logged in to the partition as the SO to perform this command.

NOTE If the HSM is zeroized while STC is enabled, the STC link between LunaSH and the admin partition will no longer authenticate, since the admin partition identity no longer exists. If this occurs, you will be unable to log into, or initialize, the HSM. To recover from this state, run the **stc partition export** command without any parameters. When you run the command, a new identity is created for the admin partition, and the new admin partition public key is exported to the default directory. This will restore the STC link between LunaSH and the admin partition, allowing you to re-initialize the HSM. You can only run this command, while not logged into the HSM, if the HSM is zeroized.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc partition export -partition <partition_name>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the name of the partition whose public key you want to export.

Example

```
lunash:>stc partition export -partition partition2
```

```
Successfully exported partition identity for partition partition2 to file: 154438865290.pid
```

```
Command Result : 0 (Success)
```

stc partition show

Display the public key and serial number for the current partition. You must be logged into the partition as the SO to perform this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

stc partition show -partition <partition_name>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the name of the partition whose public key and serial number you want to display

Example

```
lunash:>stc partition show -partition partition2
```

```
Partition Serial Number:          154438865290
Partition Identity Public Key SHA1 Hash: 67a26c546f0bdd911375c833babcf702aa61e3ee
```

```
Command Result : 0 (Success)
```

stc rekeythreshold

Monitor and set the STC re-keying threshold for the named partition.

You must be logged in as the HSM SO to use the **stc rekeythreshold** commands.

Syntax

stc rekeythreshold

set
show

Argument(s)	Shortcut	Description
set	se	Set the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " stc rekeythreshold set " on the next page.
show	sh	Display the key life for the symmetric key used to encrypt data on the STC link for the specified partition. See " stc rekeythreshold show " on page 344.

stc rekeythreshold set

Set the rekey threshold for the symmetric key used to encrypt data on an STC link. The symmetric key is used to encode the number of messages specified by the threshold value, after which it is regenerated and the counter is reset to 0.

The default of 400 million messages would force a rekeying operation once every 24 hours on an HSM under heavy load (processing approximately 5000 messages/second), or once a week for an HSM under light load (processing approximately 700 messages/second).

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

stc rekeythreshold set -partition <partition> **-value** <key_life>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the name of the partition for which you want to specify the STC rekey threshold.
-value <key_life>	-v	An integer that specifies the key life (in millions of encoded messages) for the STC symmetric key. Enter a value of 0 to disable rekeying. Range: 0 to 4000 million messages. Default: 400 million messages.

Example

```
lunash:>stc rekeythreshold set -partition partition2 -value 200
```

Successfully changed the rekey threshold for partition partition2 to 200 million messages.

Command Result : 0 (Success)

stc rekeythreshold show

Display the rekey threshold for the symmetric key used to encrypt data on an STC link. The symmetric key is used the number of times specified by the threshold value, after which it is regenerated and the counter is reset to 0. Each command sent to the HSM over the STC link uses one life.

You must be logged in as the HSM SO to use this command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

stc rekeythreshold show -partition <partition_name>

Argument(s)	Shortcut	Description
-partition <partition_name>	-p	Specifies the name of the partition for which you want to display the STC rekey threshold.

Example

```
lunash:>stc rekeythreshold show -partition partition2
```

```
Current rekey threshold for partition partition2 is 400 million messages.
```

```
Command Result : 0 (Success)
```


sysconf

Access commands that allow you to configure the appliance.

Syntax

sysconf

appliance
banner
config
drift
fingerprint
forcesologin
license
ntp
radius
regencert
snmp
ssh
time
timezone
tls

Argument(s)	Shortcut	Description
appliance	a	Access commands that allow you to manage the appliance. See "sysconf appliance" on page 347 .
banner	b	Access commands to set and clear an extended text banner, displayed to appliance administrative users when they log into a LunaSH session. See "sysconf banner" on page 355 .
config	c	Access the system configuration commands. See "sysconf config" on page 359 .
drift	d	Access commands that allow you to view and configure the drift. See "sysconf drift" on page 374 .
fingerprint	fi	Display the certificate fingerprints. See "sysconf fingerprint" on page 381 .
forcesologin	fo	Access commands that allow you to enable or disable SO login enforcement, or display the current SO login enforcement setting. See "sysconf forcesologin" on page 385 .

Argument(s)	Shortcut	Description
license	l	Access commands that allow you to manage feature licensing for capability and partition upgrades. See "sysconf license" on page 391 .
ntp	n	Access commands that allow you to view or configure the network time protocol (NTP). See "sysconf ntp" on page 395 .
radius	ra	Manage RADIUS configuration and identify RADIUS servers to use for enhanced authentication, authorization, and accounting of your SafeNet appliance users and roles "sysconf radius" on page 425 .
regencert	re	Generate or re-generate the SafeNet appliance server hardware certificate. See "sysconf regencert" on page 431 .
snmp	sn	Access commands that allow you to view or configure the Simple Network Management Protocol (SNMP) settings for SafeNet appliance. See "sysconf snmp" on page 437 .
ssh	ss	Access commands that allow you to view or configure the SSH options on the appliance. See "sysconf ssh" on page 461 .
time	t	Set or display the time and date. See "sysconf time" on page 473 .
timezone	timez	Set or display the time zone. See "sysconf timezone" on page 474 .
tls	tl	Configure the set of ciphers that TLS can use when negotiating link security. See "sysconf tls ciphers" on page 478 .

sysconf appliance

Access the **sysconf appliance** commands to manage the appliance.

Syntax

sysconf appliance

hardreboot
poweroff
reboot
rebootonpanic

Argument(s)	Shortcut	Description
hardreboot	h	Reboot the appliance, bypassing graceful closing of services. See "sysconf appliance hardreboot" on the next page .
poweroff	p	Power off the appliance. See "sysconf appliance poweroff" on page 349 .
reboot	r	Reboot the appliance. See "sysconf appliance reboot" on page 350 .
rebootonpanic	rebooto	System reboot on panic. See "sysconf appliance rebootonpanic" on page 351 .

sysconf appliance hardreboot

Perform a hard restart (reboot) of the SafeNet appliance.

When you do not have convenient physical access to your SafeNet appliances, this command replaces the **sysconf appliance reboot** command (see "[sysconf appliance reboot](#)" on page 350) which performs an orderly soft reboot sequence by ordering a large number of services/daemons to conclude their operations, and logs that process. That is the preferred method of rebooting a SafeNet Luna Network HSM appliance, if you have physical access and can retry in case any of the processes hangs and prevents the soft reboot sequence from proceeding.

Use the **sysconf appliance hardreboot** command when the appliance is not accessible for physical intervention (such as in a secluded, lights-off facility), if needed. This command bypasses many running processes at shutdown, allowing the reboot to occur without hanging.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

sysconf appliance hardreboot [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf appliance hardreboot
```

```
WARNING !! This command will reboot the appliance without gracefully shutdown.
           All clients will be disconnected.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed
```

sysconf appliance poweroff

Power off the SafeNet Luna Network HSM appliance.

Appliance reboot and power-off automatically take a snapshot of the system's known state and saves it to the **supportinfo.txt** file, so that you can send it to Technical Support for further investigation. This is useful if the system is not behaving and needs reboot or power-off. See ["hsm supportinfo" on page 182](#) for more information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf appliance poweroff [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf appliance poweroff
```

```
WARNING !! This command will power off the appliance.
```

```
All clients will be disconnected and the appliance will require a manual power on for further access.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed
```

```
Proceeding...
```

```
'hsm supportInfo' successful.
```

```
Use 'scp' from a client machine to get file named:
```

```
supportInfo.txt
```

```
Broadcast message from root@local_host (Wed Mar 1 11:20:38 2017):
```

```
The system is going down for system halt NOW!
```

```
Power off commencing
```

sysconf appliance reboot

Performs a warm restart (reboot) of the SafeNet appliance, shutting down all running processes in a controlled manner.

Appliance reboot and power-off automatically take a snapshot of the system's known state and saves it to the **supportinfo.txt** file, so that you can send it to Technical Support for further investigation. This is useful if the system is not behaving and needs reboot or power-off. See ["hsm supportinfo" on page 182](#) for more information.

To deal with the possibility that a controlled shutdown might not be possible, see ["sysconf appliance rebootonpanic enable" on page 353](#).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf appliance reboot [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf appliance reboot
```

```
WARNING !! This command will reboot the appliance.
           All clients will be disconnected.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed
Proceeding...
'hsm supportInfo' successful.
```

```
Use 'scp' from a client machine to get file named:
supportInfo.txt
```

```
Broadcast message from root@local_host (Wed Mar 1 11:24:08 2017):
```

```
The system is going down for reboot NOW!
Reboot commencing
```

sysconf appliance rebootonpanic

Access commands that allow you to enable or disable reboot on panic and show reboot on panic information.

Syntax

sysconf appliance rebootonpanic

disable
enable
show

Argument(s)	Shortcut	Description
disable	d	Disable system reboot on panic. See " sysconf appliance rebootonpanic disable " on the next page.
enable	e	Enable system reboot on panic. See " sysconf appliance rebootonpanic enable " on page 353.
show	s	Show system reboot on panic information. See " sysconf appliance rebootonpanic show " on page 354.

sysconf appliance rebootonpanic disable

Disable system automatic reboot on kernel panic.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf appliance rebootonpanic disable

Example

```
lunash:>sysconf appliance rebootonpanic disable
```

```
Command Result : 0 (Success)
```

sysconf appliance rebootonpanic enable

Enable automatic reboot in case of problem.

In normal situations, the command "[sysconf appliance reboot](#)" on page 350 causes the appliance to shut down in a controlled manner.

This command configures the SafeNet appliance to automatically reboot in the event that the appliance fails to complete a normal shutdown. In conjunction with the AutoActivation setting, this option can allow SafeNet Luna HSM cryptographic service to resume after a problem, without need for human intervention.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf appliance rebootonpanic enable

Example

```
lunash:>sysconf appliance rebootonpanic enable
```

```
Command Result : 0 (Success)
```

sysconf appliance rebootonpanic show

Display the reboot-on-panic configuration status.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf appliance rebootonpanic show

Example

```
lunash:>sysconf appliance rebootonpanic show
```

```
System auto reboot on panic is enabled.
```

```
Command Result : 0 (Success)
```

sysconf banner

Access the sysconf banner commands to set and clear an extended text banner, displayed to appliance administrative users when they log into a LunaSH session.

Syntax

sysconf banner

add
clear

Argument(s)	Shortcut	Description
add	a	Add extended banner text from a file. See " sysconf banner add " on the next page
clear	c	Clear the extended banner text. See " sysconf banner clear " on page 358 .

sysconf banner add

Add a custom text banner that is displayed when administrative users connect and log into the appliance. The text is initially obtained from a file. The file must already have been uploaded to the appliance's admin user, via scp/pscp.

Only the "admin" user can perform this operation. The command is not available to "operator".

A single extended banner is set for all users who log in; it is not possible to set different banners for different users or classes of users.

Use the command **user file list** to view available files and verify the name of the desired banner file.

The banner file size is limited to 8KB.

The banner filename is limited to characters a-z, A-Z, 0-9, '.', '-' or '_'.

For the banner text within the file, only standard ASCII characters are accepted (characters between 0 and 127 in <http://www.asciitable.com/>).

You must be logged into the HSM before issuing the command **sysconf banner add**.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf banner add -file <filename>

Argument(s)	Shortcut	Description
-file <filename>	-f	Banner text file name.

Example

```
lunash:>my file list
```

```
    273 Mar  1 11:42 banner1.txt
    515 Mar  1 10:57 154438865290.pid
133913 Feb 28 15:59 supportInfo.txt
    4330 Feb 28 15:07 firstboot.log
```

```
Command Result : 0 (Success)
```

```
lunash:>sysconf banner add -file banner1.txt
```

```
Command Result : 0 (Success)
```

```
login as: admin
```

admin@192.20.11.78's password:

Last login: Wed Mar 1 10:36:40 2017 from 10.124.0.87

Luna SA 7.0.0-880 Command Line Shell - Copyright (c) 2001-2017 SafeNet, Inc. All rights reserved.

-----W A R N I N G-----

Your use of this resource is monitored and recorded for
security and quality-control purposes.

d=(^_-)

-----H A V E---A---N I C E---D A Y-----

[local_host] lunash:>

sysconf banner clear

Remove a custom text banner that is displayed when administrative users connect and log into the appliance. The extended text was previously added from a file with the command **sysconf banner add -file** <filename>. If you wish to change an existing extended banner, simply re-issue the **add** command, naming a file with the new text. This command (**sysconf banner clear**) simply clears any extended banner text completely, with no replacement.

Only the "admin" user can perform this operation. The command is not available to "operator".

You must be logged into the HSM before issuing the command **sysconf banner clear**.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf banner clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting (useful for scripting).

Example

```
lunash:>sysconf banner clear
```

```
WARNING !! This command will clear the extended banner text.
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will abort.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config

Access the system configuration commands. This command manages the various configuration files that are created and modified when you set up various system elements such as NTLS, SSH, NTP, SNMP, etc.

Syntax

sysconf config

backup
clear
delete
export
factoryreset
import
list
restore
show

Argument(s)	Shortcut	Description
backup	b	Backs up configuration data. See " sysconf config backup " on the next page .
clear	c	Deletes all the configuration backup files except the initial factory configuration file. See " sysconf config clear " on page 362 .
delete	d	Deletes a configuration backup file. See " sysconf config delete " on page 363 .
export	e	Exports a configuration backup file. See " sysconf config export " on page 364 .
factoryreset	f	Factory reset. See " sysconf config factoryreset " on page 365 .
import	i	Imports a configuration backup file. See " sysconf config import " on page 369 .
list	l	List configuration backup files. See " sysconf config list " on page 370 .
restore	r	Restores configuration backup. See " sysconf config restore " on page 371 .
show	s	Show the current configuration. See " sysconf config show " on page 373 .

sysconf config backup

Back up the appliance configuration data, and save it to the appliance file system. There is no limit on the size of individual backup files or the number of backups that can be stored on the file system, other than the available space. This space is shared by other files, such as spkg and log files, so account for this when planning your backup and restore strategy.

If desired, you can use the command ["sysconf config export" on page 364](#) to save the backup file to the internal HSM, or an external backup token after you create it.

NOTE This command does not backup the HSM and partition configurations. See ["hsm backup" on page 82](#) and ["partition backup" on page 281](#) for more information.

The backup file includes configuration data for the following modules and services:

Network	Network configuration
NTLS	NTLS configuration
NTP	Network Time Protocol configuration
SNMP	SNMP configuration
SSH	SSH configuration
Syslog	Syslog configuration
System	System configuration (keys and certificates)
Users	User accounts, passwords, and files
Webserver	Webserver configuration for REST API

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf config backup -description <comment> [-factoryconfig]

Argument(s)	Shortcut	Description
-description <comment>	-d	Comment describing this backup. The description must be enclosed in double quotes if it contains spaces.
-factoryconfig	-f	Binary option.

Example

```
lunash:>sysconf config backup -description "Configuration Backup 17-03-01"
```

```
Created configuration backup file: local_host_Config_20170301_1200.tar.gz
```

```
Command Result : 0 (Success)
```

sysconf config clear

Deletes all the configuration backup files in the file system, in the internal HSM, or in an external backup token. This command does not delete the initial factory configuration file in the file system.

If the **-devicetype** parameter is not specified, the files in the file system are deleted.

-serialnumber is required if **-devicetype** is "token" and optional if **-devicetype** is "hsm".

-serialnumber is not required and is ignored if **-devicetype** is not specified.

SO login is required before running this command if **-devicetype** is "hsm" or "token".

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf config clear [-force] [-devicetype <devicetype>] [-serialnumber <serialnum>]

Argument(s)	Shortcut	Description
-devicetype <devicetype>	-d	Specifies whether to delete configuration backup files in the internal HSM or an external backup token. Valid values: hsm,token
-force	-f	Force the action without prompting.
-serialnumber <serialnum>	-s	Specifies the serial number of the token where backup files are to be deleted. Required if -devicetype is "token", optional if "hsm".

Example

```
lunash:>sysconf config clear
```

```
WARNING !! This command deletes all the configuration backup files except the initial factory configuration file.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config delete

Delete a configuration backup file.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf config delete -file <filename> [**-deviceType** <devicetype>] [**-serialnumber** <serialnum>] [**-force**]

Argument(s)	Shortcut	Description
-devicetype <devicetype>	-d	Device Type Valid values: hsm, token
-file <filename>	-fi	File name to delete
-force	-fo	Force action (no prompting for confirmation)
-serialnumber <serialnum>	-s	Token Serial Number

Example

```
lunash:>sysconf config delete -file local_host_Config_20170301_1222.tar.gz
```

```
WARNING !! This command deletes the configuration backup file: local_host_Config_20170301_1222.tar.gz.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config export

Exports a configuration backup file from the file system to the internal HSM, or to an external backup token. This command overwrites the existing configuration file with the same name.

-serialnumber is required if **-devicetype** is "token" and optional if **-devicetype** is "hsm".

SO login is required before running this command if **-devicetype** is "hsm" or "token".

The maximum size of configuration files being exported to the internal HSM is 64 KB. The SafeNet Luna Network HSM's Admin/SO partition has a maximum capacity of 384 KB.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf config export -file <filename> [-devicetype <devicetype>] [-serialnumber <serialnum>] [-force]

Argument(s)	Shortcut	Description
-devicetype <devicetype>	-d	Device Type (hsm, token)
-file <filename>	-fi	File Name to delete
-force	-fo	Force Action (no prompting for confirmation)
-serialnumber <serialnum>	-s	Token Serial Number

Example

```
lunash:>sysconf config export -file local_host_Config_20170301_1212.tar.gz -devicetype hsm -
serialnumber 66331
```

```
WARNING !! This command exports the configuration backup file: local_host_Config_20170301_
1212.tar.gz to the hsm.
```

```
It will overwrite the existing configuration file with the same name on the hsm.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config factoryreset

Reset the appliance to the settings created at the factory. You can specify any individual service's configuration, or just reset all of them to the initial factory settings with the '-all' option. This reset is for the configurations of the indicated services and does not affect the HSM.

This command affects appliance settings external to the HSM. To reset the HSM, use **hsm factoryreset** (which can be run from a local serial console only).

We recommend disconnecting all NTLS connections before performing factory reset.

Files are not affected

The log files, and the content of users' home directories are not affected by this command.

- > To clear log files you can use the **syslog cleanup** command. If you need to keep the logs, you should use the **syslog tarlogs** command, then scp the logs file to another computer before clearing the log files.
- > To clear the content of the user's home directory, use the **my file clear** command.

SO login required if "Force SO login" policy is set

If the Force SO login policy is set for the HSM (see command "[sysconf forcesologin show](#)" on page 390), then you must log in as SO before resetting the 'ntls' service or 'all' services.

If the HSM is zeroized, then **hsm login** is not needed, even if ForceSOlogin is enabled.

ForceSOlogin is disabled following a successful **hsm login** if 'ntls' or 'all' services are reset.

What to do

To preserve desired settings and capabilities, we recommend that you perform **sysconf config backup** on your system whenever you upgrade or update or reconfigure, so as to have a backup with all desired configurations in place, and then use **sysconf config restore** if needed, reserving **sysconf config factoryreset** for only those occasions when you want the appliance set all the way back to original factory specification.

- > Use this command along with the **hsm factoryreset** command, if you want internal HSM settings returned to factory default values.
- > Use this command from a locally-connected serial terminal (or console server). This command resets network settings to use DHCP; as a result the network interfaces might be assigned new IP addresses. You can get the new IP addresses on the LCD or from a serial port connection.
- > Disconnect all NTLS connections before factory reset.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

```
sysconf config factoryreset -service <service> [-force]
```

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-service <service>	-s	Specifies the service name. Valid values: network,ssh,ntls,syslog,ntp,snmp,users,system,webserver,all

Example with no active client connections

```
lunash:>sysconf config factoryReset -service all
```

```
Checking for connected clients
```

```
There are no active clients at this time.
```

This command resets the configuration of the selected service(s) to factory defaults. Resetting services to factory defaults can affect connectivity and the operation of the HSM. If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
Resetting service(s) to factory defaults:
-----
webserver :      succeeded
users     :      succeeded
snmp      :      succeeded
ntp       :      succeeded
ntls      :      succeeded
system    :      succeeded
ssh       :      succeeded
syslog    :      succeeded
network   :      succeeded
```

```
Command Result : 0 (Success)
```

Example with no active client connections and force option used

```
lunash:>sysconf config factoryReset -service all -force
```

```
Checking for connected clients
```

```
There are no active clients at this time.
```

```
Force option used. Proceed prompt bypassed.
```

```
Resetting service(s) to factory defaults:
-----
webserver :      succeeded
users     :      succeeded
```

```
snmp      :      succeeded
ntp       :      succeeded
ntls      :      succeeded
system   :      succeeded
ssh       :      succeeded
syslog   :      succeeded
network  :      succeeded
```

Command Result : 0 (Success)

Example with active client connections

```
lunash:>sysconf config factoryReset -service all
```

Checking for connected clients

WARNING !! There are 1 client(s) connected to this Luna SA appliance. It is recommended that you disconnect all clients before using this command.
This command resets the configuration of the selected service(s) to factory defaults. Resetting services to factory defaults can affect connectivity and the operation of the HSM. If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
Resetting service(s) to factory defaults:
-----
webserver :      succeeded
users     :      succeeded
snmp      :      succeeded
ntp       :      succeeded
ntls      :      succeeded
system   :      succeeded
ssh       :      succeeded
syslog   :      succeeded
network  :      succeeded
```

Command Result : 0 (Success)

Example with active client connections and force option used

```
lunash:>sysconf config factoryReset -service all -force
```

Checking for connected clients

WARNING !! There are 1 client(s) connected to this Luna SA appliance. It is recommended that you disconnect all clients before using this command.
Force option used. Proceed prompt bypassed.

```
Resetting service(s) to factory defaults:
-----
webserver :      succeeded
```

```
users      :      succeeded
snmp       :      succeeded
ntp        :      succeeded
ntls       :      succeeded
system     :      succeeded
ssh        :      succeeded
syslog     :      succeeded
network    :      succeeded
```

```
Command Result : 0 (Success)
```


sysconf config import

Import a configuration backup file from the internal HSM or from an external backup HSM and saves it as a file. This command overwrites the existing configuration file with the same name.

This command does not restore the configuration from the imported file. You can use the **sysconf config restore** command after running this command to restore the configurations.

-serialnumber is required if **-devicetype** is "token" and optional if **-devicetype** is "hsm".

SO login is required before running this command if **-devicetype** is "hsm" or "token".

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf config import -file <filename> [-devicetype <devicetype>] [-serialnumber <serialnum>] [-force]

Argument(s)	Shortcut	Description
-devicetype <devicetype>	-d	Device Type (hsm, token)
-file <filename>	-fi	File Name to delete
-force	-fo	Force the action without prompting.
-serialnumber <serialnum>	-s	Token Serial Number

Example

```
lunash:>sysconf config import -file local_host_Config_20170301_1212.tar.gz -devicetype hsm -
serialnumber 66331
```

```
WARNING !! This command imports the configuration backup file: local_host_Config_20170301_
1212.tar.gz from the hsm.
```

```
It will overwrite the existing configuration file with the same name.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf config list

Show the list of configuration backup files stored in the file system, the internal HSM, or in an external token. Use this command without any parameters to list the configuration files stored in the file system.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf config list [-devicetype <devicetype>] [-serialnumber <serialnumber>]

Argument(s)	Shortcut	Description
-devicetype <devicetype>	-d	Specifies the device type. You must be logged in as the HSM SO to use this parameter. Valid values: hsm, token
-serialnumber <serialnum>	-s	Specifies the token serial number: <ul style="list-style-type: none"> > this parameter is not required, and is ignored, if -devicetype is not specified. > this parameter is required if -devicetype is token > this parameter is optional if -devicetype is hsm.

Example

```
lunash:>sysconf config list
```

Configuration backup files in file system:

```
Size      | File Name                                     | Description
-----
14551    | local_host_Config_20170301_1200.tar.gz      | Configuration Backup 17-03-01
14555    | local_host_Config_20170301_1212.tar.gz      | Backup before Factory Reset
14568    | local_host_Config_20170301_1222.tar.gz      | Automatic Backup Before
Restoring: ntl
```

Command Result : 0 (Success)

sysconf config restore

Restore configuration of the selected services from a backup file. This command automatically creates a backup file of the current configurations before restoring a previous configuration. You can restore the previous configurations from this backup if the new settings are not acceptable.

If you store your appliance configuration on an HSM (using ["sysconf config export" on page 364](#)) you must first use the command ["sysconf config import" on page 369](#) to import the configuration file from the HSM to the appliance file system before using this command.

The service(s) must be stopped before restoring their configuration.

You must reboot the appliance for the changes to take effect. Please check the new configurations before rebooting or restarting the services.

NOTE This command does not restore the HSM and Partition configurations (see ["hsm restore" on page 136](#) and ["partition restore" on page 292](#) for more information).

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf config restore -file <filename> -service <service> [-force]

Argument(s)	Shortcut	Description
-file <filename>	-fi	File name
-force	-fo	Force the action without prompting.
-service <service>	-s	The service name. Valid values: network,ssh,ntls,syslog,ntp,snmp,users,system,webserver,all

Example

```
lunash:>sysconf config restore -file local_host_Config_20170301_1212.tar.gz -service ntl
```

```
WARNING !! This command restores the configuration from the backup file: local_host_Config_20170301_1212.tar.gz.
```

```
It first creates a backup of the current configuration before restoring: local_host_Config_20170301_1212.tar.gz.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
```

Created configuration backup file: local_host_Config_20170301_1222.tar.gz

Restore the ntlm configuration: Succeeded.

You must either reboot the appliance or restart the service(s) for the changes to take effect. Please check the new configurations BEFORE rebooting or restarting the services. You can restore the previous configurations if the new settings are not acceptable.

Command Result : 0 (Success)

sysconf config show

Shows the system information of a configuration backup file.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf config show -file <filename>

Argument(s)	Shortcut	Description
-file <filename>	-f	File name

Example

```
lunash:>sysconf config show -file local_host_Config_20170301_1200.tar.gz
```

System information when this backup was created:

```
hostname: local_host
eth0 IP Address: 192.20.11.78
eth1 IP Address:
eth2 IP Address:
eth3 IP Address:
Software Version: Luna SA 7.0.0-880 [Build Time: 20170228 12:16]
HSM Firmware Version: 7.0.1
HSM Serial Number: 66331
uptime: 12:00:07 up 20:00, 1 user, load average: 0.31, 0.28, 0.25
Current time: Wed Mar 1 12:00:07 EST 2017
```

```
Description: Configuration Backup 17-03-01
```

```
Command Result : 0 (Success)
```

sysconf drift

Access the **sysconf drift** commands to view and configure drift.

Syntax

sysconf drift

init
reset
set
startmeasure
status
stopmeasure

Argument(s)	Shortcut	Description
init	i	Activate automatic drift adjustments. See "sysconf drift init" on the next page .
reset	r	Reset all drift tracking data. See "sysconf drift reset" on page 376 .
set	se	Manually set internal drift data. See "sysconf drift set" on page 377 .
startmeasure	star	Set the time and start measuring. See "sysconf drift startmeasure" on page 378 .
status	stat	Display the current drift data. See "sysconf drift status" on page 379 .
stopmeasure	sto	Stop measuring and record the drift. See "sysconf drift stopmeasure" on page 380 .

sysconf drift init

Sets the time, and activates the automatic periodic drift adjustments. This is done after you have completed a period of drift measurement with the **sysconf drift startmeasure** and **sysconf drift stopmeasure** commands, with at least an uninterrupted three day measurement period between the start and stop, to calculate the baseline of drift.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf drift init -currentprecisetime <hh:mm:ss>

Argument(s)	Shortcut	Description
-currentprecisetime <hh:mm:ss>	-c	Current best precise time in hh:mm:ss format.

Example

```
lunash:>sysconf drift init -currentprecisetime 09:21:00
```

```
Measuring drift correction data on this appliance.
```

```
Setting the time to 09:21:00 and initializing drift correction of 2 seconds per day on this appliance. The time will be adjusted daily to compensate for this drift.
```

```
Use the command 'sysconf drift reset' to disable drift correction.
```

```
Date and time set to: Mon Mar 6 09:21:00 EST 2017
```

```
Command Result : 0 (Success)
```

sysconf drift reset

Reset drift and internal drift tracking data.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf drift reset [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting

Example

```
lunash:>sysconf drift reset
```

```
If you are sure that you wish to clear all data relating to drift
correction, then type 'proceed', otherwise type 'quit'
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf drift set

Manually set the internal drift measurement data.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf drift set

Example

```
lunash:>sysconf drift set
```

```
Enter the value to be used for drift (in seconds per day): 3
```

```
This value will overwrite the previous value of the drift that may have  
been measured. If you are sure that you wish to overwrite it, then type  
'proceed', otherwise type 'quit'
```

```
> proceed  
Proceeding...
```

```
NOTE: The new value will not take effect until 'sysconf drift init' is run.
```

```
Command Result : 0 (Success)
```

sysconf drift startmeasure

Sets the time, and starts measuring drift.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf drift startmeasure -currentprecisetime <hh:mm:ss>

Argument(s)	Shortcut	Description
-currentprecisetime <hh:mm:ss>	-c	Current best precise time in hh:mm:ss format.

Example

```
lunash:>sysconf drift startmeasure -currentprecisetime 12:37:00
```

```
Setting the time to 12:37:00 and recording data for drift correction mechanism.
```

```
Current date and time set to: Wed Mar 1 12:37:00 EST 2017
```

```
Command Result : 0 (Success)
```

sysconf drift status

Display the status of the current drift data.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf drift status

Example

```
lunash:>sysconf drift status
```

```
Drift measurement started on: Wed Mar 1 12:37:00 EST 2017
Measurement has yet to be stopped.
Current drift correction is: 3 seconds per day
(Note that drift correction may be manually set.)
```

```
Command Result : 0 (Success)
```

sysconf drift stopmeasure

Stops measuring and records the drift.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf drift stopmeasure -currentprecisetime <hh:mm:ss>

Argument(s)	Shortcut	Description
-currentprecisetime <hh:mm:ss>	-c	Current best precise time in hh:mm:ss format.

Example

```
lunash:>sysconf drift stopmeasure -currentprecisetime 09:18:00
```

Measuring drift correction data on this appliance.

Storing measured drift of 2 seconds/day in internal configuration files.
Use the command 'sysconf drift init' to initialize drift correction.

Command Result : 0 (Success)

sysconf fingerprint

This command displays the system's certificate fingerprints for use when ensuring that ssh connections are being made to the correct host, or that the correct server certificate was brought to a client.

Specify if you wish to see the ssh certificate fingerprint or the NTLS certificate fingerprint. The NTLS certificate is created using the sha256WithRSAEncryption algorithm.

Syntax

sysconf fingerprint

license
ntls
ssh

Argument(s)	Shortcut	Description
license	l	Display the fingerprint for the HSM serial number. See " sysconf fingerprint license " on the next page.
ntls	n	Display the fingerprint of the NTLS certificate. (On the client side, you can compare this with the value returned from vtl fingerprint -f server.pem) See " sysconf fingerprint ntls " on page 383.
ssh	s	Display the fingerprint of the SSH certificate. (Compare this with the value presented by the SSH client upon first SSH to the SafeNet appliance admin interface.) See " sysconf fingerprint ssh " on page 384.

sysconf fingerprint license

This command displays the fingerprint for the HSM serial number. You need this fingerprint to obtain the license string associated with capability and partition upgrades.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf fingerprint license

Example

```
lunash:>sysconf fingerprint license
```

```
Fingerprint for Use With Entitlement Management System
```

```
-----  
HSM serial #66331 : *1368R7JF78AHLF2
```

```
Command Result : 0 (Success)
```

sysconf fingerprint ntl

This command displays the system's certificate fingerprints for use when ensuring that the correct server certificate was brought to a client.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf fingerprint ntl

Argument(s)	Shortcut	Description
ntl	n	Display the fingerprint of the NTLS certificate. (On the client side, you can compare this with the value returned from vtl fingerprint -f server.pem)

Example

```
lunash:>sysconf fingerprint ntl
```

```
NTLS server certificate fingerprint: AD:18:EF:C1:A3:A4:B0:59:4A:DF:8D:EB:1E:D0:3C:02:C7:A5:2D:81
```

```
Command Result : 0 (Success)
```

sysconf fingerprint ssh

This command displays the system's certificate fingerprint for use when ensuring that ssh connections are being made to the correct host.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf fingerprint ssh

Argument(s)	Shortcut	Description
ssh	s	Display the fingerprint of the SSH certificate. (Compare this with the value presented by the SSH client upon first SSH to the SafeNet appliance admin interface).

Example

```
lunash:>sysconf fingerprint ssh
```

```
SSH Server Public Keys
```

```
Type  Bits  Fingerprint
```

```
-----
RSA    2048  SHA256:+Rdwts5NZKmRDmRbb18PNpsh+bIhPPxSSo4PQi/7XVo
DSA    1024  SHA256:9jSwYbRCeT4vUFp/uywspL2o7Qzd81I6OhlMp1ZH0u8
ECDSA  256   SHA256:1zJtU0ErS/z9tJtQ+UrcSxiGxVZVIGIYR8XtW7Druwo
```

```
Command Result : 0 (Success)
```


sysconf forcesologin

Access commands that allow you to enable or disable SO login enforcement, or display the current SO login enforcement setting.

When SO login enforcement is enabled, access to some LunaSH commands is restricted to the HSM SO. See ["sysconf forcesologin enable" on page 388](#) for a list of the affected commands.

Syntax

sysconf forcesologin

disable
enable
show

Argument(s)	Shortcut	Description
disable	d	Disable SO login enforcement. See "sysconf forcesologin disable" on page 387* .
enable	e	Enable SO login enforcement. See "sysconf forcesologin enable" on page 388** .
show	s	Display the current SO login enforcement setting. See "sysconf forcesologin show" on page 390 .

* On successful **hsm factoryreset** or **sysconf config factoryreset** (option "all") the SafeNet Luna Network HSM Administrator Login Enforcement feature is reset to "disabled".

** If the HSM is not initialized, then the SafeNet Luna Network HSM SO Login Enforcement feature cannot be enabled or disabled.

Most SafeNet Luna Network HSM LunaSH commands, except time- and partition-specific ones do not require the HSM Security Officer to be logged in. The SafeNet Luna Network HSM SO Login Enforcement option functions as follows:

- > Only the SO can enable SafeNet Luna Network HSM SO Login Enforcement.
- > When enabled, the feature verifies that the HSM SO is logged in before authorizing the operations described below.
- > Only the HSM SO can disable SafeNet Luna Network HSM SO Login Enforcement.

Affected commands

The affected commands include all commands that can have an effect on the HSM, its partitions, or application access to the partitions (Items that are solely appliance-level features generally are not affected).

client

- > **client assignpartition**
- > **client delete**

- > **client hostip map**
- > **client hostip unmap**
- > **client register**
- > **client revokepartition**

ntls

- > **ntls bind**
- > **ntls certificate monitor disable**
- > **ntls certificate monitor enable**
- > **ntls certificate monitor trap trigger**
- > **ntls information reset**
- > **ntls ipcheck disable**
- > **ntls ipcheck enable**
- > **ntls tcp_keepalive set**
- > **ntls threads set**
- > **ntls timer set**

sysconf

- > **sysconf config factoryreset**
- > **sysconf regencert**

sysconf forcesologin disable

Disable SO login enforcement.

You must be logged in as the HSM SO to execute this command.

The HSM must be initialized before you can execute this command. See "[hsm init](#)" on page 103 for more information.

NOTE The SO login enforcement setting persists backup and restore operations.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf forcesologin disable

Example

```
lunash:>sysconf forcesologin disable
```

```
Command Result : 0 (Success)
```

sysconf forcesologin enable

Enable SO login enforcement. You must be logged in as the HSM SO to execute this command.

SO login enforcement is reset to disabled if the HSM is factory reset using the **hsm factoryreset** or **sysconf config factoryreset** commands. The SO login enforcement setting persists backup and restore operations.

The HSM must be initialized before you can execute this command. See "[hsm init](#)" on page 103 for more information.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Affected Commands

When SO login enforcement is enabled, the following commands can be executed by the HSM Administrator only:

Client commands

- > "[client assignpartition](#)" on page 68
- > "[client delete](#)" on page 69
- > "[client hostip map](#)" on page 72
- > "[client hostip unmap](#)" on page 74
- > "[client register](#)" on page 76
- > "[client revokepartition](#)" on page 77

NTLS commands

- > "[ntls bind](#)" on page 243
- > "[ntls certificate monitor disable](#)" on page 247
- > "[ntls certificate monitor enable](#)" on page 248
- > "[ntls certificate monitor trap trigger](#)" on page 250
- > "[ntls information reset](#)" on page 254
- > "[ntls ipcheck disable](#)" on page 257
- > "[ntls ipcheck enable](#)" on page 258
- > "[ntls tcp_keepalive set](#)" on page 262
- > "[ntls threads set](#)" on page 266
- > "[ntls timer set](#)" on page 270

Sysconf commands

- > "[sysconf regencert](#)" on page 431

Syntax

sysconf forcesologin enable

Example

```
lunash:>sysconf forcesologin enable
```

Command Result : 0 (Success)

sysconf forcesologin show

Display the current SO login enforcement setting.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf forcesologin show

Example

```
lunash:>sysconf forcesologin show
```

```
HSM Administrator Login Enforcement is NOT enabled.
```

```
Command Result : 0 (Success)
```

sysconf license

Access the **sysconf license** commands to manage feature licensing for capability and partition upgrades.

Syntax

sysconf license

apply
list
revoke

Argument(s)	Shortcut	Description
apply	a	Apply a purchased upgrade license. See " sysconf license apply " on the next page.
list	l	List currently-applied upgrade licenses. See " sysconf license list " on page 393.
revoke	r	Revoke a purchased upgrade license. See " sysconf license revoke " on page 394.

sysconf license apply

This command applies a feature license entitlement for a purchased capability or partition upgrade.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf license apply -filename <filename> [-force]

Argument(s)	Shortcut	Description
-filename <filename>	-fi	The name of the file containing the license string.
-force	-fo	Force action (no prompting for confirmation).

Example

```
lunash:>sysconf license apply -filename kcda.lic -force
```

```
FwUpdate3 Application Version 2.5
```

```
SafeNet Firmware/Capability Update Utility
```

```
This is a destructive capability update
Proceed prompt bypassed
Update Result :0 (Success)
```

```
Command Result : 0 (Success)
```


sysconf license list

This command lists all currently-applied feature licenses.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Monitor
- > Operator

Syntax

sysconf license list

Example

```
lunash:>sysconf license list
```

#	FEATURE	VERSION	QUANTITY
1	LUNA_PARTITIONS	1.0	10
2	LUNA_PARTITIONS	1.0	20
3	LUNA_PARTITIONS	1.0	10

```
Command Result : 0 (Success)
```

sysconf license revoke

This command revokes a previously-applied feature license entitlement for a purchased capability or partition upgrade. Revoking a license allows you to transfer an upgrade from one HSM appliance to another.

NOTE This self-service feature is not available in the current release. Contact Thales Group Customer Care to have a license revoked.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf license revoke -feature <index> [-force]

Argument(s)	Shortcut	Description
-feature <index>	-fe	The index number (see "sysconf license list" on the previous page) of the license you wish to revoke.
-force	-fo	Force action (no prompting for confirmation).

sysconf ntp

Access the commands used to view and set the network time protocol (NTP) configuration.

Syntax

sysconf ntp

addserver
autokeyauth
deleteserver
disable
enable
listservers
log tail
ntpdate
show
status
symmetricauth

Argument(s)	Shortcut	Description
addserver	ad	Add NTP Server. See "sysconf ntp addserver" on the next page.
autokeyauth	au	NTP Autokey Authentication. See "sysconf ntp autokeyauth" on page 398.
deleteserver	de	Delete NTP Server. See "sysconf ntp deleteserver" on page 405.
disable	di	Disable NTP Service. See "sysconf ntp disable" on page 406.
enable	e	Enable NTP Service. See "sysconf ntp enable" on page 407.
listservers	li	List Configured NTP Servers. See "sysconf ntp listservers" on page 408.
log tail	lo t	NTP Log Command. See "sysconf ntp log tail" on page 409.
ntpdate	n	Set date and time using NTP. See "sysconf ntp ntpdate" on page 410.
show	sh	Show NTP Configuration. See "sysconf ntp show" on page 411.
status	st	Get NTP Service Status. See "sysconf ntp status" on page 412.
symmetricauth	sy	NTP Symmetric Key Authentication. See "sysconf ntp symmetricauth" on page 414.

sysconf ntp addserver

Add an NTP server. NTP will automatically synchronize with the highest-stratum server you add. If none of these servers are accessible, NTP will synchronize with the local clock, and may be subject to drift.

A DNS name server must be configured if you add an NTP server by hostname.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp addserver <hostname_or_ipaddress> [-**autokey** | -**key** <keyid>] [-**burst**] [-**iburst**] [-**prefer**] [-**version** <version>]

Argument(s)	Shortcut	Description
<hostname_or_ipaddress>		Specifies the hostname or IP address of the NTP Server.
- autokey	- a	Send and receive packets authenticated by the AutoKey scheme (not used with - key <keyid>).
- burst	- b	Send multiple packets when the server is reachable.
- iburst	- i	Send out bursts of 8 packets when the server is unreachable.
- key	- k	Specifies the NTP Authentication key ID (not used with AutoKey) Range: 1 to 65535
- prefer	- p	Set this server as the preferred server.
- version <version>	- v	Specifies the NTP version Valid values: 3 or 4

Example

```
lunash:>sysconf ntp addserver time.nrc.ca

NTP server 'server time.nrc.ca' added.
WARNING !! Server 'time.nrc.ca' added without authentication.
NTP is enabled
Stopping ntpd:                               [ OK ]

Starting ntpd:                                [ OK ]
Please wait to see the result .....

NTP is running
=====
```

NTP Associations Status:

```
ind assid status  conf reach auth condition  last_event cnt
=====
  1  1310  9024  yes   yes none    reject   reachable  2
  2  1311  8011  yes   no  none    reject   mobilize   1
=====
```

Please look at the ntp log to see any potential problem.

Command Result : 0 (Success)

sysconf ntp autokeyauth

Access commands that allow you to configure Autokey NTP server authentication.

When you add a trusted NTP server, SafeNet Luna Network HSM and the server negotiate, exchange certificates, and so on. You can optionally choose to use AutoKey to authenticate your connection. Additionally, if using AutoKey, you can optionally choose to use one of the supported identity schemes, IFF (Identify Friend or Foe), GQ (Guillou-Quisquater), or MV (Mu-Varadharajan), or by default none of those schemes, and just exchange private certificates.

Syntax

sysconf ntp autokeyauth

clear
generate
install
list
update

Argument(s)	Shortcut	Description
clear	c	Delete all keys and certificates. See " sysconf ntp autokeyauth clear " on the next page.
generate	g	Generate client keys and certificates (required to use AutoKey). See " sysconf ntp autokeyauth generate " on page 400.
install	i	Install Autokey Identity Scheme IFF GQ MV (optional). See " sysconf ntp autokeyauth install " on page 402.
list	l	Show Autokey keys and certificates. " sysconf ntp autokeyauth list " on page 403.
update	u	Update client certificates (a certificate usually has a ttl of one year, after which you must update to renew). " sysconf ntp autokeyauth update " on page 404.

sysconf ntp autokeyauth clear

Delete all Autokey authentication keys and certificates.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp autokeyauth clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp autokeyAuth clear
```

```
WARNING !! This command deletes all NTP Autokey keys and certificates.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
All key and certificates files were deleted.
You must restart NTP for the changes to take effect.
Check NTP status after restarting it to make sure that the client is able to start and sync with
the server.
```

```
Command Result : 0 (Success)
```

sysconf ntp autokeyauth generate

Generate new keys and certificates for NTP public key authentication

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp autokeyauth generate [-certalg <certalg>] [-modulus <modulus>] [-signalg <signalg>] [-password <ntpkey>]

Argument(s)	Shortcut	Description
-certalg <certalg>	-c	NTP Certificate Algorithm. Valid values: RSA-SHA1, DSA-SHA1 Default: RSA-SHA1
-modulus <modulus>	-m	NTP Modulus Size. Only 2048-bit keys are currently supported, so it is not necessary to include this option. Default: 2048
-password <ntpkey>	-p	NTP Symmetric Key Value
-signalg <signalg>	-s	NTP Sign Algorithm Valid values: RSA, DSA Default: RSA

NOTE If you set the signing algorithm to DSA (**-signalg sha**), specify DSA-SHA1, not DSA-SHA, for the certificate algorithm (**-certalg dsa-sha1**). Using DSA-SHA will cause a 'invalid digest type' error.

Example

```
lunash:>sysc ntp autokeyAuth generate
```

```
Generate new keys and certificates using ntp-keygen
WARNING ! Generating keys without client Password.
```

```
Generating new keys and certificates using these arguments: -S RSA -c RSA-SHA1 -m 2048
```

```
Using OpenSSL version OpenSSL 1.0.1e-fips 11 Feb 2013
Using host sadoc78 group sadoc78
Generating RSA keys (2048 bits)...
RSA 0 43 77      1 2 6          3 1 2
Generating new host file and link
```



```
ntpkey_host_sadoc78->ntpkey_RSAhost_sadoc78.3699032190
Generating RSA keys (2048 bits)...
RSA 0 2 974      1 2 12                3 1 4
Generating new sign file and link
ntpkey_sign_sadoc78->ntpkey_RSAsign_sadoc78.3699032190
Generating new certificate sadoc78 RSA-SHA1
X509v3 Basic Constraints: critical,CA:TRUE
X509v3 Key Usage: digitalSignature,keyCertSign
Generating new cert file and link
ntpkey_cert_sadoc78->ntpkey_RSA-SHA1cert_sadoc78.3699032190
```

You must restart NTP for the changes to take effect.
Check NTP status after restarting it to make sure that the client is able to start and sync with the server.

Command Result : 0 (Success)

sysconf ntp autokeyauth install

Install an Autokey Identity scheme.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp autokeyauth install -idscheme <identscheme> **-keyfile** <filename>

Argument(s)	Shortcut	Description
-idscheme <identscheme>	-i >	Specifies the NTP AutoKey Identity Scheme to install. Valid values: IFF, GQ, or MV
-keyfile <filename>	-k	Specifies the keyfile name.

sysconf ntp autokeyauth list

List the NTP Autokey authentication keys.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp autokeyauth list

Example

```
lunash:>sysc ntp autokeyAuth list
```

```
===== Installed keys and certificates: =====
ntpkey_RSA-SHA1cert_sadoc78.3699032190
ntpkey_cert_sadoc78 -> ntpkey_RSA-SHA1cert_sadoc78.3699032190
ntpkey_RSAsign_sadoc78.3699032190
ntpkey_sign_sadoc78 -> ntpkey_RSAsign_sadoc78.3699032190
ntpkey_RSAhost_sadoc78.3699032190
ntpkey_host_sadoc78 -> ntpkey_RSAhost_sadoc78.3699032190

===== Certificate details: =====
Certificate File: ntpkey_RSA-SHA1cert_sadoc78.3699032190
Certificate:
  Data:
    Version: 3 (0x2)
    Serial Number: 3699032190 (0xdc7ac07e)
  Signature Algorithm: sha1WithRSAEncryption
  Issuer: CN=sadoc78
  Validity
    Not Before: Mar 20 20:56:30 2017 GMT
    Not After : Mar 20 20:56:30 2018 GMT
  Subject: CN=sadoc78
  X509v3 extensions:
    X509v3 Basic Constraints: critical
      CA:TRUE
    X509v3 Key Usage:
      Digital Signature, Certificate Sign
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp autokeyauth update

Update the client certificates and keys.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp autokeyauth update

Example

```
lunash:>sysconf ntp autokeyAuth update
```

```
----- Updating client autokey certificate -----  
client password not configured.  
Updating certificates without password.
```

```
Using OpenSSL version OpenSSL 1.0.1e-fips 11 Feb 2013  
Using host sadoc78 group sadoc78  
Using host key ntpkey_RSAbost_sadoc78.3699032190  
Using sign key ntpkey_RSAsign_sadoc78.3699032190  
Generating new certificate sadoc78 RSA-SHA1  
X509v3 Basic Constraints: critical,CA:TRUE  
X509v3 Key Usage: digitalSignature,keyCertSign  
Generating new cert file and link  
ntpkey_cert_sadoc78->ntpkey_RSA-SHA1cert_sadoc78.3699032190
```

You must restart NTP for the changes to take effect.
Check NTP status after restarting it to make sure that the client is able to start and sync with the server.

```
Command Result : 0 (Success)
```

sysconf ntp deleteserver

Delete an NTP server.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp deleteserver <hostname_or_ipaddress>

Argument(s)	Description
<hostname_or_ipaddress>	Specifies the hostname or IP address of the NTP server to delete.

Example

```
lunash:> sysconf ntp deleteserver time.nrc.ca
```

```
NTP server time.nrc.ca deleted.
```

```
Stopping ntpd: [ OK ]
```

```
Starting ntpd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ntp disable

Disable and stop the NTP service.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp disable

Example

```
lunash:>sysconf ntp disable
```

```
NTP is disabled
```

```
Stopping ntpd:
```

```
NTP is stopped
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ntp enable

Enable and start the NTP service.

This command enables the service after it has been stopped, such as with **sysconf ntp disable**. This command is normally not needed with **sysconf ntp addserver**, which includes restarting of the NTP service.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp enable

Example

```
lunash:>sysconf ntp enable
```

```
NTP is enabled
Stopping ntpd:                [ OK ]

Starting ntpd:                [ OK ]
Please wait to see the result .....
```

```
NTP is running
```

```
=====
NTP Associations Status:
```

```
ind assid status  conf reach auth condition  last_event cnt
=====
  1  4000  9024  yes  yes  none    reject   reachable  2
  2  4001  8011  yes   no  none    reject   mobilize   1
=====
```

```
Please look at the ntp log to see any potential problem.
```

```
Command Result : 0 (Success)
```

sysconf ntp listservers

List the configured NTP servers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf ntp listservers

Example

```
lunash:> sysconf ntp listservers
```

```
=====
NTP Servers:
server time.nrc.ca
=====
```

```
Command Result : 0 (Success)
```


sysconf ntp log tail

Display the NTP logs.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp log tail [-entries <logentries>]

Argument(s)	Shortcut	Description
-entries <logentries>	-e	Specifies the number of entries to display. Range: 0 to 2147483647

Example

```
lunash:> sysconf ntp log tail -entries 12
```

```
=====
syslog tail -l ntp -e 12
20 Mar 00:08:54 ntpd[842]: 0.0.0.0 064d 0d kern PPS no signal
20 Mar 00:43:48 ntpd[842]: 0.0.0.0 065d 0d kern PPS no signal
20 Mar 01:28:25 ntpd[842]: 0.0.0.0 066d 0d kern PPS no signal
20 Mar 02:03:54 ntpd[842]: 0.0.0.0 067d 0d kern PPS no signal
20 Mar 02:39:02 ntpd[842]: 0.0.0.0 068d 0d kern PPS no signal
20 Mar 03:14:38 ntpd[842]: 0.0.0.0 069d 0d kern PPS no signal
20 Mar 03:49:00 ntpd[842]: 0.0.0.0 06ad 0d kern PPS no signal
20 Mar 04:41:50 ntpd[842]: 0.0.0.0 06bd 0d kern PPS no signal
20 Mar 05:33:49 ntpd[842]: 0.0.0.0 06cd 0d kern PPS no signal
20 Mar 06:27:09 ntpd[842]: 0.0.0.0 06dd 0d kern PPS no signal
20 Mar 07:02:59 ntpd[842]: 0.0.0.0 06ed 0d kern PPS no signal
20 Mar 07:37:55 ntpd[842]: 0.0.0.0 06fd 0d kern PPS no signal
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp ntpdate

Set the date and time using NTP.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp ntpdate <hostname_or_ipaddress> [-key <keyid>] [-version <version>]

Argument(s)	Shortcut	Description
<hostname_or_ipaddress>		Specifies the hostname or IP address of the NTP server.
-key <keyid>	-k	NTP Authentication Keyid Range: 1 to 65535
-version <version>	-v	Specifies the NTP version Valid values: 3 or 4

Example

```
lunash:>sysconf ntp ntpdate time.nrc.ca
```

This command sets the date and time using ntp server "time.nrc.ca" if NTP daemon is not running.

```
Current time before running ntpdate: Mon Mar 20 17:15:20 EDT 2017
```

```
Current time after running ntpdate: Mon Mar 20 17:15:35 EDT 2017
```

```
Command Result : 0 (Success)
```

sysconf ntp show

Display the NTP configuration.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf ntp show

Example

```
lunash:>sysconf ntp show
```

```
----- NTP Version -----
ntpq 4.2.8p8@1.3265-o Wed Nov  9 19:44:21 UTC 2016 (1)
===== NTP Configuration =====
restrict default kod limited nomodify notrap nopeer noquery ignore
restrict -6 default kod limited nomodify notrap nopeer noquery ignore
restrict 127.0.0.1
restrict -6 ::1
fudge 127.127.1.0 stratum 10
----- NTP Servers -----
server 127.127.1.0
server time.nrc.ca
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp status

Display the NTP service status.

A “+” in front of an NTP server name means that it’s a good candidate for synchronization. More than one NTP server could be a good candidate.

A “*” in front of an NTP server name means that it’s the source of synchronization and the client has been synchronized to it. Only one NTP server at a time will be chosen as the source of synchronization.

NOTE The command **sysconf ntp status** sends packets to the configured NTP servers. The response time from the server using unreliable UDP protocol, especially over large distances, is random due to the network delay, server availability etc. If no response is received from the server, the command eventually times out after some attempts; this causes a ‘random’ delay in the command output. Five-to-ten seconds seems to be the timeout period if no response is received from the server. The default timeout is 5000 milliseconds. Note that since the command retries each query once after a timeout, the total waiting time for a timeout will be twice the timeout value set. For these reasons, you might see the command output begin, then pause for several seconds, before resuming. In other network configurations, and with “nearby” fast-responding NTP servers configured, you might never notice a pause.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf ntp status

Example

```
lunash:> sysconf ntp status
```

```
NTP is running
NTP is enabled
Peers:
=====
remote          refid          st t when poll reach  delay  offset  jitter
=====
*LOCAL(0)       .LOCL.         10 1  15   64    7      0.000  0.000  0.000
=====
Associations:
=====
ind assid status  conf reach auth condition  last_event cnt
=====
  1 12393  963a  yes   yes  none  sys.peer  sys_peer  3
=====
NTP Time:
=====
```

```
ntp_gettime() returns code 0 (OK)
time d2407aa3.4e858000 Wed, Oct 12 2011 13:44:19.306, (.306725),
maximum error 8020716 us, estimated error 0 us
ntp_adjtime() returns code 0 (OK)
modes 0x0 (),
offset 0.000 us, frequency 0.000 ppm, interval 1 s,
maximum error 8020716 us, estimated error 0 us,
status 0x1 (PLL),
time constant 2, precision 1.000 us, tolerance 512 ppm,
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth

Access commands that allow you to manage NTP symmetric keys.

Syntax

sysconf ntp symmetricauth

key
trustedkeys

Argument(s)	Shortcut	Description
key	k	Manage symmetric keys. See " sysconf ntp symmetricauth key " on the next page.
trustedkeys	t	Manage trusted symmetric keys. See " sysconf ntp symmetricauth trustedkeys " on page 420.

sysconf ntp symmetricauth key

Access commands that allow you to manage the NTP symmetric authentication keys.

Syntax

sysconf ntp symmetricauth key

add
clear
delete
list

Argument(s)	Shortcut	Description
add	a	Add a symmetric authentication key. See " sysconf ntp symmetricauth key add " on the next page.
clear	c	Delete all NTP symmetric authentication keys. See " sysconf ntp symmetricauth key clear " on page 417.
delete	d	Delete an NTP symmetric authentication key. See " sysconf ntp symmetricauth key delete " on page 418.
list	l	List all of the currently configured NTP symmetric keys. See " sysconf ntp symmetricauth key list " on page 419.

sysconf ntp symmetricauth key add

Add an NTP symmetric authentication key.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp symmetricauth key add -id <keyid> -type <keytype> -value <ntpkey>

Argument(s)	Shortcut	Description
-id <keyid>	-i	Specifies the key ID. Range: 1 to 65535
-type <keytype>	-t	Specifies the key type. Valid values: M,S,A,N
-value <ntpkey>	-v	Specifies the key value.

sysconf ntp symmetricauth key clear

Delete all symmetric Authentication Keys.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp symmetricauth key clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp symmetricAuth key clear
```

```
WARNING !! This command deletes all NTP symmetric keys.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
You must restart NTP for the changes to take effect.
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth key delete

Delete a single-named authentication key from the appliance's list.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp symmetricauth key delete -id <keyid> -force

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-id <keyid>	-i	Specifies the ID of the NTP authentication key to delete.

Example

```
lunash:>sysconf ntp symmetricauth key delete someid
```

```
someid deleted
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth key list

List the NTP symmetric authentication keys.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf ntp symmetricauth key list

Example

```
lunash:>sysconf ntp symmetricauth key list
```

```
NTP Symmetric Authentication Keys:
```

```
=====
```

keyId	keyType	KeyValue
2	M	*****

```
=====
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth trustedkeys

Access commands that allow you to manage symmetric NTP authentication trusted keys.

Syntax

sysconf ntp symmetricauth trustedkeys

add
clear
delete
list

Argument(s)	Shortcut	Description
add	a	Add a symmetric NTP authentication trusted key. See " sysconf ntp symmetricauth trustedkeys add " on the next page.
clear	c	Delete all symmetric NTP authentication trusted keys. See " sysconf ntp symmetricauth trustedkeys clear " on page 422.
delete	d	Delete an symmetric NTP authentication trusted key. See " sysconf ntp symmetricauth trustedkeys delete " on page 423.
list	l	List all of the currently configured symmetric trusted NTP keys. See " sysconf ntp symmetricauth trustedkeys list " on page 424.

sysconf ntp symmetricauth trustedkeys add

Add a trusted authentication key. The key should have already been added using the **sysconf ntp symmetricAuth key add** command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp symmetricauth trustedkeys add -id <keyid>

Argument(s)	Shortcut	Description
-id <keyid>	-i	Specifies the ID of the key to add. Range: 1 to 65535

sysconf ntp symmetricauth trustedkeys clear

Delete all Trusted Authentication Keys.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp symmetricauth trustedkeys clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp symmetricauth trustedkeys clear
```

```
WARNING !! This command deletes all NTP symmetric trusted keys.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth trustedkeys delete

Delete a single named trusted authentication key from the appliance's list of trusted NTP servers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ntp symmetricauth trustedkeys delete -id <keyid> [-force]

Argument(s)	Shortcut	Description
-id <keyid>	-i	Specifies the ID of the key you want to delete. Range: 1-65535
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf ntp symmetricauth trustedkeys delete someid
```

```
someid deleted
```

```
Command Result : 0 (Success)
```

sysconf ntp symmetricauth trustedkeys list

Lists the trusted authentication keys in the appliance's list of trusted NTP servers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf ntp symmetricauth trustedkeys list

Example

```
lunash:>sysconf ntp symmetricauth trustedkeys list
```

```
current trustedkeys:
```

```
Command Result : 0 (Success)
```


sysconf radius

Manage the appliance-side configuration of appliance-user authentication via a RADIUS server.

Syntax

sysconf radius

addserver
deleteserver
disable
enable
show

Argument(s)	Shortcut	Description
addserver	a	Add a RADIUS server. See " sysconf radius addserver " on the next page .
deleteserver	de	Remove a RADIUS server. See " sysconf radius deleteserver " on page 427 .
disable	di	Disable RADIUS for SSH. See " sysconf radius disable " on page 428 .
enable	e	Enable RADIUS for SSH. See " sysconf radius enable " on page 429 .
show	s	Show RADIUS configuration. See " sysconf radius show " on page 430 .

For RADIUS configuration instructions, see "[\[Optional\] Configure for RADIUS Authentication](#)" on [page 1](#).

sysconf radius addserver

Identify a RADIUS server to the SafeNet Luna Network HSM, specifying the server's hostname or IP.

NOTE RADIUS must already be enabled, by means of command **sysconf radius enable**, before you can run this command to add a RADIUS server. In addition to enabling RADIUS, you must run the **sysconf radius addServer** command to identify the RADIUS server, as well as the **user role radiusAdd** and **user role add** commands to create a user on this appliance with the desired name, and identify that role as requiring RADIUS to authenticate.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf radius addserver -server <hostname> -port <port> -timeout <seconds>

Argument(s)	Shortcut	Description
-server <hostname>	-s	Host name
-port <port>	-p	Network port Range: 0 to 65535
-timeout <seconds>	-t	Time in seconds Range: 1 to 300

Example

```
lunash:>sysconf radius addserver -server 192.20.15.182 -port 1812 -timeout 60
```

Enter the server secret:

Re-enter the server secret:

Command Result : 0 (Success)

sysconf radius deleteserver

Remove a RADIUS server from the SafeNet Luna Network HSM, specifying the server's hostname or IP.

NOTE This command can be run only while RADIUS is enabled on the SafeNet Luna Network HSM.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf radius deleteserver -server <hostname>

Argument(s)	Shortcut	Description
-server <hostname>	-s	Host name of server to be deleted.

Example

```
lunash:>sysconf radius deleteserver -server 192.20.15.182
```

Command Result : 0 (Success)

sysconf radius disable

Disable RADIUS service on SafeNet Luna Network HSM.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf radius disable

Example

```
lunash:>sysconf radius disable
```

```
Command Result : 0 (Success)
```

sysconf radius enable

Enable RADIUS service on SafeNet Luna Network HSM.

NOTE In addition to enabling RADIUS, you must run the **sysconf radius addserver** command to identify the RADIUS server, as well as the **user role radiusadd** and **user role add** commands to create a user on this appliance with the desired name, and identify that role as requiring RADIUS to authenticate.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf radius enable

Example

```
lunash:>sysconf radius enable
```

Command Result : 0 (Success)

sysconf radius show

Show the current RADIUS configuration and status.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf radius show

Example

```
lunash:>sysconf radius show
```

RADIUS for SSH is enabled with the following deployed servers:

server:port	timeout
-----	-----
192.20.15.182:1812	60

Command Result : 0 (Success)

sysconf regencert

Generate or regenerate the SafeNet Luna Network HSM server certificate used for NTLS and save it to the appliance file system.

This command stores the resulting private and public keys, and the certificate generated from them, on the file system (hard disk) inside the SafeNet appliance.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf regencert [<device_ip_address>] [-startdate <startdate>] [-days <days>] [-force]

Argument(s)	Shortcut	Description
<device_ip_address>		Specifies the IP address to set as the CN of the server's NTLS certificate. If not specified, the CN will be the hostname of the SafeNet Luna Network HSM appliance, as specified by the network hostname command. See " network hostname " on page 213 for more information.
-days <days>	-d	Specifies the number of days for which the new certificate will remain valid, starting on <startdate>. Range: 1-3653 Default: 3653 (10 years)
-force	-f	Force the action without prompting.
-startdate <startdate>	-s	Specifies the starting date upon which the certificate becomes valid, in the format YYYYMMDD. The default is 24 hours ago, to eliminate possible time zone mismatch issues if you need the certificate to be valid immediately anywhere in the world.

Example

```
lunash:>sysconf regencert
```

```
WARNING !! This command will overwrite the current server certificate and private key.
           All clients will have to add this server again with this new certificate.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'
```

```
> proceed
Proceeding...
```

```
'sysconf regenCert' successful. The NTLS, STC and CBS services must be (re)started before clients
can connect.
```

Please use the 'ntls show' command to ensure that NTLS is bound to an appropriate network device or IP address/hostname for the network device(s) NTLS should be active on. Use 'ntls bind' to change this binding if necessary.

Command Result : 0 (Success)

sysconf reimage

Access commands that restore the appliance to the pre-installed baseline software image and the HSM firmware to the baseline version.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf reimage

start
tarlog

Argument(s)	Shortcut	Description
start	s	Re-image the appliance and the HSM to the pre-installed baseline software/firmware versions. See " sysconf reimage start " on the next page .
tarlog	t	Retrieve the archived log file for the most recent re-imaging procedure. See " sysconf reimage tarlog " on page 436 .

sysconf reimage start

Restore the appliance and the HSM to the following pre-installed baseline software/firmware versions:

- > Appliance software: **7.2**
- > HSM firmware: **7.0.3**

You must be logged in as HSM SO to use this command.

CAUTION! This command is destructive; all partitions and cryptographic objects will be destroyed, and the HSM must be re-initialized. The operation takes 15-20 minutes, and the appliance reboots twice. Do not reboot the appliance manually during this time. Ensure that you have a power backup in place before re-imaging the appliance.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

sysconf reimage start [-base]

Argument(s)	Shortcut	Description
-base	-b	Restore the SafeNet Luna Network HSM to its original capability settings. With this option included, licenses such as partition packs are not preserved after the appliance re-image process. Purchased update licenses are still valid, and you can re-apply them (or apply them to a different SafeNet Luna Network HSM) using the Thales Group Licensing Portal.

Example

```
lunash:>sysconf reimage start
```

```
The HSM Administrator is logged in. Proceeding...
```

```
To remove audit logs from the HSM, you must configure the Audit Logs feature.
```

```
If you do not configure Audit Logs before re-imaging, the existing audit log history will be retained in the HSM.
```

```
Type 'proceed' to continue the re-imaging process without configuring Audit Logs, or 'quit' to cancel.
```

```
> proceed
Proceeding...
```

```
WARNING: This operation will revert the Luna Network HSM to the baseline of software 7.2.0-220 with firmware 7.0.3 !!!
```

- (1) This is a destructive operation that erases all partitions and key material.
- (2) Ensure that you have a valid backup of all your partitions.

- (3) After completion, you must re-initialize the HSM.
- (4) After completion, remote PED must be re-connected.
- (5) This operation takes 20-30 minutes. Make sure you have power backup in place.
- (6) Access to the appliance will be unavailable. DO NOT restart the appliance during this time.
- (7) The operation erases all appliance logs.
- (8) The re-imaging operation will generate additional audit logs in the HSM.
- (9) The re-imaging procedure includes multiple appliance reboot.
- (10) This operation CANNOT be undone.

Type 'proceed' to continue, or 'quit' to quit now.

```
> proceed
```

```
Proceeding...
```

```
Step 1 of 8: Backing up the appliance support information
```

```
...
```

```
Done
```

```
Step 2 of 8: Setting up the environment for re-imaging.
```

```
...
```

```
Done
```

```
Step 3 of 8: Extracting the packages
```

```
...
```

```
This step may take a few minutes... |
```

```
Done
```

```
Step 4 of 8: Preparing the Luna Network HSM baseline installation scripts
```

```
...
```

```
Done
```

```
Step 5 of 8: Updating to the Luna Network HSM baseline firmware
```

```
...
```

```
This step may take a few minutes... |
```

```
Done
```

```
Step 6 of 8: Prepare for Luna Network HSM licenses installation
```

```
...
```

```
This step may take a few minutes... |
```

```
Step 7 of 8: Installing Luna Network HSM Base licenses
```

```
...
```

```
This step may take a few minutes... /
```

```
Done
```

```
Step 8 of 8: Zeroize Luna Network HSM
```

```
...
```

```
The Luna Network HSM with baseline firmware version has been zeroized
```

The Luna Network HSM will restart multiple times to complete the baseline installation.

This process could take up to 15 minutes.

Please wait for the operation to complete as interrupting the process could have adverse effects.

sysconf reimaged tarlog

Retrieve the archived log file produced during the last appliance re-image operation. After running **sysconf reimaged tarlog**, the file **Baseline_Re_image_logs.<timestamp>.tar.gz** can be viewed in the **admin** user's files using `lunash:>my file list` (see ["my file list" on page 196](#)) and transferred to a client workstation with **scp/pscp**.

User Privileges

Users with the following privileges can perform this command:

- > Admin

Syntax

sysconf reimaged tarlog

Example

```
lunash:>sysconf reimaged tarlog
```

```
'hsm reimaged tarlogs' successful
```

Use 'scp' from a client machine to get file named:
`Baseline_Re_image_logs.20180614_14.40.40.tar.gz`

```
Command Result : 0 (Success)
```

sysconf snmp

Access commands that allow you to configure the Simple Network Management Protocol (SNMP) settings for SafeNet appliance, and enable or disable the service. At least one user must be configured before the SNMP agent can be accessed.

Syntax

sysconf snmp

disable
enable
notification
show
trap
user

Argument(s)	Shortcut	Description
disable	d	Disable the SNMP service. See "sysconf snmp disable" on the next page .
enable	e	Enable the SNMP service. See "sysconf snmp enable" on page 439 .
notification	n	Access commands that allow you to view or configure the notifications that can be sent by the SNMP agent. See "sysconf snmp notification" on page 440 .
show	s	Display SNMP service information. See "sysconf snmp show" on page 446 .
trap	t	Access commands that allow you to view or configure the SNMP trap hosts. See "sysconf snmp trap" on page 447 .
user	u	Access commands that allow you to view or configure the users that can access the SNMP agent. See "sysconf snmp user" on page 455 .

sysconf snmp disable

Disable and stop the SNMP service.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp disable

Example

```
lunash:>sysconf snmp disable
```

```
SNMP is disabled
```

```
Starting snmpd:
```

```
SNMP is stopped
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

sysconf snmp enable

Enable and start the SNMP service.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp enable

Example

```
lunash:>sysconf snmp enable
```

```
SNMP is enabled  
Starting snmpd:  
SNMP is started
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

sysconf snmp notification

Access command that allow you to view and configure the notifications that can be sent by the SNMP agent. At least one user must be configured before the SNMP agent can be accessed.

Syntax

sysconf snmp notification

add
clear
delete
list

Argument(s)	Shortcut	Description
add	a	Add a notification target . See "sysconf snmp notification add" on the next page.
clear	c	Delete all notification targets. See "sysconf snmp notification clear" on page 443.
delete	d	Delete a notification target. See "sysconf snmp notification delete" on page 444.
list	l	Display a list of the notification targets. See "sysconf snmp notification list" on page 445.

sysconf snmp notification add

Add a single notification destination to be notified via the SNMP service.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp notification add **-ipaddress** <ipaddress> **-authpassword** <password> **-privpassword** <password> **-secname** <userid> [**-authprotocol** <protocol>] [**-notifytype** {trap | inform}] [**-privprotocol** <protocol>] [**-udpport** <port>] [**-engineid** <engineid>]

Argument(s)	Shortcut	Description
-authpassword <password>	-authpa	Specifies the authentication password. The password may be 8-to-128 characters long.
-authprotocol <protocol>	-authpr	Specifies the authentication protocol. Valid values: SHA Default: SHA
-engineid <engineid>	-e	Specifies the SNMP v3 Engine ID in hex numbers. No 0x or 0X is permitted.
-ipaddress <ipaddress>	-i	Specifies the IPv4 address of the destination (a machine running snmptrapd from Net-SNMP or some other SNMP management application, such as MG-Soft's MIB Browser or HP's Openview.)
-notifytype <type>	-n	Specifies the notification type. Valid values: trap: one-way unconfirmed notification inform: confirmed notification with retries Default: trap
-privpassword <password>	-privpa	Specifies the privacy password or encryption password. The password may be 8-to-128 characters long.
-privprotocol <protocol>	-privpr	Specifies the AES privacy protocol.
-secname <userid>	-s	Specifies the security name or user name for this user. The user name may be 1-to-31 characters. In the context of notifications this is the "Security Name" on whose behalf notifications are sent.

Argument(s)	Shortcut	Description
-udpport <port>	-u	Specifies the UDP port on the notification target host to which notifications are sent. 162 is the SNMP default port for notifications. Default: 162

Example

```
lunash:>sysconf snmp notification add -ipaddress 10.124.0.87 -authpassword authPa$$w0rd -  
privpassword privPa$$w0rd -secname admin -engineid 0029403200
```

```
SNMP notification target information added
```

```
Command Result : 0 (Success)
```

sysconf snmp notification clear

Deletes all users that are currently configured to use the SNMP command with this SafeNet appliance. If you do not use the **-force** option, a prompt requires you to type "proceed" if the operation is to go ahead - otherwise, it is aborted.

This command is most useful if you have a number of SNMPv3 notification targets defined and wish to delete all targets. This command is also useful for LunaSH scripts that need to ensure that all SNMPv3 notification targets have been deleted and that there is thus a clean and empty SNMP notification target configuration.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp notification clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf snmp notification clear
```

```
WARNING !! This command deletes all notification target information from the SNMP Agent.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
SNMP notification target information cleared
```

```
Command Result : 0 (Success)
```

sysconf snmp notification delete

Delete all notification targets that are configured for IP address <ipaddress> and UDP Port <udpPort>. It is possible that there are 0, 1 or multiple such notification targets configured. (They could be using different values for <notifyType> and/or <secName> although this would not be common.) Note that if <udpPort> is not specified, then only notification targets configured for the default SNMP UDP port 162 will be deleted.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp notification delete -ipaddress <ipaddress> [-udpport <port>]

Argument(s)	Shortcut	Description
-ipaddress <ipaddress>	-i	Specifies the IP address of the notification target to delete.
-udpport <port>	-u	Specifies the UDP port of the notification target to delete. Range: 0-65535 Default: 162

Example

```
lunash:>sysconf snmp notification delete -ipaddress 192.20.11.64
```

```
SNMP notification target information deleted
```

```
Command Result : 0 (Success)
```

sysconf snmp notification list

Lists the targets to which SNMPv3 notifications (traps or informs) will be sent.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf snmp notification list

Example

```
lunash:>sysconf snmp notification list
```

```
SNMP Notification Targets:
-----
10.124.0.87:162 "0029403200" "admin"
192.20.11.64:162 "00473984504" "James"
```

```
Command Result : 0 (Success)
```

In this example, the output conveys the following information:

Field	Description
10.124.0.87 192.20.11.64	The IP addresses of the notification target hosts (A machine running snmptrapd from Net-SNMP or some other SNMP management application, such as MG-Soft's MIB Browser or HP's Openview.)
162	The UDP port on the notification target host to which notifications are sent. 162 is the SNMP default port for notifications.
admin James	The "Security Names" (or user names) on whose behalf notifications are sent.
0029403200 00473984504	The SNMP v3 Engine ID (hex).

sysconf snmp show

Display SNMP service information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf snmp show

Example

```
lunash:>sysconf snmp show
```

```
SNMP is running  
SNMP is enabled
```

```
Command Result : 0 (Success)  
lunash:>
```

sysconf snmp trap

Access commands that allow you to view or configure SNMP trap hosts.

Syntax

sysconf snmp trap

clear
disable
enable
set
show
test

Argument(s)	Shortcut	Description
clear	c	Clear SNMP trap host information. See " sysconf snmp trap clear " on the next page.
disable	d	Disable and stop the SafeNet SNMP Trap Agent (Ista). See " sysconf snmp trap disable " on page 449.
enable	e	Enable and start the SafeNet SNMP Trap Agent (Ista). See " sysconf snmp trap enable " on page 450.
set	se	Set SNMP trap host information. See " sysconf snmp trap set " on page 451.
show	sh	Display SNMP trap host information. See " sysconf snmp trap show " on page 452.
test	t	Test SNMP trap notification. See " sysconf snmp trap test " on page 453.

sysconf snmp trap clear

Deletes all SNMP Trap Host Information.

NOTE After running this command, you must restart the lsta service with the command **service restart lsta** for the configuration change to take effect.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp trap clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf snmp trap clear
```

If you are sure that you wish to clear snmp trap information, then enter 'proceed', otherwise type 'quit'.

```
> proceed
Proceeding...
```

Please use 'service restart lsta' for the new configuration to take effect.

```
Command Result : 0 (Success)
```

sysconf snmp trap disable

Disable and stop the SafeNet SNMP Trap Agent (lsta).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp trap disable

Example

```
lunash:>sysconf snmp trap disable
```

```
SNMP trap agent is disabled
```

```
Shutting down lsta:
```

```
SNMP trap agent is stopped
```

```
[ OK ]
```

```
Command Result : 0 (Success)
```

sysconf snmp trap enable

Enable and start the SafeNet SNMP Trap Agent (Ista).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp trap enable

Example

```
lunash:>sysconf snmp trap enable
```

```
SNMP trap agent is enabled
```

```
Stopping syslog:
```

```
[ OK ]
```

```
Starting syslog:
```

```
[ OK ]
```

```
Starting lsta:
```

```
[ OK ]
```

```
SNMP trap agent is started
```

```
Command Result : 0 (Success)
```

sysconf snmp trap set

Set SNMP trap host information.

NOTE After running this command, you must restart the lsta service with the command **service restart lsta** for the configuration change to take effect.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp trap set -host <hostname/IP> [**-secname** <secname>] [**-engineid** <engineID>] [**-authprotocol** <protocol>] [**-authpwd** <password>] [**-privprotocol** <protocol>] [**-privpwd** <password>]

Argument(s)	Shortcut	Description
-host <hostname/IP>	-h	Specifies the trap host name or IP address.
-secname <secname>	-s	Specifies the SNMP v3 security name.
-engineid <engineID>	-e	Specifies the SNMP v3 Engine ID (Hex Number, No 0x or 0X)
-authprotocol <protocol>	-authpr	Specifies the SNMP v3 Authentication Protocol Valid values: SHA Default: SHA
-authpwd <password>	-authpw	Specifies the SNMP v3 Authentication password
-privprotocol <protocol>	-privpr	Specifies the SNMP v3 Privacy protocol Valid values: AES Default: AES
-privpwd <password>	-privpw	Specifies the SNMP v3 Privacy Password

Example

```
lunash:>sysconf snmp trap set -host mysnmphost -secname admin -engineid 800007c70300e05290ab60 -
authprotocol SHA -authpwd p4$$w0rd -privprotocol AES -privpwd prlvat3Pwd
```

Please use 'service restart lsta' for the new configuration to take effect.

```
Command Result : 0 (Success)
```

sysconf snmp trap show

Display SNMP trap host information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf snmp trap show

Example

```
lunash:>sysconf snmp trap show
```

SNMP Trap is configured as the following:

```
SNMP Trap Host      : mysnmphot:162
SNMP Version        : 3
SNMP v3 Security Name : admin
SNMP v3 Engine ID   : 0x800007c70300e05290ab60
SNMP v3 Security Level : authPriv
SNMP v3 Authentication protocol : SHA
SNMP v3 Privacy protocol : AES
```

```
Command Result : 0 (Success)
```

sysconf snmp trap test

Test the SNMP trap notification.

This command allows an administrator to create test logs to initiate trap notifications. Refer to the *Syslog Monitoring Guide* for details of which log messages result in traps.

To initiate a trap notification use the command parameters to format and record a log message via syslog. To distinguish between messages in the logs that are generated by this command and those that represent legitimate events, all log messages generated using this command are prefixed with "***TEST :", as shown in the following example:

```
2012 Feb 29 12:05:01 myLUT daemon crit smartd[19685]: ***TEST : Device: /dev/sda, Temperature 45
Celsius reached limit of 44 Celsius (Min/Max 31/49)
```

The SafeNet administrative shell prohibits the '<' and '>' characters as parameters. However, some traps rely on the presence of these comparators in log messages. To enable test log messages of the form that need these comparators, use a ".lt" or ".gt" string in place of the '<' or '>' character in the formatted command.

NOTE This command writes a record to the applicable system log file. The command has no dependency on the status of the SafeNet SNMP Trap Daemon. To test trap generation, ensure that you have enabled traps as described in the *Syslog and SNMP Monitoring Guide*.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp trap test -logfacility <logfacility> **-loglevel** <loglevel> **-process** <process> **-message** <message> [-pid]

Argument(s)	Shortcut	Description
-logfacility <logfacility>	-logf	Specifies the log facility to use when generating the test message. Valid values: kern, user, daemon, auth, syslog, authpriv, cron, local0, local1, local2, local3, local4, local5, local6, local7
-loglevel <loglevel>	-logl	Specifies the severity level to assign to the test message. Valid values: emergency, alert, critical, crit, error, err, warning, warn, notice, info, debug
-process <process>	-pr	Specifies the system process to use when generating the test message. Valid values: Any process defined for the system. For example, NTLN, impievd, smartd, sysstatd.

Argument(s)	Shortcut	Description
-message <message>	-m	A string that specifies the body text for the test message. You must enclose the string in double quotes (" <string> ") if it contains spaces.
-pid	-pi	Add a process identifier to the test message.

Example

```
lunash:>sysconf snmp trap test -logfacility daemon -loglevel crit -process smartd -message  
"Device: /dev/sda, Temperature 45 Celsius reached limit of 44 Celsius (Min/Max 31/49)" -pid
```

```
Command Result : 0 (Success)
```

sysconf snmp user

Access commands that allow you to view and configure the users that can access the SNMP agent. At least one user must be configured before the SNMP agent can be accessed.

Syntax

sysconf snmp user

Argument(s)	Shortcut	Description
add	a	Add a user. See "sysconf snmp user add" on the next page .
clear	c	Delete all users. See "sysconf snmp user clear" on page 458 .
delete	d	Delete a user. See "sysconf snmp user delete" on page 459 .
list	l	List the currently configured users. See "sysconf snmp user list" on page 460 .

sysconf snmp user add

Add a user who can use SNMP service. To enhance security, the authpassword and the privpassword should not be set to the same value. SNMP users created with this command are automatically configured for:

- > Read (GET/GET-NEXT/GET-BULK) access to all MIB objects.
- > Write (SET) access to all MIB objects.
- > Notify (TRAP/INFORM) access to all MIB objects.

It is not possible to modify the parameters for a configured user. You must use **sysconf snmp user delete** followed by **sysconf snmp user add**.

NOTE If an SSH connection with a SafeNet Luna Network HSM appliance is terminated while the **sysconf snmp user add** command is in progress, it is not possible to reconnect immediately to re-run the command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp user add -secname <secname> -authpassword <password> -authprotocol <protocol> -privpassword <password> -privprotocol <protocol>

Argument(s)	Shortcut	Description
-secname <secname>	-s	Specifies the security name. The name may be 1-to-31 characters; this is effectively the SNMPv3 term for "User name"
-authpassword <password>	-authpa	Specifies the authentication password. The password may be 8-to-128 characters long (for better security, it should be different than the privpassword).
-authprotocol <protocol>	-authpr	Specifies the authentication protocol. Valid values: SHA Default: SHA
-privpassword <password>	-privpa	Specifies the privacy password or encryption password. The password may be 8-to-128 characters (for better security, it should be different than the password specified for authpassword).
-privprotocol <protocol>	-privpr	Specifies the privacy protocol. Valid values: AES Default: AES

Example

To create an SNMP user with the name "admin", issue the following command:

```
lunash:>sysconf snmp user add -secname admin -authpassword authPa$$w0rd -authprotocol SHA -  
privpassword privPa$$w0rd -privprotocol AES
```

```
SNMP user account "admin" added
```

```
Command Result : 0 (Success)
```

An SNMP agent on the SafeNet host "myLuna1" can then be accessed by means of the Net-SNMP snmpwalk utility, using a command like:

```
snmpwalk -v 3 -u admin -l authPriv -a SHA -A authPa$$w0rd -x AES -X privPa$$w0rd myLuna1 .1
```

sysconf snmp user clear

Delete all users that are currently configured to use the SNMP command with this SafeNet appliance. If you do not use the **-force** option, a prompt requires you to type "proceed" if the operation is to go ahead - otherwise, it is aborted.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp user clear [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>sysconf snmp user clear
```

```
WARNING !! This command deletes all user account information from the SNMP Agent.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
SNMP user account information cleared
```

```
Command Result : 0 (Success)
```

sysconf snmp user delete

Delete a specific (named) user that is currently configured to use the SNMP command with this SafeNet appliance (allowed to access the SNMP agent).

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf snmp user delete -secname <userid>

Argument(s)	Shortcut	Description
-secname <userid>	-s	Specifies the user name of the user you want to delete.

Example

```
lunash:>sysconf snmp user delete -secname User
```

```
SNMP user account "User" deleted
```

```
Command Result : 0 (Success)
```

sysconf snmp user list

Display a list of the users that are currently configured to use the SNMP command with this SafeNet appliance.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf snmp user list

Example

```
lunash:>sysconf snmp user list
```

```
SNMP Users:
```

```
-----
```

```
admin
```

```
Jon
```

```
Command Result : 0 (Success)
```

sysconf ssh

Access commands that allow you to view or configure SSH options on the appliance.

Syntax

sysconf ssh

```

device
ip
password
port
publickey
regenkeypair
show

```

Argument(s)	Shortcut	Description
device	d	Set the SSH device restriction policy. See " sysconf ssh device " on the next page.
ip	i	Set the SSH IP restriction policy. See " sysconf ssh ip " on page 463.
password	pa	Enable or disable password authentication. See " sysconf ssh password " on page 464.
port	po	Set the SSHD listen port number (22, 1024-65535). See " sysconf ssh port " on page 467.
publickey	pu	View or configure SSH public keys. See " sysconf ssh publickey " on page 468.
regenkeypair	r	Regenerate the SSH key pair. See " sysconf ssh regenkeypair " on page 471
show	s	Display the currently set SSH restriction policies. See " sysconf ssh show " on page 472

sysconf ssh device

Restrict the appliance/HSM administrative traffic (over SSH) to a specific Ethernet device. Use this command if you want to segregate administrative traffic (SSH) from client (NTLS) traffic. This command is an alternative to the command ["sysconf ssh ip" on the next page](#), which performs the same action by specifying an IP address that corresponds to one of your network devices.

If you wish, SSH traffic restriction could complement client traffic restriction using the command ["ntls bind" on page 243](#), which binds client (NTLS) traffic to a specific IP or device name on your SafeNet Luna Network HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh device <netdevice>

Argument(s)	Description
<netdevice>	<p>Specifies the device to which you want to restrict the SSH service.</p> <p>Valid values:</p> <p>all: Allow SSH on all devices.</p> <p>eth0: Restrict SSH connections to the eth0 interface.</p> <p>eth1: Restrict SSH connections to the eth1 interface.</p> <p>eth2: Restrict SSH connections to the eth2 interface.</p> <p>eth3: Restrict SSH connections to the eth3 interface.</p>

Example

```
lunash:>sysconf ssh device eth0
```

```
Success:  SSH now restricted to ethernet device eth0 (IP address 192.20.11.78).
          Restarting ssh service.
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ssh ip

Restrict the appliance/HSM administrative traffic (over SSH) to the indicated IP address (bound to one of the SafeNet Luna Network HSM's Ethernet ports). Use this command where you need to segregate administrative traffic from client (NTLS) traffic. This command is an alternative to the command ["sysconf ssh device" on the previous page](#), which performs the same action by specifying an Ethernet device.

If you wish, SSH traffic restriction could complement client traffic restriction using the command ["ntls bind" on page 243](#), which binds client (NTLS) traffic to a specific IP or device name on your SafeNet Luna Network HSM.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh ip <ipaddress>

Argument(s)	Description
<ipaddress>	<p>Specifies the IP address associated with the SafeNet Luna Network HSM network interface device to which you want to restrict the SSH service.</p> <p>Valid Values:</p> <ul style="list-style-type: none"> > Any specific IPv4 or IPv6 address > 0.0.0.0 (unrestricted IPv4) > :: (unrestricted IPv6)

Example

```
lunash:>sysconf ssh ip 192.20.11.78
```

```
Success:  SSH now restricted to ethernet device eth0 (IP address 192.20.11.78).
          Restarting ssh service.
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ssh password

Access commands that allow you to enable or disable SSH password authentication.

Syntax

sysconf ssh password

disable
enable

Argument(s)	Shortcut	Description
disable	d	Disable SSH password authentication. See " sysconf ssh password disable " on the next page.
enable	e	Enable SSH password authentication. See " sysconf ssh password enable " on page 466.

sysconf ssh password disable

Disable SSH password authentication.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh password disable

Example

```
lunash:>sysconf ssh password disable
```

```
Password authentication disabled
```

```
Command Result : 0 (Success)
```

sysconf ssh password enable

Enable SSH password authentication.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh password enable

Example

```
lunash:>sysconf ssh password enable
```

```
Password authentication enabled
```

```
Command Result : 0 (Success)
```

sysconf ssh port

Set the SSHD listen port number.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf ssh port <port>

Argument(s)	Description
<port>	Specifies the SSHD listen port number. Range: 22 or 1024-65535 Default: 22

Example

```
lunash:>sysconf ssh port 1024
```

This command sets the SSHD listen port number.

Please make sure that you choose a new port number which is not used by other services.

```
SSH Port Changed from 22 to: Port 1024
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ssh publickey

View or configure SSH public keys.

To add, list, delete, or clear public keys, see ["my public-key" on page 200](#).

Once you enable public key authentication for an administration computer, the private SSH key (/root/.ssh/id_rsa) must be protected, and access to that computer must be restricted and password-protected. Anyone who can log into that computer can log into the SafeNet Luna Network HSM appliance without knowing the LunaSH admin password!

Syntax

sysconf ssh publickey

disable
enable

Argument(s)	Shortcut	Description
disable	di	Disable SSH public key authentication. See "sysconf ssh publickey disable" on the next page .
enable	e	Enable SSH public key authentication. See "sysconf ssh publickey enable" on page 470 .

sysconf ssh publickey disable

Disable SSH public key authentication.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh publickey disable

Example

```
lunash:>sysconf ssh publickey disable
```

```
Public key authentication disabled
```

```
Command Result : 0 (Success)
```

sysconf ssh publickey enable

Enable SSH public key authentication.

Once you enable public key authentication for an administration computer, the private SSH key (`/root/.ssh/id_rsa`) must be protected, and access to that computer must be restricted and password-protected. Anyone who can log into that computer can log into the SafeNet Luna Network HSM appliance without knowing the LunaSH admin password!

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh publickey enable

Example

```
lunash:>sysconf ssh publickey enable
```

```
Public key authentication enabled
```

```
Command Result : 0 (Success)
```

sysconf ssh regenkeypair

Regenerate the SSH key pair.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf ssh regenkeypair

Example

```
lunash:>sysconf ssh regenkeypair
```

```
WARNING !! This command regenerates SSH keypair.
```

```
WARNING !! SSH will be restarted.
```

```
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
```

```
Proceeding...
Stopping sshd: [ OK ]
Generating SSH1 RSA host key: [ OK ]
Generating SSH2 RSA host key: [ OK ]
Generating SSH2 DSA host key: [ OK ]
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

sysconf ssh show

Display the currently configured SSH restrictions.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf ssh show

Example

```
lunash:>sysconf ssh show
```

```
SSHD configuration:
```

```
SSHD Listen Port 22
```

```
SSH is restricted to ethernet device eth0 (ip address 192.20.11.78).  
SSH is unrestricted for all IPv4 addresses.
```

```
Password authentication is enabled  
Public key authentication is enabled
```

```
Command Result : 0 (Success)
```


sysconf time

Set the appliance clock. Time and system date may be set to user-specified values. Specify the correct time zone before setting a new value for the system time. The hardware clock is automatically kept in sync whenever a change is made to the system date, time, or time zone.

You can determine the current date/time setting using the **status date** command.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf time <time> [<date>]

Argument(s)	Description
<time>	Specifies the time using 24-hour clock in the following format: HH:MM
<date>	Set the date along with system time. Specify the date using the following format: YYYYMMDD

Example

```
lunash:>sysconf time 13:58 20170301
```

```
Wed Mar 1 13:58:00 EST 2017
```

```
Command Result : 0 (Success)
```

sysconf timezone

Show and set the time zone for the appliance's clock. This command allows the administrator to check and set the system time zone.

Syntax

sysconf timezone

set
show
list

Argument(s)	Shortcut	Description
list	l	Displays a list of accepted time zone codes and regions. See "sysconf timezone list" on the next page .
set	se	Set time zone. See "sysconf timezone set" on page 476 .
show	sh	Shows the current time zone setting. See "sysconf timezone show" on page 477 .

sysconf timezone list

Displays a list of accepted time zone codes and regions.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf timezone list <region>

Argument(s)	Description
<region>	Specifying a <region> parameter will produce a list of time zones associated with that region. See " Setting the Time Zone " on page 1 for more information on correct time zone abbreviations.

Example

```
lunash:>sysconf timezone list Kentucky
```

```
Available time zones:
```

```
posix/America/Kentucky
posix/America/Kentucky/Monticello
posix/America/Kentucky/Louisville
America/Kentucky
America/Kentucky/Monticello
America/Kentucky/Louisville
right/America/Kentucky
right/America/Kentucky/Monticello
right/America/Kentucky/Louisville
```

```
Command Result : 0 (Success)
```

sysconf timezone set

Set time zone.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

sysconf timezone set <time_zone>

Argument(s)	Shortcut	Description
<time_zone>	se	Set time zone. For a list of accepted time zone abbreviations, use the command sysconf timezone list , or see https://en.wikipedia.org/wiki/List_of_tz_database_time_zones .

Example

```
lunash:>sysconf timezone set EST5EDT
Time zone set to EST5EDT
```

sysconf timezone show

Shows the current time zone setting. This changes depending on whether Daylight Saving Time is in effect. See "[Setting the Time Zone](#)" on [page 1](#) for more information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf timezone show

Example

```
lunash:>sysconf timezone show  
EST
```

sysconf tls ciphers

View or modify the list of ciphers that the SafeNet Luna Network HSM appliance's TLS service negotiates with a contacting entity. This allows you to change the order of the default list, which determines the preference order when TLS is negotiating, or to exclude some of the supported ciphers from the negotiations, if desired. When the SafeNet Luna Network HSM appliance is negotiating with a Client, the client cipher options are open (but see Note below), and the appliance choices prevail.

NOTE This feature has software and/or firmware dependencies. See "[Version Dependencies by Feature](#)" on page 1 for more information.

Syntax

sysconf tls ciphers

reset
set
show

Argument(s)	Shortcut	Description
reset	r	Reset to the default ciphers. See " sysconf tls ciphers reset " on the next page.
set	se	Set the list of ciphers from which TLS can choose when negotiating session security. See " sysconf tls ciphers set " on page 482.
show	sh	Show the current list of ciphers available for TLS, or export the current settings as a template. See " sysconf tls ciphers show " on page 485.

sysconf tls ciphers reset

Reset the current list of TLS ciphers to the default list.

NOTE This feature has software and/or firmware dependencies. See "[Version Dependencies by Feature](#)" on page 1 for more information.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf tls ciphers reset [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the command without prompting.

Example

(This example shows the current list, the reset operation, and then the active list after reset.)

```
lunash:>sysconf tls ciphers show
```

The following cipher suites are available to configure TLS:

Available Ciphers

```
-----
ECDHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(256) Mac=AEAD
ECDHE-RSA-AES256-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(256) Mac=SHA384
DHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=DH Au=RSA Enc=AESGCM(256) Mac=AEAD
DHE-RSA-AES256-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AES(256) Mac=SHA256
AES256-GCM-SHA384 TLSv1.2 Kx=RSA Au=RSA Enc=AESGCM(256) Mac=AEAD
AES256-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AES(256) Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(128) Mac=AEAD
ECDHE-RSA-AES128-SHA256 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(128) Mac=SHA256
DHE-RSA-AES128-GCM-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AESGCM(128) Mac=AEAD
DHE-RSA-AES128-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AES(128) Mac=SHA256
AES128-GCM-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AESGCM(128) Mac=AEAD
AES128-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AES(128) Mac=SHA256
```

The selected TLS cipher suites are used by the NTLs, STC outer tunnel, RBS, Ped vector Server/Client features

TLS is using the following cipher suites:

Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(256) Mac=AEAD
ECDHE-RSA-AES256-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(256) Mac=SHA384
```

```
Command Result : 0 (Success)
lunash:>
lunash:>sysconf tls ciphers reset
```

This operation will reset the TLS cipher suites to use the following default cipher suites:
Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256     TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384         TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256             TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(128)  Mac=AEAD
ECDHE-RSA-AES128-SHA256   TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(128)     Mac=SHA256
DHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(128)  Mac=AEAD
DHE-RSA-AES128-SHA256    TLSv1.2  Kx=DH    Au=RSA  Enc=AES(128)     Mac=SHA256
AES128-GCM-SHA256        TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(128)  Mac=AEAD
AES128-SHA256            TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(128)     Mac=SHA256
```

This operation will restart the TLS related services (N_TLS, STCD, CBS).
Type 'proceed' to reset TLS cipher suites to default settings and restart TLS related services, or
'quit'
to quit now. > proceed

Restarting N_TLS, STC and CBS services.... Done

```
Command Result : 0 (Success)
```

```
lunash:>sysconf tls ciphers show
```

The following cipher suites are available to configure TLS:

Available Ciphers

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256     TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384         TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256             TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(128)  Mac=AEAD
ECDHE-RSA-AES128-SHA256   TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(128)     Mac=SHA256
DHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(128)  Mac=AEAD
DHE-RSA-AES128-SHA256    TLSv1.2  Kx=DH    Au=RSA  Enc=AES(128)     Mac=SHA256
AES128-GCM-SHA256        TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(128)  Mac=AEAD
AES128-SHA256            TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(128)     Mac=SHA256
```

The selected TLS cipher suites are used by the N_TLS, STC outer tunnel, RBS, Ped vector
Server/Client features

TLS is using the following cipher suites:
Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)


```

-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384      TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384    TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256        TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384            TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256                TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(128)  Mac=AEAD
ECDHE-RSA-AES128-SHA256      TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(128)     Mac=SHA256
DHE-RSA-AES128-GCM-SHA256    TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(128)  Mac=AEAD
DHE-RSA-AES128-SHA256        TLSv1.2  Kx=DH    Au=RSA  Enc=AES(128)     Mac=SHA256
AES128-GCM-SHA256            TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(128)  Mac=AEAD
AES128-SHA256                TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(128)     Mac=SHA256

```

Command Result : 0 (Success)

sysconf tls ciphers set

Set the list of ciphers that the Network HSM appliance's TLS service uses to negotiate connection security for a session.

NOTE This feature has software and/or firmware dependencies. See "[Version Dependencies by Feature](#)" on page 1 for more information.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

sysconf tls ciphers set **{-list <cipher_list> | -applyTemplate <file name>} [-force]**

Argument(s)	Shortcut	Description
-applyTemplate <file name>	-a	File name of a template file to apply. Either a template file with -applyTemplate , or a command line list with -list must be applied.
-list <cipher list>	-l	Colon-separated list of ciphers to apply. Either a template file with -applyTemplate , or a command line list with -list must be applied.
-force	-f	Force the action without prompting.

Example using a template file

```
lunash:>sysconf tls ciphers set -applyTemplate top-six
```

This operation will set the TLS cipher suites to use the following cipher suites:
Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384   TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256       TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384           TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256                TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
```

This operation will restart the TLS related services (N_TLS, STCD, CBS).
Type 'proceed' to set ciphers suites and restart TLS related services, or 'quit'
to quit now. > proceed

Restarting N_TLS, STC and CBS services.... Done

Command Result : 0 (Success)

```
lunash:>sysconf tls ciphers show
```

The following cipher suites are available to configure TLS:

Available Ciphers

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256     TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384         TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256            TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(128)  Mac=AEAD
ECDHE-RSA-AES128-SHA256   TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(128)     Mac=SHA256
DHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(128)  Mac=AEAD
DHE-RSA-AES128-SHA256    TLSv1.2  Kx=DH    Au=RSA  Enc=AES(128)     Mac=SHA256
AES128-GCM-SHA256        TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(128)  Mac=AEAD
AES128-SHA256           TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(128)     Mac=SHA256
```

The selected TLS cipher suites are used by the NTLS, STC outer tunnel, RBS, Ped vector Server/Client features

TLS is using the following cipher suites:

Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256     TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384         TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256            TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
```

Command Result : 0 (Success)

Example using a command-line list

```
lunash:>sysconf tls ciphers set -list ECDHE-RSA-AES256-GCM-SHA384:ECDHE-RSA-AES256-SHA384:AES256-GCM-SHA384
```

This operation will set the TLS cipher suites to use the following cipher suites:

Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
```

This operation will restart the TLS related services (NTLS, STCD, CBS).

Type 'proceed' to set ciphers suites and restart TLS related services, or 'quit' to quit now. > proceed

Restarting NTLS, STC and CBS services.... Done

Command Result : 0 (Success)

```
lunash:>sysconf tls ciphers show
```

The following cipher suites are available to configure TLS:

Available Ciphers

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384      TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
DHE-RSA-AES256-GCM-SHA384    TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(256)  Mac=AEAD
DHE-RSA-AES256-SHA256        TLSv1.2  Kx=DH    Au=RSA  Enc=AES(256)     Mac=SHA256
AES256-GCM-SHA384            TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(256)  Mac=AEAD
AES256-SHA256                TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(256)     Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(128)  Mac=AEAD
ECDHE-RSA-AES128-SHA256      TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(128)     Mac=SHA256
DHE-RSA-AES128-GCM-SHA256    TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM(128)  Mac=AEAD
DHE-RSA-AES128-SHA256        TLSv1.2  Kx=DH    Au=RSA  Enc=AES(128)     Mac=SHA256
AES128-GCM-SHA256            TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM(128)  Mac=AEAD
AES128-SHA256                TLSv1.2  Kx=RSA   Au=RSA  Enc=AES(128)     Mac=SHA256
```

The selected TLS cipher suites are used by the NTLN, STC outer tunnel, RBS, Ped vector Server/Client features

TLS is using the following cipher suites:

Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM(256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384      TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES(256)     Mac=SHA384
```

Command Result : 0 (Success)

sysconf tls ciphers show

Show the current list of ciphers from which the Network HSM appliance's TLS service can negotiate connection security for a session.

NOTE This feature has software and/or firmware dependencies. See "[Version Dependencies by Feature](#)" on page 1 for more information.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

sysconf tls ciphers show [-exportTemplate <filename>]

Argument(s)	Shortcut	Description
-exportTemplate <filename>	-a	Output the current TLS cipher settings to a Template file.

Example

```
lunash:>sysconf tls ciphers show
```

The following cipher suites are available to configure TLS:

Available Ciphers

```
-----
ECDHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM (256)  Mac=AEAD
ECDHE-RSA-AES256-SHA384     TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES (256)    Mac=SHA384
DHE-RSA-AES256-GCM-SHA384  TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM (256)  Mac=AEAD
DHE-RSA-AES256-SHA256      TLSv1.2  Kx=DH    Au=RSA  Enc=AES (256)    Mac=SHA256
AES256-GCM-SHA384          TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM (256)  Mac=AEAD
AES256-SHA256              TLSv1.2  Kx=RSA   Au=RSA  Enc=AES (256)    Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256 TLSv1.2  Kx=ECDH  Au=RSA  Enc=AESGCM (128)  Mac=AEAD
ECDHE-RSA-AES128-SHA256    TLSv1.2  Kx=ECDH  Au=RSA  Enc=AES (128)    Mac=SHA256
DHE-RSA-AES128-GCM-SHA256  TLSv1.2  Kx=DH    Au=RSA  Enc=AESGCM (128)  Mac=AEAD
DHE-RSA-AES128-SHA256      TLSv1.2  Kx=DH    Au=RSA  Enc=AES (128)    Mac=SHA256
AES128-GCM-SHA256          TLSv1.2  Kx=RSA   Au=RSA  Enc=AESGCM (128)  Mac=AEAD
AES128-SHA256              TLSv1.2  Kx=RSA   Au=RSA  Enc=AES (128)    Mac=SHA256
```

The selected TLS cipher suites are used by the NTLs, STC outer tunnel, RBS, Ped vector Server/Client features

TLS is using the following cipher suites:

Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(256) Mac=AEAD
ECDHE-RSA-AES256-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(256) Mac=SHA384
DHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=DH Au=RSA Enc=AESGCM(256) Mac=AEAD
DHE-RSA-AES256-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AES(256) Mac=SHA256
AES256-GCM-SHA384 TLSv1.2 Kx=RSA Au=RSA Enc=AESGCM(256) Mac=AEAD
AES256-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AES(256) Mac=SHA256
```

Command Result : 0 (Success)

```
lunash:>sysconf tls ciphers show -exportTemplate top-six
```

The following cipher suites are available to configure TLS:

Available Ciphers

```
-----
ECDHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(256) Mac=AEAD
ECDHE-RSA-AES256-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(256) Mac=SHA384
DHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=DH Au=RSA Enc=AESGCM(256) Mac=AEAD
DHE-RSA-AES256-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AES(256) Mac=SHA256
AES256-GCM-SHA384 TLSv1.2 Kx=RSA Au=RSA Enc=AESGCM(256) Mac=AEAD
AES256-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AES(256) Mac=SHA256
ECDHE-RSA-AES128-GCM-SHA256 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(128) Mac=AEAD
ECDHE-RSA-AES128-SHA256 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(128) Mac=SHA256
DHE-RSA-AES128-GCM-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AESGCM(128) Mac=AEAD
DHE-RSA-AES128-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AES(128) Mac=SHA256
AES128-GCM-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AESGCM(128) Mac=AEAD
AES128-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AES(128) Mac=SHA256
```

The selected TLS cipher suites are used by the NTLs, STC outer tunnel, RBS, Ped vector Server/Client features

TLS is using the following cipher suites:

Cipher suites are listed from highest to lowest priority.

Configured Ciphers (highest priority at top)

```
-----
ECDHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AESGCM(256) Mac=AEAD
ECDHE-RSA-AES256-SHA384 TLSv1.2 Kx=ECDH Au=RSA Enc=AES(256) Mac=SHA384
DHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=DH Au=RSA Enc=AESGCM(256) Mac=AEAD
DHE-RSA-AES256-SHA256 TLSv1.2 Kx=DH Au=RSA Enc=AES(256) Mac=SHA256
AES256-GCM-SHA384 TLSv1.2 Kx=RSA Au=RSA Enc=AESGCM(256) Mac=AEAD
AES256-SHA256 TLSv1.2 Kx=RSA Au=RSA Enc=AES(256) Mac=SHA256
```

Generated cipher template file "top-six"

Command Result : 0 (Success)

syslog

Access the syslog commands used to manage the system logs.

NOTE Syslog uses system time. If you change the time zone setting for the appliance while syslog is running, syslog continues to log entries based on the old time zone until you restart the syslog service.

Syntax

syslog

cleanup
export
period
remotehost
rotate
rotations
severity
show
tail
tarlogs

Argument(s)	Shortcut	Description
cleanup	c	Delete log files. See "syslog cleanup" on the next page .
export	e	Export syslog. See "syslog export" on page 489 .
period	p	Set the syslog period. See "syslog period" on page 490 .
remotehost	re	Configure Syslog remote hosts. See "syslog remotehost" on page 492 .
rotate	rotate	Rotate log files. See "syslog rotate" on page 491 .
rotations	rotati	Set syslog rotations. See "syslog rotations" on page 497 .
severity	se	Log severity. See "syslog severity set" on page 498 .
show	sh	Get Syslog configuration. See "syslog show" on page 499 .
tail	tai	Get last entries of log. See "syslog tail" on page 501 .
tarlogs	tar	Archive log files. See "syslog tarlogs" on page 503 .

syslog cleanup

Delete log files. Using this command following **syslog rotate** causes all grow-able log files to be deleted.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

syslog cleanup [-force]

Argument(s)	Shortcut	Description
-force	-f	Forces the command to proceed silently without prompting. Useful for scripting.

Example

```
lunash:>syslog cleanup
```

```
WARNING !! This command creates an archive of the current logs then deletes ALL THE LOG FILES.
If you are sure that you wish to proceed, then type 'proceed', otherwise type 'quit'.
```

```
> proceed
Proceeding...
Creating tarlogs then deleting all log files...
```

```
The tar file containing logs is now available via scp as filename "logs_cleanup_20170301_
1443.tgz".
Please copy "logs_cleanup_20170301_1443.tgz" to a client machine with scp.
```

```
Deleting log files ...
restart the rsyslogd service if it's running
Stopping syslog: [ OK ]
Starting syslog: [ OK ]
```

```
Command Result : 0 (Success)
```

syslog export

Prepare system logs for transfer from appliance. This command copies the current system log file to the export directory so that the user can use **scp** to transfer the file to another computer. Can be used for offline storage of old log files or to send to Technical Support for troubleshooting the SafeNet appliance.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog export

Example

```
lunash:>syslog export
```

```
System log files successfully prepared for secure transfer.  
Use scp from a client machine to get the file named: "syslog"
```

```
Command Result : 0 (Success)
```

syslog period

Set the time between syslog rotations.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog period <syslogperiod>

Argument(s)	Description
<syslogperiod>	Specifies the log rotation period. Valid values: daily, weekly, monthly

Example

```
lunash:>syslog period daily
```

Log period set to daily.

Command Result : 0 (Success)

syslog rotate

Rotate log files immediately if they have not already been rotated on the same date. Logs cannot be rotated more than once per day.

NOTE Using this command followed by **sysconf cleanup logs** causes all grow-able log files to be deleted.

EXCEPTION: The **syslog rotate** command does not rotate the NTP log file.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog rotate

Example

```
lunash:>syslog rotate
```

Command Result : 0 (Success)

syslog remotehost

Access the **syslog remotehost** commands to manage the syslog remote hosts.

Syntax

syslog remotehost

add
clear
delete
list

Argument(s)	Shortcut	Description
add	a	Add a remote host. See "syslog remotehost add" on the next page.
clear	c	Delete All Remote Logging Servers. See "syslog remotehost clear" on page 494.
delete	d	Delete a remote host. See "syslog remotehost delete" on page 495.
list	l	List all syslog remote hosts. See "syslog remotehost list" on page 496.

syslog remotehost add

Add a remote host receiving the logs. Can be any system that provides the remote syslog service.

NOTE For this function to work you must open receiving udp port 514 on the remote log server.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog remotehost add -host <hostname/IP> [-protocol <protocol>] [-port <port>]

Argument(s)	Shortcut	Description
-host <hostname_or_IP_address>	-h	Specifies the hostname or the IP address of the remote computer system that will be accepting and storing the syslogs.
-protocol <protocol>	-pr	Specifies the network protocol. Valid values: tcp,udp
-port <port>	-po	Remote Logging Server port number. Range: 0-65535

Example

```
lunash:>syslog remotehost add -host 192.12.1.123
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
```

```
192.12.1.123 added successfully
```

```
Make sure the rsyslog service on 192.12.1.123 is properly configured to receive the logs
```

```
Command Result : 0 (Success)
```

syslog remotehost clear

Delete all remote logging servers.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog remotehost clear -force

Argument(s)	Shortcut	Description
-force	-f	Force the action; useful for scripting.

Example

```
lunash:>syslog remotehost clear -force
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
```

```
Command Result : 0 (Success)
```

syslog remotehost delete

Delete a remote host receiving the logs. Use **syslog remotehost list** to see which systems are receiving the logs.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog remotehost delete -host <hostname_or_IP_address>

Argument(s)	Shortcut	Description
-host <hostname_or_IP_address>	-h	Specifies the hostname or the IP address of the remote computer system to delete from the list.

Example

```
lunash:>syslog remotehost delete -host 192.20.9.144
```

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
```

```
Command Result : 0 (Success)
```

syslog remotehost list

List the syslog remote hosts.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog remotehost list

Example

```
lunash:>syslog remotehost list
```

```
Remote logging server(s):  
=====
```

```
192.20.9.160:6767, tcp  
192.20.11.158:514, tcp  
192.20.11.155:514, udp
```

```
Command Result : 0 (Success)
```


syslog rotations

Set the number of history files to keep when rotating system log files. For example, two rotations would keep the current log files and the most recent set; three rotations would keep the current log files and the two most recent sets. Specify a whole number less than 100.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

syslog rotations <#_of_rotations>

Argument(s)	Description
<#_of_rotations>	An integer that specifies the number of history files to keep when rotating system log files. Range: 1 to 100

Example

```
lunash:> syslog rotations 5
```

Log rotations set to 5.

Command Result : 0 (Success)

syslog severity set

Set the log service severity threshold for events to be logged.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

syslog severity set -logname <logname> -loglevel <loglevel> [-host <hostname/IP>]

Argument(s)	Shortcut	Description
-loglevel <loglevel>	-logl	Specifies the severity level of the log messages to include in the logs. Valid values: emergency, alert, critical/crit, error/err, warning/warn, notice, info, debug NOTE: These values are arranged from those which produce the fewest to the most log entries. Each level includes all the levels above it. For example, setting the log level to critical will gather all emergency , alert , and critical events.
-logname <logname>	-logn	The name of the log file to which you want to apply severity levels.
-host <hostname/IP>	-h	The remote host that will receive the logs. Add new hosts with "syslog remotehost add" on page 493. The hosts must be configured to receive logs.

Example

```
lunash:>syslog severity set -logname lunalogd -loglevel crit
```

This command sets the severity level of lunalogd local log messages. Only messages with the severity equal to or higher than the new log level: "crit" will be logged.

```
Stopping syslog: [ OK ]
```

```
Starting syslog: [ OK ]
```

```
Command Result : 0 (Success)
```

syslog show

Display the current log rotation configuration and log levels. Optionally, show a list of the log files.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

syslog show [-files]

Argument(s)	Shortcut	Description
-files	-f	Show a list of all log files, in addition to the current log configuration.

Example

In the example below, the asterisks indicate that ALL events are logged and that this setting is not user configurable.

```
lunash:>syslog show -files
```

```
Syslog configuration
```

```
Rotations:          4
Rotation Period:    weekly
Log disk full policy: tarlogs_cleanup
```

```
Local Configured Log Levels:
```

```
-----
lunalog   info
messages  *
cron      notice
secure    *
boot      *
```

```
Remote Configured Log Levels:
```

```
-----
lunalog:
  192.20.11.50    info
messages:
  192.20.11.50    info
cron:
  192.20.11.50    notice
secure:
  192.20.11.50    info
```

```
boot:
    192.20.11.50      info
```

Note: '*' means all log levels.

LogFileName	Size	Date	Time
acpid	0	Feb 28	16:59
anaconda	4096	Dec 15	10:39
audit	4096	Dec 15	10:53
boot.log	0	Feb 28	16:59
btmpt	0	Feb 28	16:13
btmpt-2017-02-28	384	Feb 28	15:13
cron	6321	Mar 1	14:01
cron-2017-02-28	4852	Feb 28	16:13
dmesg	72318	Feb 28	16:00
dmesg.old	72387	Feb 28	15:08
ksyms	0	Feb 28	16:59
lastlog	291416	Mar 1	11:54
lost+found	16384	Dec 15	10:25
lunalog	570795	Mar 1	14:27
maillog	0	Dec 15	10:36
messages	258781	Mar 1	14:27
messages-2017-02-28	656831	Feb 28	16:13
mgetty.log	0	Feb 28	16:59
ntp.log	0	Feb 28	16:59
rpmpkgs	0	Feb 28	16:59
secure	44597	Mar 1	13:56
secure-2017-02-28	13367	Feb 28	16:03
snmpd.log	0	Feb 28	16:59
spooler	0	Dec 15	10:36
tallylog	0	Dec 15	10:34
tuned	4096	Dec 15	10:53
wtmp	18048	Mar 1	11:54
yum.log	0	Dec 15	10:55

Command Result : 0 (Success)

syslog tail

Display the last entries of the syslog. If no number is included, the command displays the entire syslog.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

syslog tail **-logname** <logname> [**-entries** <#entries>] [**-search** <string>]

Argument(s)	Shortcut	Description
-entries <#entries>	-e	Specifies the number of entries to display. If this parameter is not specified, the entire log is displayed. Range: 0-4294967295
-logname <logname>	-l	Specifies the log name. Valid values: lunalogs, messages, secure, ntp, snmp NOTE: The hsm option is not available in this release. To see HSM-specific logs, use the messages option.
-search <string>	-s	Search for the specified string. NOTE: To search the logs for HSM Alarm messages, for example, include this option with the string "ALM".

Example

```
lunash:>syslog tail -logname lunalogs -entries 8
```

```
2017 Mar  1 14:27:54 local_host  local5 info  hsm[32081]: STC policy is set to "OFF" on partition
66331 : Unknown ResultCode value
2017 Mar  1 14:27:55 local_host  local5 info  hsm[32120]: STC policy is set to "OFF" on partition
66331 : Unknown ResultCode value
2017 Mar  1 14:29:53 local_host  local5 info  hsm[3948]: STC policy is set to "OFF" on partition
66331 : Unknown ResultCode value
2017 Mar  1 14:29:59 local_host  local5 info  lunash [29529]: info : 0 : Command: syslog
remotehost add : admin : 10.124.0.87/61470
2017 Mar  1 14:30:37 local_host  local5 info  hsm[5511]: STC policy is set to "OFF" on partition
66331 : Unknown ResultCode value
2017 Mar  1 14:30:48 local_host  local5 info  lunash [29529]: info : 0 : Command: syslog
remotehost list : admin : 10.124.0.87/61470
2017 Mar  1 14:33:10 local_host  local5 info  lunash [29529]: info : 0 : Command: syslog severity
set : admin : 10.124.0.87/61470
2017 Mar  1 14:33:47 local_host  local5 info  lunash [29529]: info : 0 : Command: syslog severity
set -logname lunalogs -loglevel crit : admin : 10.124.0.87/61470
```

Command Result : 0 (Success)

Error message when using -logname hsm

```
lunash:>syslog tail -logname hsm
```

HSM log does not exist

Command Result : 65535 (Luna Shell execution)

syslog tarlogs

Archives log files to logs.tar file in the current user's temporary directory. A single logs.tgz file allows you to obtain all the logs in one operation.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

syslog tarlogs

Example

```
lunash:>syslog tarlogs
```

The tar file containing logs is now available via scp as filename 'logs.tgz'.

```
Command Result : 0 (Success)
```

token backup

Access the token backup commands.

When to use LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices.

You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

Syntax

token backup

factoryreset
init
list
login
logout
partition
show
update

Argument(s)	Shortcut	Description
factoryreset	f	Reset a backup token to factory default settings. See " token backup factoryreset " on page 506.
init	i	Initializes the token with the specified serial number and prepares it to receive backup data. See " token backup init " on page 508.

Argument(s)	Shortcut	Description
list	li	List all backup tokens. See "token backup list" on page 511 .
login	logi	Login backup token admin. See "token backup login" on page 513 .
logout	logo	Logout backup token admin. See "token backup logout" on page 515 .
partition	p	Access the token backup partition commands to manage your backup partitions. See "token backup partition" on page 517 .
show	s	Get backup token information. See "token backup show" on page 525 .
update	u	Update commands. See "token backup update" on page 527 .

An external SafeNet Luna Backup HSM can be USB-connected to a SafeNet Luna Network HSM appliance for local backup/restore operations.

SafeNet Luna Network HSM does not pass PED operations and data through to an externally connected SafeNet Luna backup HSM from a Luna PED that is connected locally to the SafeNet Luna Network HSM.

If the external HSM is PED-authenticated, then the options for Luna PED connection are:

- > local PED connection, directly to the affected HSM, when needed, or
- > Remote PED connection, passed through the SafeNet Luna Network HSM

NOTE Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.

NOTE Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM> and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token backup** commands.

CAUTION! When labeling HSMs or partitions, *never* use a numeral as the first, or only, character in the name/label. Token backup commands allow a slot-number OR a label as identifier, which can lead to confusion if the label is a string version of a slot number.

For example, if the token is initialized with the label "1", the user cannot use the label to identify the target for backup purposes, because VTL parses "1" as the numeric ID of the first slot rather than as a text label for the target in the actual occupied slot.

LunaSH token backup commands on SafeNet Luna Network HSM would be unable to see SafeNet Luna Backup HSM slots maintained by Remote Backup server. Either connect the Backup HSM locally to the SafeNet Luna Network HSM USB port to use token backup commands, or use VTL commands directed to a SafeNet Luna Backup HSM connected to a computer configured as a backup server.

token backup factoryreset

Reset a backup token to factory default settings (destroys the KEK or permanently denies access to existing objects, erases or authentication, so you need to initialize before using again). Can be run only from the local serial console.

The action is equivalent to the **hsm factoryReset** command that acts on the appliance's built-in HSM.

View a table that compares and contrasts various "deny access" events or actions that are sometimes confused: "[Comparison of Destruction/Denial Actions](#)" on page 1 (Right-click the link if you prefer that it not open in a new window.)

An external SafeNet Luna Backup HSM can be USB-connected to a SafeNet Luna Network HSM appliance for local backup/restore operations.

SafeNet Luna Network HSM does not pass PED operations and data through to an externally connected SafeNet Luna backup HSM from a Luna PED that is connected locally to the SafeNet Luna Network HSM.

If the external HSM is PED-authenticated, then the options for Luna PED connection are:

- > local PED connection, directly to the affected HSM, when needed, or
- > Remote PED connection, passed through the SafeNet Luna Network HSM

NOTE Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.

NOTE Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM> and

hsm ped connect -serial <serial#_of_external_HSM>

before using **token backup** commands.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices.

You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote

Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup factoryreset -serial <serialnum> [-force]

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the token serial number.
-force	-f	Force the action without prompting.

Example

```
lunash:>token backup factoryreset -serial 496771
```

CAUTION: Are you sure you wish to reset this backup token to factory default settings? All data will be erased.

```
Type 'proceed' to return the token to factory default, or
'quit' to quit now.
> proceed
```

```
'token backup factoryReset' successful.
```

```
Command Result : 0 (Success)
```

token backup init

Initializes the token with the specified serial number and prepares it to receive backup data. Both the **-label** and **-serial** parameters are required at the command line. For SafeNet Luna Network HSM with Password Authentication, the domain and Token Admin (SO) password are prompted, and your input is obscured by asterisk (*) symbols. For SafeNet Luna Network HSM with Trusted Path authentication, any typed values for domain or password are ignored and you are prompted for Luna PED operations with PED keys.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup init -label <label> **-serial** <serialnum> [**-domain** <domain>] [**-tokenadminpw** <password>] [**-force**]

Argument(s)	Shortcut	Description
-domain <domain>	-d	Backup Token Domain (required for Password authenticated HSMs, ignored for PED authenticated - if you prefer to not type it in the clear, on the command line, it is prompted later).
-force	-f	Force the action without prompting.
-label <label>	-l	Token label.
-serial <serialnum>	-s	Token serial number.
-tokenadminpw <password>	-t	Token Admin / SO Pas.sword (required for Password authenticated HSMs, ignored for PED authenticated - if you prefer to not type it in the clear, on the command line, it is prompted later).

An external SafeNet Luna Backup HSM can be USB-connected to a SafeNet Luna Network HSM appliance for local backup/restore operations.

SafeNet Luna Network HSM does not pass PED operations and data through to an externally connected SafeNet Luna backup HSM from a Luna PED that is connected locally to the SafeNet Luna Network HSM.

If the external HSM is PED-authenticated, then the options for Luna PED connection are:

- > local PED connection, directly to the affected HSM, when needed, or
- > Remote PED connection, passed through the SafeNet Luna Network HSM

NOTE Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.

NOTE Use of Remote PED with an external device is made possible when you set up with the commands
hsm ped vector init -serial <serial#_of_external_HSM> and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token backup** commands.

Example

```
lunash:>token backup init -label sa7docbackup -serial 496771
```

```
Please enter a password for the Token Administrator:
```

```
> *****
```

```
Please re-enter password to confirm:
```

```
> *****
```

```
Please enter a cloning domain used when initializing this HSM:
```

```
> *****
```

```
Please re-enter cloning domain to confirm:
```

```
> *****
```

CAUTION: Are you sure you wish to initialize the backup
token named: sa7docbackup
Type 'proceed' to continue, or 'quit' to quit now.
> proceed

'token backup init' successful.
Command Result : 0 (Success)

token backup list

Display a list all of the backup tokens on the system. This command shows all connected backup devices with their serial numbers. Use the serial number that you find with this command to identify specific backup HSMs or partitions that you can then query with the **token backup partition list** command for more detailed information.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

token backup list

Example

```
lunash:>token backup list
```

```
Token Details:
=====
Token Label:          sa78backup
Slot:                 1
```

Serial #: 496771
Firmware: 6.2.3
HSM Model: G5Backup

Command Result : 0 (Success)

token backup login

Log the Backup Token Administrator into the backup token. This command is used immediately before performing a firmware update on a backup token.

Remember to always log out of the backup token using the **token backup logout** command.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices.

You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

An external SafeNet Luna Backup HSM can be USB-connected to a SafeNet Luna Network HSM appliance for local backup/restore operations.

SafeNet Luna Network HSM does not pass PED operations and data through to an externally connected SafeNet Luna backup HSM from a Luna PED that is connected locally to the SafeNet Luna Network HSM.

If the external HSM is PED-authenticated, then the options for Luna PED connection are:

- > local PED connection, directly to the affected HSM, when needed, or
- > Remote PED connection, passed through the SafeNet Luna Network HSM

NOTE Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.

NOTE Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM> and

hsm ped connect -serial <serial#_of_external_HSM>

before using **token backup** commands.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup login -serial <serialnum> [**-password** <password>]

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the backup HSM/token.
-password <password>	-p	Specifies the Backup Token Administrator's password. This parameter is mandatory in SafeNet Luna Network HSM with Password Authentication. It is ignored in SafeNet Luna Network HSM with PED Authentication.

Example

```
lunash:>token backup login -serial 496771
```

```
  Please enter Token Administrator's password:
  > *****
```

```
'token backup login' successful.
```

```
Command Result : 0 (Success)
```

token backup logout

Log out the backup Token Administrator from the backup token.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup logout -serial <serialnum>

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the backup HSM/token.

Example

```
lunash:>token backup logout -serial 496771
```

```
'token logout' successful.
```

Command Result : 0 (Success)

token backup partition

Access the token backup partition commands to manage your backup partitions.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

An external SafeNet Luna Backup HSM can be USB-connected to a SafeNet Luna Network HSM appliance for local backup/restore operations.

SafeNet Luna Network HSM does not pass PED operations and data through to an externally connected SafeNet Luna backup HSM from a Luna PED that is connected locally to the SafeNet Luna Network HSM.

If the external HSM is PED-authenticated, then the options for Luna PED connection are:

- > local PED connection, directly to the affected HSM, when needed, or
- > Remote PED connection, passed through the SafeNet Luna Network HSM

NOTE Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.

NOTE Use of Remote PED with an external device is made possible when you set up with the commands
hsm ped vector init -serial <serial#_of_external_HSM> and
hsm ped connect -serial <serial#_of_external_HSM>
before using **token backup** commands.

Syntax

token backup partition

delete
list
show

Argument(s)	Shortcut	Description
delete	d	Delete a backup partition. See " token backup partition delete " on the next page
list	l	List the backup partitions. See " token backup partition list " on page 521 .
show	s	List the objects on a backup token. See " token backup partition show " on page 523 .

token backup partition delete

Delete a backup partition on the Backup device and free the license used by the HSM Partition. To use the **token backup partition delete** command you must be logged in to the Backup HSM as HSM Admin.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices.

You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

An external SafeNet Luna Backup HSM can be USB-connected to a SafeNet Luna Network HSM appliance for local backup/restore operations.

SafeNet Luna Network HSM does not pass PED operations and data through to an externally connected SafeNet Luna backup HSM from a Luna PED that is connected locally to the SafeNet Luna Network HSM.

If the external HSM is PED-authenticated, then the options for Luna PED connection are:

- > local PED connection, directly to the affected HSM, when needed, or
- > Remote PED connection, passed through the SafeNet Luna Network HSM

NOTE Support for locally connected Backup HSM with Remote PED, begins at firmware version 6.10.1 in the external HSM.

NOTE Use of Remote PED with an external device is made possible when you set up with the commands

hsm ped vector init -serial <serial#_of_external_HSM> and
hsm ped connect -serial <serial#_of_external_HSM>
 before using **token backup** commands.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup partition delete -partition <partition_name> -serial <serialnum> [-force]

Argument(s)	Shortcut	Description
-force	-f	Specifies that the Backup Token partition is erased without prompting the user for a confirmation of this destructive command.
-partition <partition_name>	-p	Specifies the name of the Backup Token partition to delete. Obtain the Backup Token partition name by using the token backup partition list command.
-serial <serialnum>	-s	Specifies the serial number of the Backup Token partition to delete. Obtain the Backup Token partition serial number by using the token backup partition list command.

Example

```
lunash:>token backup partition delete -partition sa78parlbackup -serial 496771
```

```
CAUTION: Are you sure you wish to delete the partition named:
          sa78parlbackup
          Type 'proceed' to delete the partition, or 'quit'
          to quit now.
          > proceed
'token backup partition delete' successful.
```

```
Command Result : 0 (Success)
```


token backup partition list

Display a list of the partitions on the specified SafeNet Luna Backup HSM. The serial number and name of each partition is displayed. Login as HSM Admin is not needed for execution of this command.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

The HSM firmware needs approximately 2K bytes of memory to manage each partition and data objects in it. To avoid you having to calculate the exact memory space available for data storage -- with you deducting the memory used by internal data structures --the "partition list" command adjusts the memory size attributes for you. Thus, the total available memory reported by "partition list" will be different than that reported by "token backup show" and "token backup partition list."

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

token backup partition list -serial <serialnum>

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	Specifies the serial number of the backup HSM/token.

Example

```
lunash:>token backup partition list -serial 496771
```

Partition	Name	Objects	Storage (bytes)		
			Total	Used	Free
496771005	sa78par1backup	6	9480	9348	132
496771010	sa78par2backup	12	18960	18696	264

```
Command Result : 0 (Success)
```

token backup partition show

Display a list of objects on the backup token/HSM.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

token backup partition show -partition [<partitionName>] **-serial** <serialnum> **-password** <backup_token/hsm_userPassword>

Argument(s)	Shortcut	Description
-password <tokenpartitionpassword>	-pas	Specifies the password of the partition for which to display information. If you do not specify a password, you are prompted to enter it when you execute the command.

Argument(s)	Shortcut	Description
-partition <tokenpartitionname>	-par	Specifies the name of the partition for which to display information. By default information about all partitions is shown. Obtain the partition name by using the partition list command.
-serial <tokenserialnumber>	-s	The serial number of the partition for which to display information. By default information about all partitions is shown. Obtain the partition name by using the partition list command.

Example

```
lunash:>token backup partition show -partition sa78par1backup -serial 496771
```

```
Please enter the user password for the token:
> *****
```

```
Partition Name:          sa78par1backup
Partition SN:           496771005
Partition Label:       sa78par1backup
Storage (Bytes): Total=9480, Used=9348, Free=132
Number objects: 6
```

```
Object Label:  MT RSA 4096-bit Public KeyGen
Object Type:   Public Key
Object Handle: 14
```

```
Object Label:  MT RSA 4096-bit Private KeyGen
Object Type:   Private Key
Object Handle: 15
```

```
Object Label:  MT RSA 4096-bit Public KeyGen
Object Type:   Public Key
Object Handle: 19
```

```
Object Label:  MT RSA 4096-bit Private KeyGen
Object Type:   Private Key
Object Handle: 20
```

```
Object Label:  MT RSA 4096-bit Public KeyGen
Object Type:   Public Key
Object Handle: 24
```

```
Object Label:  MT RSA 4096-bit Private KeyGen
Object Type:   Private Key
Object Handle: 25
```

```
Command Result : 0 (Success)
```

token backup show

Displays the token label and firmware version for the specified backup token.

CAUTION! Wait at least 20 seconds before you run the **token backup show** command after performing a backup token backup firmware update. If you run the **token backup show** command within 10 seconds or less following a successful completion of token backup update firmware, the **token backup show** command will hang and the green LED on the token reader will continue to flash. The work-around for the hanging state is to remove and re-insert the backup token and then rerun the **token backup show** command.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

The HSM firmware needs approximately 2K bytes of memory to manage each partition and data objects in it. To avoid you having to calculate the exact memory space available for data storage -- with you deducting the memory used by internal data structures --the "partition list" command adjusts the memory size attributes for you. Thus, the total available memory reported by "partition list" will be different than that reported by "token backup show" and "token backup partition list."

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

token backup show -serial <serialnum>

Argument(s)	Shortcut	Description
-serial <serialnum>	-s	The serial number of the backup HSM/token.

Example

```
lunash:>token backup show -serial 496771
```

```
Token Details:
```

```
=====
```

```
Token Label:                sa78backup
Serial #:                   496771
Firmware:                   6.2.3
HSM Model:                  G5Backup
Authentication Method:      Password
Token Admin login status:   Logged In
Token Admin login attempts left: 3 before Token zeroization!
```

```
Partition Information:
```

```
=====
```

```
Partitions licensed on token: 20
Partitions created on token:  2
```

```
-----
```

```
Partition: 496771005,      Name: sa78par1backup
Partition: 496771010,      Name: sa78par2backup
```

```
Token Storage Information:
```

```
=====
```

```
Maximum Token Storage Space (Bytes): 16252928
Space In Use (Bytes):                 32752
Free Space Left (Bytes):               16220176
```

```
License Information:
```

```
=====
```

```
001111-012      G5 Backup Config - 001111-012
004444-012      Test BackupToken RemotePed - 004444-012
004444-006      Test BackupToken Partitions 20 Update - 4444-006
004444-009      Test BackupToken HSM Storage 15.5 Meg - 004444-009
004444-008      Test BackupToken External MTK Update 2 - 004444-008
```

```
Command Result : 0 (Success)
```

token backup update

Access the token backup update commands to update the backup token capabilities or firmware.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

Syntax

token backup update

capability
firmware
show

Argument(s)	Shortcut	Description
capability	c	Update the capabilities for a backup token. See " token backup update capability " on page 529.
firmware	f	Update the firmware on a backup token. See " token backup update firmware " on page 531.

Argument(s)	Shortcut	Description
show	s	Show a list of the available backup token updates. See " token backup update show " on page 533.

token backup update capability

Update Backup Token Capability, using a capability update package that you have acquired from SafeNet and transferred via scp to the SafeNet appliance. Before you can use this command, you must:

- > Acquire the secure package update file from SafeNet and send the file to the SafeNet Luna Network HSM (using scp or pscp)
- > Open the file on the SafeNet Luna Network HSM with the LunaSH command **package update** <filename> - **authcode** <authcode>

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices.

You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and lunash:> commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance.

For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup update capability -serial <serialnum> **-capability** <capabilityname> [**-force**]

Argument(s)	Shortcut	Description
-capability <capabilityname>	-c	Specifies the capability name.
-force	-f	Force the action without prompting.
-serial <serialnum>	-s	Specifies the token serial number.

Example

```
lunash:>token backup update capability -serial 667788 -capability newcapability
```

CAUTION: This command updates the Token Capability.
This process cannot be reversed.

Type 'proceed' to continue, or 'quit'
to quit now.

```
> proceed
```

This is a NON-destructive capability update

Update Result :0 (Capability newcapability added)

Command Result : 0 (Success)

token backup update firmware

Update the firmware on a backup token, using a firmware update package available on the SafeNet appliance. The package must be transferred to the SafeNet appliance by scp (individually or as a component of a system update), and you must login to the backup token as Token Administrator (using the **token backup login** command) or SO before the token backup update firmware command is run. The command requires no package name.

The term "token" in this case refers to removable token-format HSMs connected via SafeNet DOCK 2 and USB, or SafeNet Luna Backup HSM, connected via USB.

Before you can use this command, you must:

- > Acquire the secure package update file from SafeNet and send the file to the SafeNet Luna Network HSM (using scp or pscp)
- > Open the file on the SafeNet Luna Network HSM using the **package update** command

NOTE Firmware update is a local operation only, and is not supported remotely.

A capability update or a firmware update is meant to be applied just one time to an HSM. If you attempt to re-apply a capability update to an HSM that already has the capability installed, the system throws an error like "C0000002 : RC_GENERAL_ERROR ". A similar result occurs if you attempt to install a particular firmware update more than once on one HSM. This is expected behavior.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator

Syntax

token backup update firmware -serial <serialnum> [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.
-serial <serialnum>	-s	Specifies the token serial number.

Example

```
lunash:>token backup update firmware -serial 496771
```

CAUTION: This command updates the Token firmware.
This process cannot be reversed.

```
Type 'proceed' to continue, or 'quit'
to quit now.
```

```
>proceed
```

```
Success  
Firmware updated.
```

```
Command Result : 0 (Success)
```

token backup update show

Display information about any capability updates that are available for backup tokens. This refers to update files that have been uploaded to the SafeNet appliance and are available to be applied to an attached backup HSM.

WHEN to USE LunaSH "token backup" commands, or use "vtl backup" commands:

LunaSH **token backup** commands operate a SafeNet Luna Backup HSM attached directly to SafeNet Luna Network HSM via USB, and are not intended for use with remotely connected backup devices. You might have a locally-connected backup HSM (connects directly to a SafeNet Luna Network HSM via USB cable) and a locally connected serial terminal and be walking them from SafeNet Luna Network HSM to SafeNet Luna Network HSM in your server room to perform backups. Or you might be administering remotely via SSH and `lunash:>` commands, while a technician in your server center carries the backup HSM from one SafeNet Luna Network HSM to the next. In either case, these **token backup** commands are the method to use. The important distinction is where the backup HSM is physically connected - from the SafeNet Luna Network HSM perspective, those are both local backup operations to a backup HSM that is locally connected to the appliance.

VTL backup commands operate a SafeNet Luna Backup HSM connected to a computer, and located distantly from your primary SafeNet Luna Network HSM appliance. The **VTL backup** commands are not for use with a SafeNet Luna Backup HSM that is connected directly to your SafeNet Luna Network HSM appliance. For true, hands-off, lights-out operation of your SafeNet appliances, use a SafeNet Luna Backup HSM located in your administrator's office (or other convenient location), connected to a computer acting as a Remote Backup server (this could be your administrative workstation, or it could be a completely separate computer). This means the computer and Backup HSM are located near you and remote/distant from your SafeNet Luna Network HSM appliance(s). For that application, use the **backup** commands in the VTL utility supplied with the SafeNet Luna Network HSM Client software (which must be installed on the computer that is acting as Remote Backup server) - the appliance **token backup** commands are not designed to work for Remote Backup.

User Privileges

Users with the following privileges can perform this command:

- > Admin
- > Operator
- > Monitor

Syntax

token backup update show

Example

```
lunash:> token backup update show
```

```
Capability Updates:
  HsmStorage15.5Meg
  Partitions20
```

```
Command Result : 0 (Success)
```

user

Access the user-level command. With the user commands, the HSM Appliance admin can create (add) additional named users and assign them roles of greater or lesser capability on the system. The admin can also lock (disable), unlock (enable) such accounts, set/reset their passwords, or delete them entirely, as needed.

Users without the "admin" role cannot execute any "user" command, even to change their own password. They should use the **my password set** command to change their own password.

The current implementation creates named users that are separate from the roles that those users can hold. The purpose is to allow administrators to assign any of the roles to multiple people, to allow logged tracking, by name, of the actions of each user in a given role (this was not possible previously when the role was the user, and only one of each could exist).

Syntax

user

add
delete
disable
enable
list
password
radiusadd
role

Argument(s)	Shortcut	Description
add	a	Add LunaSH user. See "user add" on the next page .
delete	de	Delete a named LunaSH user. See "user delete" on page 536 .
disable	di	Disable a LunaSH user (but the user still exists with role(s) assigned. See "user disable" on page 537
enable	e	Enable a locked LunaSH user (with whatever roles are assigned to that user). See "user enable" on page 538 .
list	l	List the LunaSH user accounts. See "user list" on page 539 .
password	p	Set User Password. See "user password" on page 540 .
radiusadd	ra	Add a RADIUS-authenticated user. See "user radiusadd" on page 541 .
role	ro	Access the user role commands. See "user role" on page 542 .

user add

Add a LunaSH user. Adds a new administrative LunaSH (command line) user. This command is available only to the **admin** account. Administrative users' names can be a single character or as many as 31 characters, chosen from letters a-z, or A-Z, numbers 0-9, the dash, the dot, or the underscore. No spaces.

abcdefghijklmnopqrstuvwxyABCDEFGHIJKLMNOPQRSTUVWXYZ0123456789-._

After the new, named administrative user is created, its default password is PASSWORD. The newly-created administrative user cannot do anything in the LunaSH until the **admin** user assigns it a role with the **user role add** command.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user add -username <username>

Argument(s)	Shortcut	Description
-username <username>	-u	Specifies the user name of the user to create.

Example

```
lunash:>user add -username james
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

user delete

Delete a role from a user. This command removes a LunaSH user. Works on any named users that you have created. Does not affect the permanent users 'admin', 'operator', and 'monitor'. A user must be logged out before you can delete that user.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user delete -username <username>

Argument(s)	Shortcut	Description
-username <username>	-u	Specifies the user name of the user being removed.

Example

```
lunash:>user delete -username anna
```

Command Result : 0 (Success)

user disable

Disable a named LunaSH user.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user disable -username <username>

Argument(s)	Shortcut	Description
-username <username>	-u	Specifies the user name of the user to disable.

Example

```
lunash:>user disable -username james
```

```
James was disabled successfully.
```

```
Command Result : 0 (Success)
```

user enable

Enable a locked LunaSH user.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user enable -username <username>

Argument(s)	Shortcut	Description
-username	-u	Specifies the user name of the user being enabled.

Example

```
lunash:>user enable -username monitor
```

```
monitor was enabled successfully.
```

```
Command Result : 0 (Success)
```

user list

List all of the LunaSH user accounts.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user list

Example

```
lunash:>user list
```

Users	Roles	Status	RADIUS
-----	-----	-----	-----
cindy	none	enabled	no
james	none	disabled	no
admin	admin	enabled	no
audit	audit	enabled	no
monitor	monitor	enabled	no
operator	operator	disabled	no

Command Result : 0 (Success)

user password

Set or change the appliance password for the specified user. This command allows admin-level users to change their own password or the password for another admin-level, operator-level, or monitor-level user. Operator-level or monitor-level users can use the **my password set** command to change their own password.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user password [<userid>]

Argument(s)	Description
<userid>	Specifies the user name of the user whose password you want to change. You can change the password for operator-level, monitor-level, or other admin-level users. Omit this parameter to change your own password.

Example

```
lunash:>user password james
```

Changing password for user james.

You can now choose the new password.

The password must be at least 8 characters long.

The password must contain characters from at least 3 of the following 4 categories:

- Uppercase letters (A through Z)
- Lowercase letters (a through z)
- Numbers (0 through 9)
- Non-alphanumeric characters (such as !, \$, #, %)

New password:

Retype new password:

passwd: all authentication tokens updated successfully.

Command Result : 0 (Success)

user radiusadd

Add a RADIUS-authenticated user. This command adds a new administrative lunash (command line) user. This command is available only to the 'admin' account. Administrative users' names can be a single character or as many as 128 characters, chosen from letters a-z, or A-Z, numbers 0-9, the dash, the dot, or the underscore. No spaces.

abcdefghijklmnopqrstuvwxyzABCDEFGHIJKLMNOPQRSTUVWXYZ0123456789-._

After the new, named administrative user is created, it can authenticate via RADIUS only. The newly-created administrative user cannot do anything in LunaSH until the 'admin' assigns it a role with the **user role add** command.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user radiusadd -username <username>

Argument(s)	Shortcut	Description
-username <username>	-u	Specifies the user name of the user to add.

Example

```
lunash:>user radiusadd -username jon
```

```
Stopping sshd: [ OK ]
```

```
Starting sshd: [ OK ]
```

```
Command Result : 0 (Success)
```

user role

Access the user role commands to manage the roles associated with a user account.

Syntax

user role

add
clear
delete
import
list

Argument(s)	Shortcut	Description
add	a	Add a role to a LunaSH user. See "user role add" on the next page .
clear	c	Clears user role assignments. See "user role clear" on page 545 .
delete	d	Delete a role from a LunaSH user. See "user role delete" on page 546 .
import	i	Import a role description or definition from a file. See "user role import" on page 547
list	l	List the possible role assignments. See "user role list" on page 548 .

user role add

Assign an operational role to a user account. A role is a profile defining a level of access and authority with respect to the appliance.

The purpose of this command in combination with the **user add** command is to apply one of the possible roles to a new named user, which defines the scope of access and authority of that named user. This **user role add** command adds a role to a named LunaSH administrative or auditor user that you have already created with the **user add** command. This command is available only to the original **admin** account, and cannot be used to modify the predefined **admin**, **operator**, **monitor** or **audit** accounts (whose names are permanently the same as their roles).

See "[Appliance Roles and Procedures](#)" on page 1 in the *Administration Guide* for more information.

Users

A user is an identity on the SafeNet appliance. A user has a name. The name of a user can be one of the following:

- > a predefined user name (the general administrative users **admin**, **operator** or **monitor**, and the special **audit** user whose only function is managing the auditing of the HSM).
- > any name that you wish to use for operational convenience, as created using the command "[user add](#)" on page 535.

Predefined Roles

The available predefined roles are **admin**, **operator**, **monitor** or **audit**. These predefined role names are the same as the names of the built-in, permanent user names. A predefined user always has the same role as its name.

In addition to the predefined users, you can create a user account and assign one of the predefined roles to it, which confers upon that user a specific access and authority on the appliance.

Custom Roles

In addition to the predefined roles, you can use the command "[user role import](#)" on page 547 to create a custom role. A custom role is able to perform a set of commands that you provide in a file and upload to the appliance. For example, you could create a role called **snmp** that is able to access only the SNMP commands. See "[Appliance Roles and Procedures](#)" on page 1.

Example

For example, we can create a new user called "indigo" and give indigo the authority of "operator". Therefore, if you can log in as the built-in user named "operator", you can perform read-and-write operations with some limits, and if you can log in as user "indigo", you have exactly the same scope of operation and abilities/constraints as would someone logged in as user "operator". Of course, this assumes that the role is also enabled with **user enable** command.

Adding a role to a user displaces or overwrites any previous role held by that user. To see the role currently held by a user, run the **user role list -username <username>** command.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user role add -username <username> -role <rolename>

Argument(s)	Shortcut	Description
-username <username>	-u	Specifies the name of the existing named user account to which the role is being added.
-role <rolename>	-r	The name of the administrative role being added to that user. The available default roles, in descending order of capability are admin, operator, and monitor, for general administration, and audit for managing HSM auditing functions. Valid values: admin, operator, monitor, audit, or a custom role

Example

```
lunash:>user role add -username james -role audit
```

User james was successfully modified.

Command Result : 0 (Success)

user role clear

Clears all roles assigned to an account. This command is available only to the 'admin' account and cannot be used to modify the admin, monitor or operator accounts. If user has only one role, then the effect is the same as the user role delete command. This command is infrastructure for possible future functionality.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user role clear -username <username>

Argument(s)	Short	Description
-username <username>	-u	Specifies the name of the user account from which the role is being removed.
-force	-f	Force the action. Useful for scripting.

Example

```
lunash:>user role clear -username james
```

```
WARNING !! This command will delete all james's role assignments.
If you are sure that you wish to proceed, then enter 'proceed', otherwise this command will abort.
```

```
> proceed
Proceeding...
Role list cleared for user James
```

```
Command Result : 0 (Success)
```

user role delete

Delete a role from a user account. This command is available only to the original 'admin' account and cannot be used to modify the admin, monitor, operator, or audit accounts.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user role delete -role <rolename> **-username** <username>

Argument(s)	Shortcut	Description
-username <username>	-u	Specifies the name of the user account from which the role is being removed.
-role <rolename>	-r	The role name of the role being removed from the user. The available roles, in descending order of capability are admin, operator and monitor, and the special role audit. Valid values: admin,operator,monitor,audit

Example

```
lunash:>user role delete -username cindy -role admin
```

User cindy was successfully modified.

Command Result : 0 (Success)

user role import

Import a role description or definition from a file that defines the list of commands a custom role is able to perform. See ["Appliance Roles and Procedures" on page 1](#) in the Administration Guide for more information.

A role definition file is a UNIX-format file containing a list of LunaSH commands that are allowed for the role, for example:

```
exit
help
scp
hsm init
hsm login
hsm logout
hsm show
my file list
partition create
```

All lines must end with a UNIX-style linefeed (lf) character. If you create your file in Windows, be sure to convert to the UNIX style before transferring it to an HSM appliance.

When the definition is applied to a named role using the command ["user role add" on page 543](#), that role will have access only to commands that are named in the file.

NOTE The system does not pre-detect the purpose of the file, so it is up to you to name your role definition files usefully, and to recognize them when you import them.

Syntax

user role import -file <filename> -role <rolename>

Argument(s)	Shortcut	Description
-file <filename>	-f	Name of the file being imported.
-role <rolename>	-r	The name of the administrative role for which a description file is being imported.

Example

```
lunash:>user role import -file rolefile1 -role indigo
```

```
"rolefile1" was successfully imported.
```

```
Command Result : 0 (Success)
```

user role list

List the available user roles that can be assigned to a user. The "built-in" account called 'admin' has the full "admin" role, the "built-in" account called 'operator' has the "operator" role, and "built-in" account called 'monitor' has the "monitor" role. Those three roles can also be applied/assigned, as desired, to any new named account that the original, built-in 'admin' user cares to create.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

user role list [-username <username>]

Argument(s)	Shortcut	Description
-username <username>	-u	See the roles assigned to the named user.
.	.	If no user is named, all users and their roles are listed.

Example

```
lunash:>user role list
```

```
Available Roles:
```

```
-----
admin
audit
monitor
operator
```

```
Command Result : 0 (Success)
```

webserver

The **webserver** command set is available in LunaSH (lunash:>) if your SafeNet Luna Network HSM appliance is at version 6.0 or higher, and you have the REST API configuration upgrade installed.

Syntax

webserver

bind
certificate
ciphers
disable
enable
show

Argument(s)	Shortcut	Description
bind	b	Set REST API service network port. See "webserver bind" on the next page .
certificate	ce	Manage REST API service certificate. See "webserver certificate" on page 552 .
ciphers	ci	Manage REST API service cipher suite. See "webserver ciphers" on page 557 .
disable	d	Disable REST API service. See "webserver disable" on page 560 .
enable	e	Enable REST API service. See "webserver enable" on page 561 .
show	s	Show REST API service configuration and status. See "webserver show" on page 562 .

webserver bind

Bind the REST API service to a network interface and port.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

webserver bind -netdevice <netdevice> [-port <port>] [-force] [-restart]

Argument(s)	Shortcut	Description
-netdevice <netdevice>	-n	Network device that REST API Service is to use for communication. Valid values: eth0, eth1, eth2, eth3, all, bond0, bond1
-force	-f	Force the action without prompting.
-port <port>	-p	Network port that REST API Service is to use for communication. Range: 80 to 65535 Default: 8443
-restart	-r	Restart the REST API service if parameter is specified. Otherwise, the administrator must restart the REST API service by running service start webserver .

Example

Attempting to bind the REST API service when the service is not enabled

```
webserver bind -netdevice eth0
```

```
Error: The REST API Service is not enabled.
The REST API Service must be enabled in order to execute this command.
```

```
Command Result : 65535 (Luna Shell execution)
```

Binding the REST API service without specifying the -restart option

```
webserver bind -netdevice eth0 -port 8443
```

```
WARNING: This operation will modify REST API Server binding information !!!
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
You chose not to restart REST API Service now.
```

The changes will be effective when REST API Service is restarted.
To restart it run: `service restart webserver`

Command Result : 0 (Success)

Binding the REST API service with the -restart option

```
lunash:>webserver bind -netdevice eth0 -restart
```

WARNING: This operation will modify REST API Server binding information !!!

Type 'proceed' to continue, or 'quit' to quit now.

```
> proceed  
Proceeding...
```

```
Restarting REST API service...
```

```
Command Result : 0 (Success)
```

webserver certificate

Syntax

webserver certificate

generate

show

Argument(s)	Shortcut	Description
generate	g	Create REST API service certificate. See " webserver certificate generate " on the next page.
show	s	Show REST API service configuration and status. See " webserver certificate show " on page 555.

webserver certificate generate

Generates a REST API Server certificate.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

```
webserver certificate generate -keytype <key_type> [-keysize <size>] [-curve <curve_name>] [-restart] [-force]
```

Argument(s)	Shortcut	Description
-keytype <key_type>	-keyt	Key type. Valid values: ecc,rsa
-keysize <size>	-keys	RSA key size (default to 2048). Valid values: 2048,3072,4096
-curve <curve_name>	-c	Elliptic Curve name (default to secp384r1).
-force	-f	Force the action without prompting.
-restart	-r	Restart the REST API service if parameter is specified. Otherwise, the administrator must restart the REST API service via other means (i.e., "service start webserver").

Example

```
lunash:>webserver certificate generate -keytype rsa -restart
```

```
WARNING: This operation will generate/regenerate the REST API Server certificate !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
Restarting REST API service...
Redirecting to /bin/systemctl restart webserver.service
```

```
REST API Server Certificate:
  Data:
    Version: 3 (0x2)
    Serial Number:
      d6:93:f0:66:1c:04:9f:34
    Signature Algorithm: sha384WithRSAEncryption
    Issuer: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=local_host
    Validity
      Not Before: Mar  1 20:22:56 2017 GMT
```

```

Not After : Feb 27 20:22:56 2027 GMT
Subject: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=local_host
Subject Public Key Info:
  Public Key Algorithm: rsaEncryption
    Public-Key: (2048 bit)
    Modulus:
      00:cf:f2:56:9b:22:24:f2:4e:bb:ab:8b:d3:38:42:
      24:65:0d:98:13:de:62:92:8f:5b:a5:6b:a5:ea:15:
      aa:08:f7:ae:c4:62:58:cf:54:3c:0b:16:fe:ba:71:
      93:ac:a9:71:14:f0:a7:41:94:0f:34:80:cc:fd:6d:
      d2:ae:2b:8d:a5:ef:f2:25:43:d6:5e:08:59:b7:1b:
      a1:7a:dc:96:08:c1:ee:c0:35:41:1e:90:7f:16:d1:
      32:d0:c6:4c:6b:df:3c:b3:48:2d:14:5f:fa:cc:b4:
      cf:11:27:3a:74:14:80:17:eb:87:c8:f6:41:35:91:
      c6:c5:60:67:87:d7:58:ba:b0:7b:97:b8:a9:08:de:
      67:c9:2d:cf:ac:08:3e:a1:c1:31:23:b3:cd:96:7b:
      af:45:4e:fd:e6:80:61:28:52:4e:27:27:9c:d6:01:
      19:ef:74:6e:15:7d:51:d4:62:be:38:a8:8f:04:7e:
      82:18:7c:75:a5:6a:4c:10:3e:d8:ec:86:03:52:fe:
      f7:15:0a:45:55:f4:ae:be:c7:88:e5:6b:09:be:18:
      27:96:54:c2:ad:30:8e:43:d9:0e:f4:4a:00:06:28:
      fb:08:cd:df:af:31:e3:1d:58:95:f8:51:90:ee:5a:
      48:3a:21:83:f1:53:59:a8:8f:7c:cf:e8:0f:b2:09:
      1c:49
    Exponent: 65537 (0x10001)
X509v3 extensions:
  X509v3 Subject Key Identifier:
    C1:20:E0:21:B8:19:7F:11:0B:57:7C:3E:0D:CA:70:63:6D:97:E4:CD
  X509v3 Authority Key Identifier:
    keyid:C1:20:E0:21:B8:19:7F:11:0B:57:7C:3E:0D:CA:70:63:6D:97:E4:CD

  X509v3 Basic Constraints:
    CA:TRUE
Signature Algorithm: sha384WithRSAEncryption
6c:b6:04:92:f9:52:6f:ae:1f:ef:b8:fa:f9:40:16:97:28:10:
f2:13:64:af:cb:67:63:4b:81:42:cb:00:cb:5a:9b:39:2d:88:
30:c1:75:bc:90:69:33:67:51:1c:05:c0:b1:e2:88:47:8e:ad:
48:28:eb:d0:24:e0:48:46:b0:5a:97:e8:c8:0d:39:b9:13:e3:
78:5a:c2:f6:66:cf:25:97:8e:0b:47:70:41:7e:e1:46:f5:4a:
25:9a:b0:3f:43:2b:4c:ed:64:b0:2d:24:13:17:2f:bd:09:11:
c0:15:f2:da:aa:7e:9d:27:2e:b5:cd:7d:0d:b5:80:23:14:3a:
8c:fc:e2:76:92:d1:87:1b:9e:a5:c6:ef:b2:a0:af:f3:15:cc:
41:84:5c:d1:fc:d3:3f:9a:c1:65:b0:bf:3c:be:e9:07:f4:25:
45:ff:f0:65:a7:a6:38:d8:f8:13:55:a6:ee:b1:9f:4a:31:c1:
d5:e2:b7:a2:f1:8d:07:72:cc:39:d1:4f:34:a7:df:1d:bc:4e:
d0:94:c4:f2:f9:a0:53:c4:fb:fe:03:4a:01:13:8b:bd:c0:ef:
ed:1b:90:c8:ec:e9:26:ee:90:9f:94:f2:9c:62:8e:09:55:27:
26:fb:00:02:3b:6b:5b:53:8a:b4:9c:25:7c:33:78:ec:40:30:
02:09:cf:20

```

Command Result : 0 (Success)

webserver certificate show

Shows the REST API Server certificate.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

webserver certificate show

Example

```
lunash:>webserver certificate show
```

```
REST API Server Certificate:
```

```
Data:
```

```
Version: 3 (0x2)
```

```
Serial Number:
```

```
d6:93:f0:66:1c:04:9f:34
```

```
Signature Algorithm: sha384WithRSAEncryption
```

```
Issuer: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=local_host
```

```
Validity
```

```
Not Before: Mar 1 20:22:56 2017 GMT
```

```
Not After : Feb 27 20:22:56 2027 GMT
```

```
Subject: C=CA, ST=Ontario, L=Ottawa, O=Gemalto, CN=local_host
```

```
Subject Public Key Info:
```

```
Public Key Algorithm: rsaEncryption
```

```
Public-Key: (2048 bit)
```

```
Modulus:
```

```
00:cf:f2:56:9b:22:24:f2:4e:bb:ab:8b:d3:38:42:
```

```
24:65:0d:98:13:de:62:92:8f:5b:a5:6b:a5:ea:15:
```

```
aa:08:f7:ae:c4:62:58:cf:54:3c:0b:16:fe:ba:71:
```

```
93:ac:a9:71:14:f0:a7:41:94:0f:34:80:cc:fd:6d:
```

```
d2:ae:2b:8d:a5:ef:f2:25:43:d6:5e:08:59:b7:1b:
```

```
a1:7a:dc:96:08:c1:ee:c0:35:41:1e:90:7f:16:d1:
```

```
32:d0:c6:4c:6b:df:3c:b3:48:2d:14:5f:fa:cc:b4:
```

```
cf:11:27:3a:74:14:80:17:eb:87:c8:f6:41:35:91:
```

```
c6:c5:60:67:87:d7:58:ba:b0:7b:97:b8:a9:08:de:
```

```
67:c9:2d:cf:ac:08:3e:a1:c1:31:23:b3:cd:96:7b:
```

```
af:45:4e:fd:e6:80:61:28:52:4e:27:27:9c:d6:01:
```

```
19:ef:74:6e:15:7d:51:d4:62:be:38:a8:8f:04:7e:
```

```
82:18:7c:75:a5:6a:4c:10:3e:d8:ec:86:03:52:fe:
```

```
f7:15:0a:45:55:f4:ae:be:c7:88:e5:6b:09:be:18:
```

```
27:96:54:c2:ad:30:8e:43:d9:0e:f4:4a:00:06:28:
```

```
fb:08:cd:df:af:31:e3:1d:58:95:f8:51:90:ee:5a:
```

```
48:3a:21:83:f1:53:59:a8:8f:7c:cf:e8:0f:b2:09:
```

```
1c:49
```

```
Exponent: 65537 (0x10001)
```

```
X509v3 extensions:
```

```
X509v3 Subject Key Identifier:
```

```
C1:20:E0:21:B8:19:7F:11:0B:57:7C:3E:0D:CA:70:63:6D:97:E4:CD
```

```
X509v3 Authority Key Identifier:
```

```
keyid:C1:20:E0:21:B8:19:7F:11:0B:57:7C:3E:0D:CA:70:63:6D:97:E4:CD
```

```
X509v3 Basic Constraints:
```

```
CA:TRUE
Signature Algorithm: sha384WithRSAEncryption
6c:b6:04:92:f9:52:6f:ae:1f:ef:b8:fa:f9:40:16:97:28:10:
f2:13:64:af:cb:67:63:4b:81:42:cb:00:cb:5a:9b:39:2d:88:
30:c1:75:bc:90:69:33:67:51:1c:05:c0:b1:e2:88:47:8e:ad:
48:28:eb:d0:24:e0:48:46:b0:5a:97:e8:c8:0d:39:b9:13:e3:
78:5a:c2:f6:66:cf:25:97:8e:0b:47:70:41:7e:e1:46:f5:4a:
25:9a:b0:3f:43:2b:4c:ed:64:b0:2d:24:13:17:2f:bd:09:11:
c0:15:f2:da:aa:7e:9d:27:2e:b5:cd:7d:0d:b5:80:23:14:3a:
8c:fc:e2:76:92:d1:87:1b:9e:a5:c6:ef:b2:a0:af:f3:15:cc:
41:84:5c:d1:fc:d3:3f:9a:c1:65:b0:bf:3c:be:e9:07:f4:25:
45:ff:f0:65:a7:a6:38:d8:f8:13:55:a6:ee:b1:9f:4a:31:c1:
d5:e2:b7:a2:f1:8d:07:72:cc:39:d1:4f:34:a7:df:1d:bc:4e:
d0:94:c4:f2:f9:a0:53:c4:fb:fe:03:4a:01:13:8b:bd:c0:ef:
ed:1b:90:c8:ec:e9:26:ee:90:9f:94:f2:9c:62:8e:09:55:27:
26:fb:00:02:3b:6b:5b:53:8a:b4:9c:25:7c:33:78:ec:40:30:
02:09:cf:20
```

```
Command Result : 0 (Success)
```

webserver ciphers

Set or show the REST API Server ciphers suite.

Syntax

webserver ciphers

set
show

Argument(s)	Shortcut	Description
set	se	Set REST API Server ciphers suite. See " webserver ciphers set " on the next page.
show	sh	Show REST API Server supported ciphers. See " webserver ciphers show " on page 559.

webserver ciphers set

Sets REST API Server ciphers suite.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

webserver ciphers set -list <cipher_list> [-restart] [-force]

Argument(s)	Shortcut	Description
-list <cipher_list>	-l	Colon-separated list of ciphers. To allow all ciphers, set " -list all ".
-force	-f	Force the action without prompting.
-restart	-r	Restart the REST API service if parameter is specified. Otherwise, the administrator must restart the REST API service by running service restart webserver .

Example

NOTE This example is small for illustrative purposes and does not reflect an adequate cipher suite for operational use.

```
lunash:>webserver ciphers set -list ECDHE-RSA-AES256-GCM-SHA384:ECDHE-ECDSA-AES256-GCM-
SHA384:ECDHE-RSA-AES256-SHA384:ECDHE-ECDSA-AES256-SHA384:DHE-DSS-AES256-GCM-SHA384:DHE-RSA-AES256-
GCM-SHA384:DHE-DSS-AES256-SHA256:DHE-DSS-AES256-SHA256:ADH-AES256-GCM-SHA384:ADH-AES256-
SHA256:ECDH-RSA-AES256-GCM-SHA384:ECDH-ECDSA-AES256-GCM-SHA384:ECDH-RSA-AES256-SHA384:ECDH-ECDSA-
AES256-SHA384:AES256-GCM-SHA384:AES256-SHA256 -restart
```

New REST API Service ciphers suite:

```
ECDHE-RSA-AES256-GCM-SHA384:ECDHE-ECDSA-AES256-GCM-SHA384:ECDHE-RSA-AES256-SHA384:ECDHE-ECDSA-
AES256-SHA384:DHE-DSS-AES256-GCM-SHA384:DHE-RSA-AES256-GCM-SHA384:DHE-DSS-AES256-SHA256:DHE-DSS-
AES256-SHA256:ADH-AES256-GCM-SHA384:ADH-AES256-SHA256:ECDH-RSA-AES256-GCM-SHA384:ECDH-ECDSA-
AES256-GCM-SHA384:ECDH-RSA-AES256-SHA384:ECDH-ECDSA-AES256-SHA384:AES256-GCM-SHA384:AES256-SHA256
```

```
Restarting REST API service...
Stopping webserv:OK
Starting webserv:OK
```

Command Result : 0 (Success)

webserver ciphers show

Show the REST API Server supported ciphers.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

webserver ciphers show

Example

```
lunash:>webserver ciphers show
```

Ciphers suite supported by REST API Server:

```
ECDHE-RSA-AES256-GCM-SHA384, ECDHE-ECDSA-AES256-GCM-SHA384, ECDHE-RSA-AES256-SHA384,  
ECDHE-ECDSA-AES256-SHA384, DHE-RSA-AES256-GCM-SHA384, DHE-RSA-AES256-SHA256,  
ECDH-RSA-AES256-GCM-SHA384, ECDH-ECDSA-AES256-GCM-SHA384, ECDH-RSA-AES256-SHA384,  
ECDH-ECDSA-AES256-SHA384, AES256-GCM-SHA384, AES256-SHA256, ECDHE-RSA-AES128-GCM-SHA256,  
ECDHE-ECDSA-AES128-GCM-SHA256, ECDHE-RSA-AES128-SHA256, ECDHE-ECDSA-AES128-SHA256,  
DHE-RSA-AES128-GCM-SHA256, DHE-RSA-AES128-SHA256, ECDH-RSA-AES128-GCM-SHA256,  
ECDH-ECDSA-AES128-GCM-SHA256, ECDH-RSA-AES128-SHA256, ECDH-ECDSA-AES128-SHA256,  
AES128-GCM-SHA256, AES128-SHA256
```

Command Result : 0 (Success)

webserver disable

Disable the REST API service.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

webserver disable [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting.

Example

```
lunash:>webserver disable
```

```
WARNING: This operation will stop and disable REST API Service !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed  
Proceeding...
```

```
Command Result : 0 (Success)
```


webservice enable

Enable the REST API service. After enabling the service, use **service start webservice** to start the service.

User Privileges

Users with the following privileges can perform this command:

> Admin

NOTE You must call **webservice bind** to access the REST API.

Syntax

webservice enable [-force]

Argument(s)	Shortcut	Description
-force	-f	Force the action without prompting - useful for scripting.

Example

```
lunash:> webservice enable
```

```
WARNING: This operation will enable REST API Service !!!
```

```
Type 'proceed' to continue, or 'quit' to quit now.
```

```
> proceed
Proceeding...
```

```
Command Result : 0 (Success)
```

webserver show

Display the REST API Server configuration.

User Privileges

Users with the following privileges can perform this command:

> Admin

Syntax

webserver show

Example

```
lunash:>webserver show
```

```
REST API Service:
```

```
=====
```

```
API Version: 5
```

```
Configuration: enabled
```

```
Status: running
```

```
IP address: 0.0.0.0
```

```
Port: 8443
```

```
Certificate Key Type: rsa
```

```
Key Size: 2048
```

```
Command Result : 0 (Success)
```